



Ben Liu
 Mobile/ WeChat: +86-13705041170
 FUZHOU SUNSHINE MACHINERY CO.,LTD
 NO.6 Gulouyuan, Juyuanzhou Industrial Zone,
 Jinshan Development Area, Fuzhou, Fujian, China.
 Email: sales@primepowergenset.com
<http://www.gensetengine.com>

Cummins KTA38 engine Spare parts catalog

Part number	Description
3010247	COV,VLV
3643960	SEAL,OIL
3633046	SEALFERRULE
3631244	PISTONENGINE
4089500	SET PISTONE RING
100478	SEALO RING
4026171	GASKET,FUEL PUMP
BM76340	DAMPER,FUEL CONTROL
AR7542	
3016792	SEAL,OIL 3016792
3053478	LEVER,ROCKER
3053476	LEVER,ROCKER
3053477	LEVERROCKER
3630839	GASKET,RKR LEVER HOUSING
3521225	SCREWHEXAGON HEAD SET
3076489	THERMOSTAT
212161	ORING
4024809	KIT,FUEL SOLENOID 4024809
175830	PLUGEXPANSION
3046283	SCREW, HEX FLANGE HEAD CAP
3046200	SPIDER,JAW COUPLING
3640775	SEALTAMPER PROOF
3090450	RING,OIL PISTON
3090460	RING,COMPRESSION PISTON
4081176	RING,COMPRESSION PISTON
3081489	SEALOIL
3635074	CORE, COOLER

3642503	LEVER,CAM FOLLOWER 3081413
3078218	SHAFT,CAM FOLLOWER
S172B	SCREW,HEXAGON HEAD CAP
S181	
S181C	SCREW, HEXAGON HEAD CAP
S186	
S189	SCREW
S189C	SCREW,SOCKET HEAD CAP
S197	
S200	NUT,HEAVY HEXAGON
S212	NUT,REGULAR HEXAGON
S2268	FITTING,GREASE
S251	
S306	
S316	KEY,PLAIN WOODRUFF
S600	WASHER,LOCK
S602	Washer, Plain
S603	WASHER,LOCK
S607	WASHER,LOCK
S608	WASHER,LOCK
S610	WASHER,LOCK
S611	WASHER,LOCK
S624	
S915A	PLUG,PIPE
S923E	DRAINCOCK
S955	BUSHING,REDUCING PIPE
S962E	DRAINCOCK
S965E	PLUG, PIPE
102020	SCREW,HEXAGON HEAD CAP
102978	DOWELPIN
103009	SCREW,HEXAGON HEAD CAP
103023	SCREW,HEXAGON HEAD CAP
106069	SCREW,HEXAGON HEAD CAP
107460	CLIP
107695	PINROLL
107948	DOWELDIAMOND
108172	SEAL,O RING
108330	WASHER,PLAIN
108602	SCREW,HEXAGON HEAD CAP
108707	SCREWHEXAGON HEAD CAP
108767	SCREW,HEXAGON HEAD CAP
109319	LOCKPLATE
109594	WASHERPLAIN
110266	SCREW,HEXAGON HEAD CAP
111445	WASHER,LOCK

114307	BRACE,TUBE
116391	BUSHING
118226	SCREW, SOCKET HEAD CAP
119810	PINPISTON
121229	ELBOWMALE ADAPTER
124507	GEAR, FLYWHEEL RING
127018	WASHER, LOCK
127362	WASHER, PLAIN
127571	WASHER, PLAIN
127936	SEALRECTANGULAR RING
127940	VALVECOMPRESSOR EXHAUST
127950	GASKETCONNECTION
128086	SEALO RING
129768	SPRINGVALVE
129838	KNOB
129839	COVER, SHUTOFF VALVE
129888	SEALRECTANGULAR RING
130083	BEARING, THRUST
131026	SEALO RING
131584	PIN, ROLL
135783	WASHER, LOCK
136574	SCREWHEXAGON HEAD CAP
138912	DOWEL, PIN
139473	PLUG, THREADED
139990	WASHERPLAIN
140315	CLAMP, T BOLT
144948	VALVECOMPRESSOR INTAKE
145028	SEATCPR INTAKE VALVE
145507	SEAL, O RING
145510	SEALO RING
145529	SEALO RING
145530	SEALO RING
145550	SEALO RING
145581	SEALO RING
145586	SEALO RING
145600	SEAL, O RING 4998542
145613	SEALO RING
147610	BUSHING
148582	DOWELPIN
149134	LOCKPLATE
150631	SPRINGCOMPRESSION
151355	LOCKPLATE
154087	SEAL, RECTANGULAR RING
155787	CONNECTIONAIR CPR INLET
158250	SCREW, TWELVE POINT CAP

158829	SCREW,HEXAGON HEAD CAP
163086	PLUG,PIPE
168306	SCREW,SLOTTED SET
169834	CLIP
178079	VALVE, CHECK
180371	CLIP
181466	WASHER,LOCK
3069102	GASKETAIR COMPRESSOR
3175255	GEAR,CRANKSHAFT
3521442	SEAL,SPLIT RING
3523429	HOUSINGTUR BEARING
185505	VALVECHECK
190397	SLEEVEWEAR
191772	SCREW,TWELVE POINT CAP
194037	SOCKETROCKER LEVER
195265	PLUGPIPE
199919	SCREWTWELVE POINT CAP
S1047A	ELBOW, HOSE
205230	BUSHING
200908	SCREWHEXAGON HEAD CAP
3007525	KIT LINER 3007525
201048	GASKETCONNECTION
201049	GASKET,CONNECTION
3047390	BEARING,CON ROD (STD)
203760	WASHER,PLAIN
203933	PLUGEXPANSION
204994	CONNECTORMALE
205059	WASHER,PLAIN
205091	COLLETVALVE
205093	INSERT,VALVE
205094	RETAINERVERVE SPRING
205126	WASHERPLAIN
205128	WASHER,PLAIN
205156	BUSHING
205227	PLUG, EXPANSION
205269	RINGRETAINING
205275	SCREWTWELVE POINT CAP
205314	SCREWTWELVE POINT CAP
205348	PLUNGERPRS REGULATOR
3177556	SEALRECTANGULAR RING
205354	SCREWTWELVE POINT CAP
205393	SCREW,TWELVE POINT CAP
3804301	SETLOWER ENGINE GASKET
205394	SCREW,TWELVE POINT CAP
205401	PLUGEXPANSION

205413	SCREWTWELVE POINT CAP
205438	LOCKWIRE
205439	RING,RETAINING
205462	LINKINJECTOR PLUNGER
205544	SHAFTLUB OIL PUMP
205565	SCREWTWELVE POINT CAP
205571	GASKETOIL SLINGER
205584	SCREWTWELVE POINT CAP
205683	BUSHING
205684	BRACKETLIFTING
205976	RING,RETAINING
206013	GASKETFLANGE
206028	SCREW,SOCKET HEAD CAP
206090	RINGRETAINING
206091	GEARENGINE BARRING
206093	HOUSINGENGINE BARRING
206158	COVER,HYD PUMP FLANGE
206177	GASKETPRS RLF VALVE BODY
206193	GASKETWATER PUMP
206195	SLEEVE,SPLINE COUPLING
206196	RINGRETAINING
206198	SEAL, OIL
206224	PLUG,EXPANSION
206277	GASKET,INTAKE MANIFOLD
206279	GASKETCONNECTION
206326	SCREW,TWELVE POINT CAP
206406	COVER,HYD PUMP FLANGE
206407	GASKET,HAND HOLE
206416	GASKETSUPPORT
206434	CONNECTIONAIR CROSSOVER
206436	TUBEAIR
206438	CONNECTIONAIR CROSSOVER
206443	GASKETTHERMOSTAT HOUSING
206460	GASKETCONNECTION
206526	POINTER,TIMING
206527	SCREW,TWELVE POINT CAP
206576	GASKETTURBOCHARGER
206580	BEARINGMAIN STD
206587	CAPMAIN BEARING
206588	CAPMAIN BEARING
206590	BEARINGMAIN STD
206600	BEARINGMAIN STD
206610	BEARINGMAIN STD
206709	TUBEWATER TRANSFER
206742	PLUG,EXPANSION

8265	WASHER,PLAIN
206756	GEARLUBRICATING OIL PUMP
8306	PINROLL
206904	KEY,PLAIN WOODRUFF
207226	BUSHING
207244	SEAL INJECTOR
207344	BUSHING
207373	COVER,CAMSHAFT
207509	SLEEVE
207515	GASKETCONNECTION
208084	RIVET
43765	ELBOWMALE ADAPTER
44680	LEVERTHROTTLE
60985	HOSE,PLAIN
67684	WASHER,PLAIN
67946	WASHER,PLAIN
68139	ELBOW,PLAIN ADAPTER
68152	CLIP
68189	CLIP
68193	PLUGPIPE
68445	PIN, GROOVE
68908	LOCKPLATE
69519	DOWELPIN
69558	DOWELPIN
69580	DOWELPIN
69771	SCREW,SOCKET HEAD CAP
69901	PLUGPIPE
70295	PLUGFUEL PUMP DRAIN
70415	SEAL,O RING
70662	DOWELPIN
70704	WASHER PLAIN
70897	NUT,LOCK
213559	SOCKET,CAM FOLLOWER
219153	BOLTCONNECTING ROD
553044	BUSHINGREDUCING PIPE
3000082	WASHER,PLAIN
3000138	SUPPORTBEARING
3000139	BEARINGTHRUST
3000174	HUBSPLINE COUPLING
3000204	WASHERSEALING
3000632	GASKET,CONNECTION
3001340	SEALO RING
3001663	GUIDEVALVE SPRING
3001811	SCREW,HEXAGON HEAD CAP
3002126	NUT,LOCK

3002158	PLUGPIPE
3002350	BRACKETOIL TUBE
3002351	BRACKETOIL TUBE
3002886	SCREWHEXAGON HEAD CAP
3002956	TUBEWATER TRANSFER
3002993	DOWEL,RING
3003156	SEAL,WIRE
3004272	LOCKPLATE
3004318	BRACKETOIL TUBE
3004683	GEAR,IDLER
3004686	BUSHING
3006696	CLAMPINJECTOR
3008465	PLUGPIPE
3008466	PLUGPIPE
3008468	PLUGPIPE
3008469	PLUGPIPE
3008717	TUBEWATER TRANSFER
3009109	PLATESWIRL
3010121	CONNECTIONWATER TRANSFER
3010410	COVERACCESS HOLE
3010595	SCREWCAPTIVE WASHER CAP
3010597	SCREWCAPTIVE WASHER CAP
3010635	ADAPTERFILTER HEAD
3011580	GASKETAFTERCOOLER COVER
3011884	INSERTLINER
3012472	SCREWCAPTIVE WASHER CAP
3012475	SCREWCAPTIVE WASHER CAP
3013036	SHAFTSHUTOFF VALVE
3013114	CONNECTIONAIR INTAKE
3013266	SCREWCONNECTING ROD CAP
3013643	VALVESHUTOFF
3013786	PLUGPIPE
3014010	BODYSHUTOFF VALVE
3014103	WASHER PLAIN
3014449	GASKETFLANGE
3014766	SCREW,CAPTIVE WASHER CAP
3015750	HOUSINGGOVERNOR
3016182	NUT,LOCK
3016825	ROLLERCAM FOLLOWER
3016826	ROLLERCAM FOLLOWER
3017961	RODPUSH
3019030	MANIFOLDAIR INTAKE
3019031	MANIFOLDAIR INTAKE
3019620	CONNECTIONWATER OUTLET
3019621	CONNECTIONWATER INLET

3021362	COVERAFTERCOOLER
3021394	FLYWHEEL
3021618	PLUNGERPRS REGULATOR
3021977	COVERSPRING PACK
3022590	SCREWCAPTIVE WASHER CAP
3023066	SEAL,O RING
3023536	SCREWHEXAGON HEAD CAP
3025460	PLUG, PIPE
3025485	WASHERPLAIN
3026296	INSERTVALVE
3026312	SHIM
3026313	SHIM
3026316	CONNECTIONOIL TRANSFER
3026556	BEARING, THRUST
3026557	BEARINGTHRUST
3026705	TUBELUB OIL TRANSFER
3028235	MANIFOLDEXHAUST
3028237	MANIFOLDEXHAUST
3028291	SEAL,O RING
3028552	BODYBYPASS VALVE
3030207	RETAINER,DIPSTICK
3030792	HOSE, HUMP
3030970	DISCVALVE
3031404	CONNECTOR, TUBE
3031928	BRACKETAFTERCOOLER
3031929	SUPPORTAFTERCOOLER
3032628	ELBOW,MALE UNION
3032633	SCREW,TWELVE POINT CAP
3033405	HEAD,LUB OIL FILTER
3033626	WASHERPLAIN
3033629	PIN,ROLL
3033853	SHAFTIDLER
3034243	PUMPGEAR FUEL
3034574	SCREWHEX FLANGE HEAD CAP
3035844	TUBE-FUEL IN
3036230	SCREWHEXAGON HEAD CAP
3037821	GASKET,EXHAUST MANIFOLD
3039164	LEVER,CAM FOLLOWER
5412990	BELTV RIBBED
3040721	GASKETCAM FOL HOUSING
3040722	GASKETCAMSHAFT COVER
3043211	GASKET,OIL PAN
3043212	GASKET,OIL PAN
3043909	Bushing, Connecting Rod
3043912	LOCKPLATE

3045136	WASHERPLAIN
3045137	SCREWHEXAGON HEAD CAP
3045229	SHAFTACCESSORY DRIVE
3045568	CONNECTIONWATER INLET
3046201	SEALO RING
3046202	PLUG,THREADED
3046852	GASKET,ACC DRIVE SUPPORT
3050453	IMPELLERWATER PUMP
3050944	GASKET,FLANGE
3053479	LEVER,ROCKER
154706	VALVEAIR STARTER
165006	SCR,CAP
184125	LOCKPLATE
184235	GASKETAIR COMPRESSOR
184240	CAPUNLOADER VALVE
188040	BEARINGTHRUST
190334	SPRINGVALVE
199358	SLEEVESPLINE COUPLING
199510	BUSHING
201982	DOWELRING
205169	GUIDEVALVE CROSSHEAD
4095009	PIN, PISTON K
205349	SPRINGVALVE
205532	GASKETLUB OIL PUMP
205545	SHAFTLUB OIL PUMP
205546	COVERLUB OIL PUMP
205547	
205548	BUSHING
205549	COVERLUB OIL PUMP
205607	SPRINGCOMPRESSION
205659	SPRINGCOMPRESSION
205661	GASKETBEARING SUPPORT
205662	GASKETPRS RLF VALVE BODY
206092	SPRINGCOMPRESSION
206179	GASKETCONNECTION
206421	GASKETGEAR HOUSING
206446	GASKET WTR TRANSFER TUBE
207038	SEALO RING
207251	GER,PMP
207253	
207551	SEALO RING
208045	CAPFILLER
211315	SEALO RING
211662	BEARINGTHRUST
216187	SEAL,O RING

3001718	BODYPRS RELIEF VALVE
3001719	PINSTRAIGHT
3003016	SEALO RING
3004594	GEAR
3005474	HUBSPLINE COUPLING
3005939	GASKETCOVER PLATE
3005940	GASKETGEAR HOUSING
3007441	SEALO RING
3007512	SEALO RING
3008710	SEALRECTANGULAR RING
3009323	GSK,COV
3009324	GASKET,WATER HEADER COVER 3637727
3009735	BODYUNLOADING VALVE
3009736	CLAMPRETAINING
3009738	SEALO RING
3009739	SEALO RING
3010269	DRIVE ACCESSORY
3628973	GSK,PLT
3013642	BODYFUEL SHUTOFF VALVE
3015068	SEALO RING
3016316	VALVECOUPLING
3018153	BUSHING
3021519	SPRINGCOMPRESSION
3022696	LUBRICATORAIR STG MOTOR
3022697	I/R Relay Valve
3023077	NIPPLECOUPLING
3023101	SPRINGCOMPRESSION
3023129	SEAL,DUST
3023130	SEALDUST
3025825	ROD2 CYL CPR CON
3026391	SEALRECTANGULAR RING
3026393	SEALO RING
3026421	SEALO RING
3026796	ELBOWPLAIN STREET PIPE
3027232	PLUGPIPE
3028296	COVER2 CYL COMPRESSOR
3028297	BODYUNLOADING VALVE
3028587	PULLEYACCESSORY DRIVE
3028696	COVER,OIL PAN :3178743
3028888	PLN,RGL
3030487	SPACERBEARING
3031544	SEAL,RECTANGULAR RING
3031736	ADAPTERCRANKSHAFT
3032030	CORE AFTERCOOLER
3032630	HEAD, FUEL FILT

3803529	K VLV,EXH
3037239	SPACERCRANKSHAFT
3040710	TUBE,WATER TRANSFER
3040810	
3040911	PLG,THD
3043642	WASHERSPRING
3043947	SEATCPR EXHAUST VALVE
3046625	SCREWHEXAGON HEAD CAP
3054489	SPRINGCOMPRESSION
3055069	PLUG,THREADED
3055776	GASKETAIR COMPRESSOR
3056615	COMPRESSOR,2 CYL AIR
3057139	RODPUSH
3058150	RINGCOMPRESSION PISTON
3058154	GASKETAIR COMPRESSOR
3058162	SUPPORTAIR COMPRESSOR
3058165	CRANKCASE2 CYL CPR
3058423	PLUNGERPRESSURE LIMITER
3058424	SPRINGCOMPRESSION
3063673	ELBOWMALE UNION
3063809	CLAMPT BOLT
3066498	SCREW,HEX FLANGE HEAD CAP
3066888	CAMSHAFT
3066889	CAMSHAFT
3067344	WASHER,PLAIN
3069026	CAP
3069779	SCREW,TWELVE POINT CAP
3076346	SLEEVEWEAR
3081064	HEAD, CYLINDER
3642365	SEAL, OIL
3084539	SEAL,O RING
3086362	CROSSHEAD,VALVE
3087563	PAN,OIL
3088317	LOCKPLATE
3160924	SEALDUST
4334080	GASKET,CYLINDER HEAD
3171368	GASKET,TURBOCHARGER
3175027	WASHER,PLAIN
3175032	GASKETBREATHER
3175056	SPACERMOUNTING
3175074	SCREWHEXAGON HEAD CAP
3175239	NUT,LOCK
3175247	TUBELUB OIL SUPPLY
3175267	TUBEWATER TRANSFER
3175281	SUPPORTBEARING

3175318	TUBE,LUB OIL DRAIN
3175452	HEADCORROSION RESISTOR
3175453	HEADCORROSION RESISTOR
3175514	SUPPORTAIR COMPRESSOR
3175517	GASKETFLANGE
3175528	CONNECTIONADAPTER
3175573	RINGRETAINING
3175658	TUBELUB OIL SUCTION
3175688	NIPPLEPLAIN HEXAGON
3175705	SEALFERRULE
3175716	ELBOW,MALE ADAPTER
3175790	
3175797	CONNECTIONFUEL BLOCK
3175856	GASKET,HAND HOLE
3175857	SUPPORTWATER PUMP
3176117	STUD
3176122	HOUSINGAFTERCOOLER
3176127	HEADLUB OIL FILTER
3176216	WEIGHTCRANKSHAFT COUNTER
3176218	DOWEL,RING
3176323	HOSEPLAIN
3176394	PLUGTHREADED
3176395	WASHERPLAIN
3176465	SCREWHEXAGON HEAD CAP
3176607	BREATHERCRANKCASE
3176618	DOWEL,DIAMOND
3176637	HOUSINGFLYWHEEL
3176710	TUBEFUEL SUPPLY
3176713	CONNECTIONOIL TRANSFER
3176772	SHAFT,ROCKER LEVER
3176834	CONNECTIONAIR CROSSOVER
3176857	DOWELRING
3176883	SHD,HET
3176918	HOUSING GEAR
3177025	TEEPLAIN ADAPTER
3177026	TUBEFUEL SUPPLY
3177039	TUBEBREATHER
3177040	SHAFTSHUTOFF VALVE
3177093	WASHERPLAIN
3177108	GASKETFILTER HEAD
3177133	BRACESTARTING MOTOR
3177160	GASKET,GEAR COVER
3177198	ELBOW,MALE UNION
3177366	CONNECTORMALE
3177433	COVER,LUB OIL FILTER

3177443	SCREWHEX FLANGE HEAD CAP
3177509	BUSHING
3177510	BUSHING
3177530	HOSE,PLAIN
3177558	TUBEAIR
4955577	BLOCK,CYLINDER
3177945	SCREWHEX FLANGE HEAD CAP
3178022	HED,FIL
3178076	GASKET,GEAR HOUSING
3178319	TUBEWATER BYPASS
3178320	TUBEWATER BYPASS
3178450	SHAFTIDLER
3178457	Washer, Plain
3178464	
3178764	COVERHAND HOLE
3178812	COVER,HAND HOLE 3642213
3178845	CONNECTIONFUEL BLOCK
3178846	CONNECTIONFUEL BLOCK
3178858	
3178947	SCREWHEXAGON HEAD CAP
3178988	GSK,TUR
3179000	DOWELPIN
3179026	GASKETCONNECTION
3179027	GASKETCONNECTION
3179035	GASKET,WTR TRF CONNECTION
3179664	VALVE, PISTON COOLING
3179821	ELBOWPLAIN UNION
3179935	PULLEYALTERNATOR
3179944	PULLEYACCESSORY DRIVE
3200287	SEALKEYWAY
3201125	SEALO RING
3201128	NUT,REGULAR HEXAGON
3201568	PLUGCOUPLING
3201583	PLUG,THREADED
3201585	SEALO RING
3201739	SHAFT,BARRING
3201740	ASSEMBLY,ENGINE BARRING
3202032	SPACERMOUNTING
3202210	GUIDEVALVE STEM
3252438	CONNECTORTUBE
3252444	ELBOWTUBE CONNECTOR
3279503	COVERFUEL PUMP
3279601	BODYFUEL PUMP
3279715	
3279794	SEALINJECTOR O RING

3279798	ACTUATOR
LF777	LF PKGA
3313306	FILTER
3648162	SEAL, DUST
3502449	SEAL,RECTANGULAR RING
3504967	WASHERPLAIN
3519163	SCREWDRIVE
3519535	NUTLOCK
3519623	COLLAR, THRUST
3519627	Bearing, Turbocharger
3519641	RINGRETAINING
3519783	SHIELD,TURBOCHARGER HEA
3521918	IMPELLERTURBO HC5A
3522597	PINROLL
3522631	CLAMPV BAND
3522904	LOCKPLATE
3522911	HOUSINGTURBINE
3523412	SEALSPLIT RING
3523980	SLINGEROIL
3524418	SHIM
3524419	BAFFLEOIL
3524861	HOUSINGCOMPRESSOR HC5A
3524862	DIFFUSERTURBOCHARGER
3525073	SCREWHEXAGON HEAD SET
3526985	BEARING, TUR THRUST
3527619	DATAPLATE
3558754	RINGRETAINING
3558813	WASHERPLAIN
3558860	RINGCOMPRESSION PISTON
3558870	RINGOIL PISTON
3559041	BREATHERCOMPRESSOR
3609964	CUPINJECTOR
3626493	HOSEPLAIN
3627309	ADAPTER,FILTER HEAD
3627697	
3627786	CONNECTIONADAPTER
3627808	SUPPORTTHM HOUSING
3627961	SEAL,THERMOSTAT
3627999	SUPPORTALTERNATOR
3628194	SCREW,HEXAGON HEAD CAP
3628196	SCREW,HEXAGON HEAD CAP
3628229	COVER,HAND HOLE
3628411	COVERSTARTER FLANGE
3628452	SCREWHEXAGON HEAD CAP
3628496	SPACERSHUTOFF VALVE

3628604	PLUG,PIPE
3628605	PLUG,PIPE
3628606	PLUG,PIPE
3628607	PLUG,PIPE
3628608	PLUG,PIPE
3628609	PLUG,PIPE
3628639	SHAFTWATER PUMP
3628652	DAMPER VISCOUS VIBRATION
3628798	GEAR,CRANKSHAFT
3628822	GEAR IDLER
3628823	GEAR,IDLER
3628894	SEALDUST
3628895	SEALOIL
3628902	WASHER,PLAIN
3629006	SPRINGVALVE
3629065	COVERWATER HEADER
3629066	COVER,WATER HEADER 3648236
4920076	GASKET,ROCKER LEVER COVER
3629141	GASKET,LUB OIL FIL COVER
3629387	GASKETFILTER HEAD
3629494	ELBOW,MALE ADAPTER
3629496	ELBOW,MALE ADAPTER
3629497	DRAINCOCK
3629516	CLIP
3629962	WASHER,PLAIN
3630874	GASKETFLYWHEEL HOUSING
3630969	GASKET,LUB OIL CLR HSG
3632225	ROD,ENGINE CONNECTING
3637731	GASKET,WATER HEADER COVER
3640338	HEAD, FUEL FILTER
3640685	ADAPTERO RING
3800730	SETUPPER ENGINE GASKET
3801884	TURBOHC5A
3803852	KIT,ASSESSORY DRIVE SEAL
3803880	SETCOMPRESSOR RING
3803890	KITCOMPRESSOR PISTON
3811988	HEADCYLINDER
3818885	SEAL,O RING
3913994	SEALO RING
3966349	GASKETEXHAUST MANIFOLD
4017621	PLUG,EXPANSION
4066112	SEAL,O RING
43696A	SEAL,O RING
43828A	CLAMP,HOSE
43828C	CLAMP,HOSE

69204D	RINGRETAINING
70183	RINGRETAINING
70811A	SHIM,FUEL PUMP GOVERNOR
AK6015SS	Hose, Flexible
AR11475	VALVE,PRESSURE RELIEF
AR12250	SET,MAIN BEARING (STD)
S1003A	SEAL, GROMMET
S103D	SCREW,HEXAGON HEAD CAP
S104	SCREW,HEXAGON HEAD CAP
S105	SCREW,HEXAGON HEAD CAP
S109	SCREW,HEXAGON HEAD CAP
S111	SCREW,HEXAGON HEAD CAP
S112	SCREW,HEXAGON HEAD CAP
S113	
S116	SCREW,HEXAGON HEAD CAP
S117	SCREW,HEXAGON HEAD CAP
S120	
S125	SCREW,HEXAGON HEAD CAP
S126	Screw, Hexagon Head Cap
S127	SCREW,HEXAGON HEAD CAP
S137	SCREW,HEXAGON HEAD CAP
S141	
S145	SCREW,HEXAGON HEAD CAP
S153	SCREW,HEXAGON HEAD CAP
S159B	
S16054	BEARING, BALL
S16069	BEARING, BALL
S163	SCREW, HEX HEAD CAP
S167B	SCREW,HEXAGON HEAD CAP
3503335	NUT, REGULAR HEXAGON
S910B	PLUG, PIPE
S1005A	ELBOW, MALE ADAPTER
3800729	SETSINGLE HEAD GASKET
S162A	SCREW,HEXAGON HEAD CAP
3628799	GEAR, IDLER
3630068	BODY, PISTON COOLING VALVE
S907A	PLUG, PIPE
3627723	RETAINER, SHAFT
3628187	SHAFT, WATER PUMP
3176012	ASSEMBLY, FRONT ENGINE SUP
3177812	SUPPORT, FRONT ENGINE
S121B	SCREW,HEXAGON HEAD CAP
S150A	SCREW,HEXAGON HEAD CAP
S167A	SCREW, HEXAGON HEAD CAP
3630681	SEAL, OIL

3175550	COVER, PROTECTIVE
3628939	PULLEY, ACCESSORY DRIVE
3027151	NAMEPLATE
3027935	DECAL
3315228	DECAL
3315230	DECAL
3318651	DECAL
3329609	DECAL
3329610	DECAL
3630483	COVER, PROTECTIVE
3630484	COVER, PROTECTIVE
3889382	DECAL
3803515	VALVE, INTAKE
205068	PIN, CAM FOLLOWER ROLLER
205071	PIN, CAM FOLLOWER ROLLER
3049688	GASKET, AIR COMPRESSOR
3016793	SEAL, OIL
3177006	PULLEY, ACCESSORY DRIVE
3009631	COVER, CAMSHAFT
3175805	BUSHING
102827	SEAL, O RING
AS6020SL	HOSE, FLEXIBLE
AS6022SL	HOSE, FLEXIBLE
3019581	MANIFOLD, FUEL LH
3019582	MANIFOLD, FUEL RH
AS602240SL	HOSE, FLEXIBLE
AS6024SL	HOSE, FLEXIBLE
AR12387	PUMP, LUBRICATING OIL
AR11461	SHAFT, LUB OIL PUMP DRIVE
AR12386	SHAFT, LUB OIL PUMP DRIVE
S174B	SCREW, HEXAGON HEAD CAP
205538	BODY, LUBRICATING OIL PUMP
205536	BODY, LUBRICATING OIL PUMP
3628330	GASKET, RKR LEVER HOUSING
3175861	BRACKET, SHIPPING
3627704	HOSE, FLEXIBLE
3627693	UNION, MALE
3628640	SUPPORT, WATER PUMP
3024195	SUPPORT, WATER PUMP
3627083	PUMP, WATER
3030489	BODY, WATER PUMP
3035248	SEAL, WATER PUMP
3626952	SHAFT, WATER PUMP
3176424	CRANKSHAFT, ENGINE
S106A	SCREW, HEXAGON HEAD CAP

S130A	SCREW, HEXAGON HEAD CAP
3052983	HEAD, COMPRESSOR
3056530	PISTON, COMPRESSOR
3053099	SUPPORT, AIR COMPRESSOR
3052970	CRANKCASE, COMPRESSOR
259375	AID, STARTING
214318	ALTERNATOR
3177540	COVER, GEAR
3177539	COVER, GEAR
S195B	SCREW, HEXAGON HEAD CAP
3023200	HEAD, FUEL FILTER
3176502	COVER, PROTECTIVE
AR11496	SUPPORT, AND BUSHING
3177278	SUPPORT, ACCESSORY DRIVE
3177279	SUPPORT, ACCESSORY DRIVE
3027923	VALVE, ONE BANK
3278090	PLUNGER, FUEL CONTROL
3278091	CONNECTION, FUEL BLOCK
AS8014SL	HOSE, FLEXIBLE
206517	FLYWHEEL
S149A	SCREW, HEXAGON HEAD CAP
3011650	GASKET, FILTER HEAD
3028890	GASKET, LUB OIL FIL COVER
3313279	ELEMENT, LUB OIL FILTER
AK6018SS	HOSE, FLEXIBLE
3039251	ADAPTER, OIL PAN
3626494	ROD, ENGINE CONNECTING
3053184	ROD, ENGINE CONNECTING
3803265	KIT, PISTON ENGINE
3166286	GASKET, CYLINDER HEAD
3179029	GASKET, CONNECTION
3067370	HOSE, PLAIN
3524450	TURBOCHARGER
3052309	PLUG, OIL DRAIN
3052310	CHAIN
3630106	DECAL KIT
3889381	DECAL
3630079	MOTOR, AIR STARTING
WF2075	WF PKG
AR11501	HSG, THM & SPT ASSEMBLY
3028238	MANIFOLD, EXHAUST
3176580	SCREW, HEX FLANGE HEAD CAP
3176582	HOSE, FLEXIBLE
206457	SEAL, O RING
3629112	CAP, FILLER

206455	GASKET,WATER PUMP
3053476RX	LEVER ROCKER
3086362RX	CROSSHEAD, VALVE
3017961RX	RODPUSH
3177040RX	SHAFTSHUTOFF VALVE