

Ben Liu

Mobile/ WeChat +86-13705041170

FUZHOU PRIME POWER CO.,LTD

[Sales@primepowergenset.com](mailto:Sales@primepowergenset.com)

[w: http://www.gensetengine.com](http://www.gensetengine.com)

**Cummins KTA19 QSK19 Engine Overhaul Parts**

No.	Cummins KTA19 and QSK19 Upper Engine Gasket Sets	Part No.
1	UPPER ENGINE GASKET SET – KTA19 / QSK19	4352587
2	UPPER ENGINE GASKET SET – KTA19 / QSK19 (NON-AFTERCOOLED )	3800727
3	CYLINDER HEAD GASKET SET – KTA19 / KTA38 / QSK19 / QSK38	3803600
4	UPPER ENGINE GASKET SET – KTA19 / QSK19	3804667
5	UPPER ENGINE GASKET SET – KTA19 / QSK19	3801895
6	UPPER ENGINE GASKET SET – K19 / KTA19 / QSK19	3801005
7	UPPER ENGINE GASKET SET – KTA19 / KTA38 / QSK19 / QSK38	4352580
8	UPPER ENGINE GASKET SET – KTA19 / QSK19	4352582
	Cummins KTA19 and QSK19 Lower Engine Gasket Sets	
9	LOWER ENGINE GASKET SET – KTA19 / QSK19	4376511
10	LOWER ENGINE GASKET SET – KTA19 / QSK19	4376512
11	LOWER ENGINE GASKET SET – KTA19 / KTA19GC / QSK19	4376512
12	LOWER ENGINE GASKET SET – KTA19 / QSK19	4089391
13	LOWER ENGINE GASKET SET – KTA19 / KTA38 / QSK19 / QSK38	3804301
14	LOWER ENGINE GASKET SET – KTA19 / QSK19	3801007
15	OIL PAN GASKET – KTA19 / QSK19	3042590
16	ADAPTER COVER GASKET – KTA19 / QSK19	3073213
17	LOWER ENGINE GASKET SET – KTA19 / QSK19	4089717
18	LOWER ENGINE GASKET SET – KTA19 / QSK19	4089390
19	OIL PAN ADAPTOR GASKET – KTA19 / QSK19	3042587
20	OIL PAN ADAPTOR GASKET – KTA19 / QSK19	3042588
21	LOWER ENGINE GASKET SET – KTA19 / QSK19	4089717
	Cummins KTA19 and QSK19 Turbochargers	
22	TURBOCHARGER KIT – KTA19 / QSK19	2882092
23	TURBOCHARGER – KTA19 / QSK19 (HX82, DRY)	2881849
24	REMANUFACTURED TURBOCHARGER (HOSE TYPE)	3801697
25	TURBOCHARGER – KTA19 / QSK19 (HC5A)	3801697
26	TURBOCHARGER – KTA19 / QSK19 (HT60)	3804860
27	TURBOCHARGER – KTA19 / QSK19 (BHT4C)	3803635
28	REMANUFACTURED TURBOCHARGER – KTA38 / QSK38 (HC5A)	3801695

29	REMANUFACTURED TURBOCHARGER (HC5A)	3803103
30	TURBOCHARGER – KTA19 / QSK19 (HX83, WATER COOLED)	2881848
31	TURBOCHARGER – KTA19 / QSK19 (HT60)	4089084
32	TURBOCHARGER KIT – KTA19 / QSK19	2881870
33	TURBOCHARGER KIT – KTA19 / QSK19	4309466
	Cummins KTA19 and QSK19 Aftercoolers	
34	AFTERCOOLER CORE – KTA19 / QSK19	3001299
35	AFTERCOOLER CORE – QSK19	4910356
36	AFTERCOOLER CORE – QSK19	4927220
37	AFTERCOOLER CORE – KTA19 / QSK19	4975632
38	AFTERCOOLER CORE – KTA19 / QSK19	4910355
	Cummins KTA19 and QSK19 Cylinder Heads	
39	CYLINDER HEAD – KTA19 / QSK19	3641566
40	CYLINDER HEAD – KTA19 / QSK19	3646328NX
41	CYLINDER HEAD – KTA19 / QSK19	3646329NX
42	CYLINDER HEAD – KTA19 / QSK19	4955911
	Cummins KTA19 and QSK19 Cylinder Head Gaskets	
43	CYLINDER HEAD GASKET SET – KTA19 / QSK19 (SINGLE)	4376269
44	CYLINDER HEAD GASKET SET – KTA19 / QSK19	4352576
45	CYLINDER HEAD GASKET – KTA19 / KTA38 / KTA50 / QSK19	3634664
46	CYLINDER HEAD GASKET – KTA19 / KTA38 / KTA50 / QSK19	3166288
47	CYLINDER HEAD GASKET SET – KTA19 / QSK19 (SINGLE)	3800726
48	CYLINDER HEAD GASKET SET – KTA19 / QSK19	4024805
49	CYLINDER HEAD GASKET SET – KTA19 / QSK19	4024806
50	CYLINDER HEAD GASKET SET – KTA19 / QSK19 (SINGLE)	4352577
51	CYLINDER HEAD GASKET SET – KTA19 / QSK19 (SINGLE)	4352583
	Cummins KTA19 and QSK19 Valve Train Components	
52	INTAKE AND EXHAUST VALVE GUIDE – KTA19 / KTA38	3202210
53	EXHAUST VALVE KIT – KTA19 / KTA38 / KTA50 / QSK19	3803528
54	EXHAUST VALVE INSERT – KTA19 / KTA38 / KTA50	205093
55	INTAKE VALVE SEAT INSERT – KTA19 / KTA38 / KTA50	3052819
56	INTAKE VALVE SEAT INSERT – KTA19 / QSK19 / QSK38	3026296
57	INTAKE VALVE – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	3803515
58	EXHAUST VALVE KIT – KTA19 / KTA38 / KTA50 / QSK19	3803529
59	EXHAUST VALVE – KTA19 / QSK19 / QSK60 / QSK95	3090469
60	VALVE BRIDGE GUIDE – KTA19 / QSK19 (CROSSHEAD)	205169
61	CYLINDER HEAD EXHAUST VALVE – QSK19 / KTA38 / QSK38	3088391

62	PUSH ROD – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	3017961
63	CAM FOLLOWER LEVER – KTA19 / QSK19 / KTA38 / QSK38	3039163
64	INTAKE VALVE SEAT INSERT – KTA19 / KTA38 / KTA50	3031098
65	INTAKE AND EXHAUST VALVE GUIDE – KTA19 / KTA38	3018818
66	INTAKE VALVE KIT – KTA19 / KTA38 / KTA50	3803518
67	PUSH ROD – KTA19 / QSK19	3408259
68	PUSH ROD – KTA19 / QSK19	3090378
69	ROCKER LEVER – NH220 / NH250 / NT855 / VTA 1710	AR2308
70	CAM FOLLOWER LEVER – KTA19 / QSK19 / KTA38 / QSK38	3039164
71	EXHAUST VALVE – KTA19 / QSK19 / QSK60 / QSK95	2881813
72	CAM FOLLOWER LEVER – KTA19 / QSK19 / KTA38 / QSK38	3642503
73	INTAKE VALVE KIT – KTA19 / QSK19 / KTA38 / QSK38	2881836
74	ROCKER LEVER – KTA19 / QSK19 / KTA38 / QSK38 / KTA50	3053477
75	INTAKE VALVE SEAT INSERT – KTA50 / QSK50 / KTA19	3086193
76	INTAKE VALVE KIT – KTA19 / QSK19 / QSK45 / QSK60 / QSK95	2881810
77	INTAKE VALVE KIT – KTA19 / QSK19 / QSK60 / QSK95	2881815
78	EXHAUST VALVE KIT – KTA19 / QSK19 / QSK60 / QSK95	2881812
79	EXHAUST VALVE KIT – KTA19 / KTA38 / KTA50 / QSK19	4955286
	Cummins KTA19 and QSK19 Fresh Water Pumps	
80	WATER PUMP KIT – KTA19 / QSK19	2881826
81	WATER PUMP – KTA19 / QSK19 (WITH WATER FILTER MOUNT)	3098964
82	WATER PUMP – KTA19 / QSK19	4910310
83	WATER PUMP – KTA19 / QSK19	3286471
84	WATER PUMP – KTA19 / QSK19	-4025310
85	WATER PUMP – KTA19 / QSK19	4950317
	Cummins KTA19 and QSK19 Raw Water Pumps	
86	RAW WATER PUMP – KTA19 / QSK19 (GILKES)	3074540
87	RAW WATER PUMP – KTA19 / QSK19	4968776
88	RAW WATER PUMP – KTA19 / QSK19	3866609
	Cummins KTA19 and QSK19 Thermostats	
89	THERMOSTAT – KTA19 / QSK19	4967783
90	THERMOSTAT – KTA19 / QSK19	3607932
91	THERMOSTAT – KTA / QSK (176°F, NON VENTED)	3629205
92	THERMOSTAT – KTA19 / QSK19	4922278
	Cummins KTA19 and QSK19 Repair Kits	
93	WATER PUMP REPAIR KIT – KTA19 / QSK19 (MAJOR )	3803153
94	WATER PUMP REPAIR KIT – KTA19 / QSK19 (MINOR)	3897386

95	WATER PUMP REPAIR KIT – KTA19 / QSK19 (MAJOR)	3803283
96	RAW WATER PUMP REPAIR KIT – KTA19 / KTA38 (MAJOR)	3897385
97	RAW WATER PUMP REPAIR KIT – KTA19 / KTA38 / KTA50 (MAJOR)	3866065
98	WATER PUMP REPAIR KIT – KTA19 / QSK19 (MAJOR)	3804573
99	RAW WATER PUMP REPAIR KIT – KTA19 / QSK19	3074619
100	RAW WATER PUMP REPAIR KIT – KTA19 / QSK19	3074620
	Cummins KTA19 and QSK19 Heat Exchangers	
101	HEAT EXCHANGER – QSK19	4019774
102	HEAT EXCHANGER – KTA19 / QSK19	4078339
103	HEAT EXCHANGER – KTA19 / QSK19	3968807
104	HEAT EXCHANGER – QSK19	3968809
105	HEAT EXCHANGER – QSK19	3968810
106	HEAT EXCHANGER – QSK19	4959469
107	HEAT EXCHANGER CORE – QSK19	4019516
108	HEAT EXCHANGER CORE – KTA19 / QSK19	3968806
109	HEAT EXCHANGER CORE – KTA19 / QSK19	3968761
110	HEAT EXCHANGER COOLER CORE – QSK19 / KTA38 / QSK38	3968805
111	HEAT EXCHANGER PLATE – KTA19-MX (LOW THETA B)	3349266
112	HEAT EXCHANGER PLATE – KTA19-MX (HIGH THETA B)	3349267
113	HEAT EXCHANGER PLATE – KTA19-MX (HIGH THETA A)	3393446
114	HEAT EXCHANGER PLATE – KTA19-MX (HIGH THETA, END PLATE 2)	3393448
115	HEAT EXCHANGER PLATE – KTA19-MX (END PLATE 1, HIGH THETA)	3393447
	Cummins KTA19 and QSK19 Fuel Injectors	
116	FUEL INJECTOR ASSEMBLY – KTA19 / QSK19 (PTK)	3016676
117	FUEL INJECTOR ASSEMBLY – KTA19 / QSK19 (PTK)	3022197
118	FUEL INJECTOR ASSEMBLY – KTA19 / QSK19 (PTK)	3016675
119	REMANUFACTURED FUEL INJECTOR – KTA19 / QSK19 / QSK19G	3008899
120	FUEL INJECTOR ASSEMBLY – KTA19 / QSK19 (PTK)	3052255
121	FUEL INJECTOR ASSEMBLY – KTA19 / QSK19 (PTK)	3053124
122	FUEL INJECTOR ASSEMBLY – KTA19 / QSK19 (PTK)	3022196
123	INJECTOR – KTA19 / QSK19	3087587
124	FUEL INJECTOR – K19 / KTA19 / QSK19	4928347
125	FUEL INJECTOR – KTA38 / KTA50 / QSK19 / QSK38 / QSK50	2882078
126	FUEL INJECTOR – QSK19	4955524
127	FUEL INJECTOR – KTA38 / KTA50 / QSK19 / QSK38 / QSK50	2882077
	Cummins KTA19 and QSK19 Fuel Lines	
128	FUEL CONNECTOR TUBE – KTA19 / QSK19 / KTA38 / QSK39 / KTA50	3031404

129	FUEL MANIFOLD – KTA19 / QSK19	207441
130	MALE ADAPTER ELBOW – KTA19 / QSK19 / KTA50 / QSK50	3095292
131	FUEL TUBE CONNECTOR – KTA19 / QSK19 / KTA50 / QSK50	3629437
132	FUEL TUBE CONNECTOR – KTA19 / QSK19 / KTA50 / QSK50	3630840
133	FUEL BLOCK CONNECTION – KTA19 / QSK19	207442
	Cummins KTA19 and QSK19 Camshaft Components	
134	CAMSHAFT – KTA19 / QSK19	3408299
135	CAMSHAFT BUSHING – KTA19 / QSK19	3002834
136	CAMSHAFT – KTA19 / QSK19	3066877
137	CAMSHAFT – KTA19 / QSK19 (STC)	3066882
138	REMANUFACTURED CAMSHAFT – KTA19 / QSK19	3066881
139	REMANUFACTURED CAMSHAFT – KTA19 / QSK19	3066880
140	REMANUFACTURED CAMSHAFT – KTA19 / QSK19	3066879
141	CAMSHAFT THRUST BEARING	3007971
142	CAMSHAFT – KTA19 / QSK19	3076767
143	CAMSHAFT – KTA19 / QSK19	3096412
144	CAMSHAFT – KTA19 / QSK19	3066887
145	CAMSHAFT – KTA19 / QSK19	4098459
146	CAMSHAFT – KTA19 / QSK19	4067667
147	CAMSHAFT – KTA19 / QSK19	3066878
148	CAMSHAFT BUSHING – KTA19 / QSK19	3081677
	Cummins KTA19 and QSK19 Piston Kits	
149	PISTON KIT – KTA19 / QSK19	4352368
150	PISTON KIT – KTA19 / QSK19	4955233
151	PISTON KIT – KTA19 / KTA38 / QSK19 / QSK38 (OFFSET PIN)	3631241
152	PISTON KIT – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	3631245
153	PISTON KIT – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	3631246
154	PISTON KIT – KTA19 / KTA38 / QSK19 / QSK38 (14.5:1)	3631244
155	PISTON KIT – KTA19 / KTA38 / QSK19 / QSK38	3631242
156	PISTON BODY – KTA38 / QSK38 / KTA19 / QSK19 / KTA50	3096680
157	PISTON KIT – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	4090013
158	PISTON KIT – KTA19 / QSK19	4955235
159	PISTON KIT – KTA19 / QSK19	4955325
160	PISTON KIT – KTA19 / QSK19	3806278
161	PISTON KIT – KTA19 / QSK19	4955236
	Cummins KTA19 and QSK19 Piston Ring Sets	
162	PISTON RING SET – KTA19 / QSK19	4352358

163	PISTON RING SET – KTA19 / QSK19 / QSK50 / QSK60 / QSK95	4309503
164	PISTON RING SET – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	2865146
165	PISTON RING SET – KTA19 / KTA38 / QSK19 / QSK38	4955975
166	PISTON RING SET – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	4955976
167	PISTON RING SET – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	4090028
168	PISTON RING SET – KTA19 / QSK19 / QSK50	4352282
	Cummins KTA19 and QSK19 Connecting Rod Bearings	
169	CONNECTING ROD BEARING – KTA19 / QSK19 (STANDARD)	205840
170	CONNECTING ROD BUSHING – KTA19 / KTA38 / QSK19 / QSK38	3043909
171	CONNECTING ROD BEARING – KTA19 / QSK19 (.010)	205841
172	CONNECTING ROD BEARING – KTA19 / QSK19 (.020)	205842
173	CONNECTING ROD BEARING – KTA19 / QSK19 (.030)	205843
174	CONNECTING ROD – KTA19 / QSK19	3811995
175	CONNECTING ROD – KTA19 / QSK19	4910522
	Cummins KTA19 and QSK19 Liners and Liner Kits	
176	CYLINDER LINER KIT – QSK19 (STANDARD)	S-4371769
177	CYLINDER LINER KIT – KTA19 / QSK19 (STANDARD)	4371782
178	CYLINDER LINER KIT – KTA19 / QSK19 (STANDARD)	4352259
179	CYLINDER LINER KIT – KTA19 / QSK19 (STANDARD)	4371783
180	CYLINDER LINER KIT – KTA19 / QSK19 (STANDARD)	4371773
181	CYLINDER LINER KIT – KTA19 / QSK19 (STANDARD)	4371779
182	CYLINDER LINER KIT – KTA19 / QSK19 (STANDARD)	4371775
183	CYLINDER LINER – KTA19 / QSK19 (STANDARD)	4024767
184	CYLINDER LINER – KTA19 / QSK19 (STANDARD)	4009220
185	CYLINDER LINER KIT – KTA19 / QSK19 (STANDARD)	4024770
186	CYLINDER LINER KIT – KTA19 / QSK19 (.020)	4024773
187	CYLINDER LINER KIT – KTA19 / QSK19	4090054
188	CYLINDER LINER KIT – KTA19 / QSK19 (.020, UPD)	4024768
189	LINERS KIT – K19 / KTA19 / QSK19 (0.95 O/S)	4009230
190	CYLINDER LINER KIT – KTA19 / QSK19 (.040, UPD)	4009222
191	CYLINDER LINER KIT – KTA19 / QSK19 (.020, UPD)	4009221
192	CYLINDER LINER KIT – KTA19 / KTA38 / QSK19 / QSK38	3801268
193	CYLINDER LINER KIT – KTA19 / QSK19 (.020)	3012612
194	CYLINDER LINER KIT – KTA19 / QSK19 (.010)	3012611
195	CYLINDER LINER KIT – KTA19 / QSK19 (.095, UPD)	4024772
196	CYLINDER LINER KIT – KTA19 / QSK19 (.083, UPD)	4024771
197	CYLINDER LINER KIT – KTA19 / QSK19 (.060, UPD)	4024775

198	CYLINDER LINER KIT – KTA19 / QSK19 (.040, UPD)	4024769
199	CYLINDER LINER KIT – KTA19 / QSK19 (.060/.020, UPD)	4024774
	Cummins KTA19 and QSK19 Crankshafts	
200	CRANKSHAFT – KTA19 / QSK19	3347569
201	CRANKSHAFT – KTA19 / QSK19 (W/O GEAR)	3096362
202	CRANKSHAFT – QSK19	3418898
203	CRANKSHAFT – QSK19	3331588
204	CRANKSHAFT – QSK19	4963966
205	CRANKSHAFT – QSK19	3331586
206	CRANKSHAFT – QSK19	4910530
	Cummins KTA19 and QSK19 Crankshaft Bearings and Seals	
207	MAIN BEARING SET – KTA19 / QSK19 (STANDARD)	AR12270
208	MAIN BEARING SET – KTA19 / KTA38 / KTA50 / QSK19	AR12250
209	FRONT CRANKSHAFT OIL SEAL – KTA19 / KTA38 / QSK19 / QSK38	3016792
210	REAR CRANKSHAFT SEAL – KTA19 / QSK19	3006236
211	MAIN BEARING SET – KTA19 / QSK19 (.010 )	AR12271
212	MAIN BEARING SET – KTA19 / QSK19 (.020)	AR12272
213	MAIN BEARING SET – KTA19 / QSK19 (.030)	AR12273
214	WEAR SLEEVE – K19 / KTA19 / QSK19	3006236S
215	REAR CRANKSHAFT SEAL – KTA19 / QSK19	3090297
216	REAR CRANKSHAFT SEAL – KTA19 / QSK19	4089902
217	FRONT CRANKSHAFT OIL SEAL KIT – KTA19 / QSK19	3804703
	Cummins KTA19 and QSK19 Oil Coolers	
218	OIL COOLER KIT – K19 / KTA19 / QSK19	3804935
219	OIL COOLER KIT – KTA19 / QSK19	3804934
220	OIL COOLER CORE – KTA19 / QST30	4068308
221	OIL COOLER ASSEMBLY TORQUE CONVERTER – QSK19	3201153
222	OIL COOLER GASKET – KTA19 / QSK19	3065792
	Cummins KTA19 and QSK19 Piston Cooling Nozzles	
223	PISTON COOLING NOZZLE – KTA19 / QSK19	3007517
224	PISTON COOLING NOZZLE – KTA19 / QSK19	3804664
225	PISTON COOLING NOZZLE – KTA19 / QSK19	3897840
	Cummins KTA19 and QSK19 Oil Filters	
226	OIL FILTER (FULL FLOW, SPIN-ON)	LF670
227	OIL FILTER CARTRIDGE (SPIN-ON)	LF777
228	OIL FILTER CARTRIDGE (BY-PASS)	LF750A
	Cummins KTA19 and QSK19 Exhaust Manifolds	

229	EXHAUST MANIFOLD – KTA19 / QSK19	4970925
230	EXHAUST MANIFOLD GASKET – KTA19 / QSK19	3043097
231	EXHAUST MANIFOLD – KTA19 / QSK19 (WATER COOLED)	3078024
232	EXHAUST MANIFOLD – KTA19 / QSK19	205186
233	EXHAUST MANIFOLD – KTA19 / QSK19	4098953
234	EXHAUST MANIFOLD – KTA19 / QSK19	4098951
235	EXHAUST MANIFOLD – KTA19 / QSK19	4098955
236	EXHAUST MANIFOLD – KTA19 / QSK19	205337
237	EXHAUST MANIFOLD – KTA19 / QSK19	3329562
238	EXHAUST MANIFOLD – KTA19 / QSK19	4997756
239	EXHAUST MANIFOLD – KTA19 / QSK19	3084620
240	EXHAUST MANIFOLD – KTA19 / QSK19	3037824
241	EXHAUST MANIFOLD – QSK19	2888643
	Cummins KTA19 and QSK19 Belts	
242	BELT – K38 / KTA50 / QSK38 / QSK45 / QSK45G / QSK50	5413029
243	V-BELT – K19 / KTA19/QSK19 / KTA19GC / QSK19	178568
244	V-BELT – KTA19 / QSK19	178460
245	RIBBED BELT – KTA19 / QSK19	206996
246	RIBBED V-BELT – KTA19 / QSK19	3347727
247	RIBBED V-BELT – KTA19 / QSK19	3090365
248	BELT TENSIONER – KTA19 / QSK19	2888888
249	SERPENTINE BELT – K19 / KTA19 / KTA19GC / QSK19	3002203
250	BELT TENSIONER – KTA19 / QSK19	2888887
251	RIBBED V-BELT – KTA19 / QSK19	3090123
252	RIBBED V-BELT – K19 / KTA19 / KTA19GC / QSK19	3002206
253	ENGINE BELT – K19 / KTA19 / KTA19GC / QSK19	178699
254	ENGINE BELT – K19 / KTA19 / KTA19GC / QSK19	3002207
	Cummins KTA19 and QSK19 Starters	
255	STARTER – KTA19 / QSK19	4337600
256	COMPRESSION SPRING – KTA19 / QSK19 / QST30	3086269
257	STARTER – ISX / KTA19 / QSK19 / QSX	4081239
258	STARTER	4081235
259	STARTER – KTA19 / QSK19	4081236
260	STARTER – KTA19 / QSK19 / QST30	4081237
261	STARTER – KTA19 / QSK19	3004699
262	STARTER – KTA19 / QSK19	3632272
263	STARTER – ISX / KTA19 / QSK19 / QSX	4081238



	Cummins KTA19 and QSK19 Senders and Switches	
264	TEMPERATURE SWITCH	4327015
265	TEMPERATURE SWITCH – KTA19 / QSK19	4327023
266	PRESSURE SENSOR – KTA / QSK	2894868
267	TEMPERATURE SENSOR – KTA19 / KTA38 / QSK19 / QSK38	4326919
268	PRESSURE SENSOR – KTA19 / QSK19	2872882
269	TEMPERATURE SWITCH – K19 / KTA19 / QSK19	3408627
270	BLOWBY FLOW SENSOR – KTA / QSK / QST / QSV	5461522
271	TEMPERATURE SWITCH – KTA19 / KTA38 / QSK19 / QSK38	4917761
272	PRESSURE SENSOR – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	3408515
273	TOGGLE SWITCH – KTA19 / QSK19	3612761
274	TEMPERATURE SWITCH – KTA19 / QSK19	3286266
275	TEMPERATURE SWITCH – KTA19 / QSK19	3090106
276	RELAY SWITCH	3628971
277	PRESSURE SWITCH – KTA19 / QSK19	4984591
278	PRESSURE SWITCH – KTA19 / QSK19	3286122
279	FLUID LEVEL SWITCH – KTA19 / QSK19	3001723
280	FLUID LEVEL SWITCH	3348814
281	ENGINE STARTER SWITCH SOLENOID – K19 / KTA19 / QSK19	3055737
282	TEMPERATURE SENSOR – KTA19 / QSK19	3090104
283	TEMPERATURE SENSOR – KTA19 / KTA38 / QSK19 / QSK38	4099166
284	PRESSURE SENSOR – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	4954405
285	PRESSURE SENSOR – KTA19 / KTA38 / QSK19 / QSK38	4098644
286	PRESSURE SENSOR – KTA19 / QSK19	3408519
287	PRESSURE SENSOR – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	3408600
288	MAGNETIC PICKUP	213272
289	TEMPERATURE SWITCH – KTA19 / QSK19	3090107
290	ROTARY SWITCH – KTA / QSK	2871200
291	SPEED SENSOR – KTA19 / KTA38 / QSK19 / QSK23 / QSK38	4042082
292	PRESSURE SENSOR – KTA19 / KTA38 / QSK19 / QSK38 / QSK50	4927803
293	PRESSURE SWITCH – KTA19 / QSK19	4307058
294	PRESSURE SWITCH – KTA19 / QSK19	2897709
295	PRESSURE SWITCH – KTA19 / QSK19	2897711
296	PRESSURE SWITCH – KTA19 / QSK19	2897710
297	TEMPERATURE SWITCH – KTA19 / KTA38 / QSK19 / QSK38	4327014
298	TEMPERATURE SWITCH	4327017
299	PRESSURE SWITCH – KTA19 / QSK19	4984664

300	FLUID LEVEL SWITCH	4072714
	Parts for Cummins KTA19 and QSK19 Engines	
301	OIL PUMP – KT19 / KTA19 / QSK19	3047549
302	CYLINDER BLOCK – KTA19 / QSK19	3811921
303	CYLINDER BLOCK – KTA19 / QSK19	3811923
304	FUEL SHUTDOWN VALVE – K19 / KTA19 / KTA19GC / QSK19	3035344
305	FLYWHEEL RING GEAR – ISM11 / K19 / N14 / NH855 / NT855 / M11 / QSM11(118 TFFTH)	4851
306	PIN – KTA19 / QSK19 / KTA38 / QSK38 / KTA50 / QSK50	4009479
307	O-RING SEAL – KTA19 / KTA19GC / QSK19 / QSK19G	3028291
308	GEAR COVER PLATE GASKET – KTA19 / QSK19	3410141
309	VALVE COVER GASKET – QSK60 / QSK60G / K19 / KTA19	3081898
310	HYDRAULIC PUMP GASKET – KTA19 / KTA19GC / QSK19 / QSK19G	3008400
311	DIPSTICK (BLANK, 90.0 INCHES)	216484
312	EXHAUST CLAMP – KTA19 / QSK19 / KTA38 / QSK38	201989
313	FILLER CAP – ISM / KTA19 / NH220 / NH250 / NT855 / QSK19 / QSM	162654
314	WATER PUMP BEARING	3003354
315	LOCK NUT – KTA19 / QSK19 / KTA38 / QSK38	3016182
316	HEXAGON FLANGE NUT – KTA19 / QSK19 / KTA50 / QSK50	3632305
317	FREQUENCY METER – GTA38 / K19 / KTA19G / QSK19 / QSK38 / NH855 / NT855	3015044
318	INJECTOR AND VALVE ADJUSTMENT KIT – K19 / K38 / K50	3822575
319	OFFSET WOODRUFF KEY – V504 / V555 / V903 / KTA19 / QSK19 / KTA50 / QSK50	200708
320	PLAIN HOSE – KTA19 / QSK19 / KTA50 / QSK50 / KTA38 / QSK38	60985
321	PLAIN HOSE – KTA19 / QSK19 / KTA50 / QSK50 / KTA38 / QSK38	3630125
322	HUMP HOSE – KTA19 / QSK19 / KTA50 / QSK50	3634116
323	HUMP HOSE	3636437
324	MALE ADAPTER ELBOW – ISB / KTA19 / QSK19	116936
325	GOVERNOR CONTROL – KTA19 / QSK19	3098693
326	VALVE SPRING COMPRESSOR TOOL – KTA19 / QSK19 / KTA38 / QSK38	3163606
327	EXHAUST CLAMP – KTA19 / QSK19 / KTA38 / QSK38 / KTA50	4936174
328	EXHAUST CLAMP – KTA19 / QSK19 / KTA50 / QSK51	3089765
329	EXHAUST CLAMP – KTA19 / QSK19 / KTA50 / QSK50	3029631
330	T-BOLT CLAMP – ISC / QSC / KTA19 / QSK19	140314
331	CYLINDER HEAD LEAK TEST KIT – KTA19 / QSK19 / QSK23 / QSK45 / QSK60 / QSK95	3164341
332	FLEXIBLE HOSE – KTA19 / QSK19 / VTA Series / NH220 / NH250 / NT855	2870338
333	OIL PUMP – KTA19 / QSK19	3096326RX
334	SEA WATER PUMP GEAR – KTA19 / QSK19 / KTA38 / QSK38 / KTA50	3008841
335	INJECTOR ADAPTER O-RING – NH / NT 855 / K19 / V555 / 855 / L10	193736