

**Ben Liu**

Mobile/ WeChat +86-13705041170

**FUZHOU PRIME POWER CO.,LTD**

[Sales@primepowergenset.com](mailto:Sales@primepowergenset.com)

[w: http://www.gensetengine.com](http://www.gensetengine.com)

**Cummins ISB and QSB Engine Overhaul Parts**

No.	Cummins ISB and QSB Overhaul Kits	Part No.
1	IN-FRAME OVERHAUL KIT – B6.7 / ISB6.7 / QSB (STANDARD)	4955365
2	IN-FRAME OVERHAUL KIT – B5.9 / B6.7 / ISB6.7 / QSB	4089669
3	COMPLETE ENGINE OVERHAUL KIT – ISB 6.7L (STANDARD)	4955365
4	COMPLETE ENGINE OVERHAUL KIT – QSB6.7 (HPCR, EGR)	4956007
5	COMPLETE ENGINE OVERHAUL KIT – ISB	4089670
6	COMPLETE ENGINE OVERHAUL KIT – ISB 6.7L (STANDARD)	4089669
7	COMPLETE ENGINE OVERHAUL KIT – ISB	4089950
8	COMPLETE ENGINE OVERHAUL KIT – ISB 6.7L (STANDARD)	4089260
9	COMPLETE ENGINE OVERHAUL KIT – ISB	4089671
10	COMPLETE ENGINE OVERHAUL KIT – ISB	3800784
11	COMPLETE ENGINE OVERHAUL KIT – ISB	3800785
12	COMPLETE ENGINE OVERHAUL KIT – ISB6.7 / QSB 6.7L	4955160
13	COMPLETE ENGINE OVERHAUL KIT – QSB 4.5L (STANDARD)	4955160-4B
14	COMPLETE ENGINE OVERHAUL KIT – QSB3.9	38062714B
15	IN-FRAME OVERHAUL KIT – ISB6.7 / QSB 6.7L (STANDARD)	4955160
	<b>Cummins ISB and QSB Upper Engine Gasket Sets</b>	
16	UPPER GASKET SET – ISB 5.9 (HPCR W/ FGT – EGR) (2002-2006)	4089819
17	UPPER ENGINE GASKET SET – ISB / QSB / B SERIES	4089649
18	UPPER ENGINE GASKET SET – ISB 5.9 / QSB 5.9 (1998-2002)	4090035
19	UPPER ENGINE GASKET SET – B SERIES / ISB / QSB	4955229
20	UPPER ENGINE GASKET SET	4955354
21	UPPER ENGINE GASKET SET – QSB4.5 / B4.5-99C / B4.5 / B3.9-M250 / QSB-110C	4089648
22	UPPER ENGINE GASKET SET – ISB 4.5 / QSB 4.5	4955356
23	UPPER ENGINE GASKET SET – B SERIES / ISB / QSB	4955229
24	UPPER ENGINE GASKET SET – ISB 6.7	4955523
25	UPPER ENGINE GASKET SET – ISB (2002-2006)	4089263
26	UPPER ENGINE GASKET SET – ISB 5.9 / QSB 5.9 (1998-2002)	4090037
27	UPPER ENGINE GASKET SET – B SERIES / ISB / QSB	4089781
28	UPPER ENGINE GASKET SET – QSB	4089957
29	UPPER ENGINE GASKET SET – B SERIES / ISB / QSB	4089780

	Cummins ISB and QSB Lower Engine Gasket Sets	
30	OIL PAN GASKET – 6B5.9 / ISB6.7	4337596
31	LOWER ENGINE GASKET SET – 6B 5.9 / G5.9 / QSB 5.9	3802376
32	LOWER ENGINE GASKET SET – QSB3.9-30 / QSB4.5-30	3802375
33	OIL PAN GASKET	3959052
34	LOWER ENGINE GASKET SET – ISB 6.7	4089173
35	OIL PAN GASKET – B SERIES	3958165
36	LOWER ENGINE GASKET SET – B SERIES / ISB / QSB	4955230
37	LOWER ENGINE GASKET SET – ISB (HPCR CM2150 FGT)	4955355
38	LOWER ENGINE GASKET SET – B SERIES / ISB / QSB	4955357
39	LOWER ENGINE GASKET SET – ISB 5.9 (HPCR WITH RGT, EGR)	4089264
40	LOWER ENGINE GASKET SET – QSB 5.9 (4 VALVE VP44)	3800833
41	OIL PAN GASKET	3938161
42	OIL PAN GASKET – ISB / ISC / QSC	3973509
43	LOWER ENGINE GASKET SET – ISBE 5.9 / QSB 5.9	4025139
44	LOWER ENGINE GASKET SET – QSB 5.9-M (HPCR 425HO FGT)	4089956
45	LOWER ENGINE GASKET SET – ISB / QSB / 4B / B5.9	4025108
46	LOWER ENGINE GASKET SET – ISB 6.7L	4955522
47	OIL PAN GASKET – 4B3.9 / 6B5.9 / ISB / ISD	3959797
48	OIL PAN GASKET – 4B3.9 / 6B5.9 / ISB / ISD	4943167
	Cummins ISB and QSB Turbochargers	
49	REMANUFACTURED TURBOCHARGER ACTUATOR KIT	4034309RX
50	REMANUFACTURED TURBOCHARGER (HX55)	3802948
51	TURBOCHARGER	3802778
52	TURBOCHARGER KIT – 6BT5.9 / ISB3.9 / ISB4.5 / QSB3.9 / QSB4.5	3802770
53	REMANUFACTURED TURBOCHARGER – ISB / QSB (HX35 WASTERGATE)	4955479
54	REMANUFACTURED TURBOCHARGER (HX35, NON WASTEGATE)	3800788
55	TURBOCHARGER – 4BT / 6BTA / ISB / 6CTA 8.3L (H1C)	3802290
56	TURBOCHARGER – B SERIES / ISB / QSB (H1)	3802289
57	REMANUFACTURED TURBOCHARGER – 4BT / 6BTA / ISB	3802290
58	REMANUFACTURED TURBOCHARGER – ISB (HE351CW)	4089797
59	REMANUFACTURED TURBOCHARGER – B SERIES / ISB / QSB	4089467
60	REMANUFACTURED TURBOCHARGER – B SERIES / ISB / QSB	3802289
61	TURBOCHARGER GASKET – 4BT3.9 / 6BT5.9 / ISB3.9 / ISB4.5 / QSB3.9	3921926
62	TURBOCHARGER – B SERIES / ISB / QSB (HX55W)	4955232
63	TURBOCHARGER – B SERIES / ISB / QSB (HX40)	4089816
64	TURBOCHARGER – ISB / QSB (HE 07 VG MR)	4089946

65	TURBOCHARGER KIT – 4B3.9 / B4.5 / B5.9 / B6.7 (HX35)	3802915
66	REMANUFACTURED TURBOCHARGER (HX35W ISB)	3802946
67	REMANUFACTURED TURBOCHARGER (HX35W ISB)	3802880
68	REMANUFACTURED TURBOCHARGER (HX35W)	3802778
69	REMANUFACTURED TURBOCHARGER – B SERIES / ISB / QSB (H1C)	3802594
70	REMAN TURBO, KIT HX30W	3800709
71	REMANUFACTURED TURBOCHARGER (HY35W)	4089642
72	REMANUFACTURED TURBOCHARGER (HY35W)	4089392
73	REMANUFACTURED TURBOCHARGER (HX35W)	3802878
74	REMANUFACTURED TURBOCHARGER (HX35W)	3802882
75	REMANUFACTURED TURBOCHARGER – ISB / QSB (HE351Ve)	4955401
76	TURBOCHARGER – B SERIES / ISB / QSB (HX55W)	4955626
77	TURBOCHARGER	3802946
78	TURBOCHARGER – 5.9	4089392
79	REMANUFACTURED TURBOCHARGER (HY35V)	3599957
80	TURBOCHARGER – ISB (HE351CW)	4089797
81	TURBOCHARGER – B SERIES / ISB	3599957
82	REMANUFACTURED TURBOCHARGER	3802291
83	REMANUFACTURED TURBOCHARGER – ISB / QSB / B SERIES	3802591
84	TURBOCHARGER – ISB / QSB / B SERIES (H1C)	3802591
	Cummins ISB and QSB Cylinder Heads	
85	CYLINDER HEAD – 6BT / ISB (24 VALVE ENCORE)	5361587
86	REMANUFACTURED CYLINDER HEAD – 6BT / ISB (24 VALVE ENCORE)	3991773
87	CYLINDER HEAD – 6BT / ISB	3969071
88	CYLINDER HEAD – 6BT / ISB	3957408
89	BARE CYLINDER HEAD – ISB / QSB	3977225
90	CYLINDER HEAD – ISB / QSB (6 CYLINDER)	4936081
91	CYLINDER HEAD – 6BT / ISB	4981626
92	CYLINDER HEAD – 6BT / ISB	3957958
93	CYLINDER HEAD – 6BT / ISB (24 VALVE ENCORE)	3991773
94	CYLINDER HEAD ASSEMBLY – ISB / QSB (6 CYLINDER)	3967457
	Cummins ISB and QSB Cylinder Head Gaskets	
95	CYLINDER HEAD GASKET (.50 MM OVERSIZE)	3283339
96	CYLINDER HEAD GASKET – B SERIES	3977063
97	CYLINDER HEAD GASKET	3978517
98	CYLINDER HEAD GASKET	3958644
99	CYLINDER HEAD GASKET (.25MM OVERSIZED)	3283336

100	CYLINDER HEAD GASKET – 6C8.3 / G8.3 / ISC / ISL	3935585
101	CYLINDER HEAD GASKET	3283335
102	CYLINDER HEAD GASKET – ISB	C6204111840
103	CYLINDER HEAD GASKET – ISB	3283333
104	CYLINDER HEAD GASKET – 4B3.9 / B4.5 / B5.9 / B6.7	2830705
105	CYLINDER HEAD GASKET	4932210
	Cummins ISB and QSB Valve Train Components	
106	VALVE TAPPET – 4BT / 6BT / ISB	3931623
107	INTAKE VALVE KIT	3802924
108	EXHAUST VALVE KIT	3802967
109	VALVE STEM SEAL	3955393
110	EXHAUST VALVE KIT	4089672
111	VALVE STEM SEAL	3955394
112	PUSH ROD – 4B3.9 / 6B5.9 / ISB / ISD	3284377
113	EXHAUST VALVE KIT	4955210
114	REMANUFACTURED VALVE KIT – 4B3.9 / B4.5 / B5.9 / B6.7	4309085RX
	Cummins ISB and QSB Valve Cover Components	
115	VALVE COVER GASKET (INTEGRATED WIRING)	5264950
116	ROCKER COVER GASKET – B SERIES / C SERIES / ISB / QSB	3905449
117	VALVE COVER GASKET – B SERIES / C SERIES / ISB / QSB	3959798
118	VALVE COVER GASKET – B SERIES	3935878
119	VALVE COVER GASKET – B SERIES	4899226
120	VALVE COVER GASKET – B SERIES	4897568
121	VALVE COVER GASKET – B SERIES / C SERIES / ISB / QSB	3939284
	Cummins ISB and QSB Fresh Water Pumps	
122	WATER PUMP KIT – QSB 4.5 L / ISB 6.7 L	2881688
123	WATER PUMP – B 3.3 / QSB 4.5	3800883
124	WATER PUMP – 6.7L	4309429
125	WATER PUMP KIT – B SERIES / ISB	5473172
126	WATER PUMP KIT	5473238
127	WATER PUMP KIT – B / ISB SERIES (W/ MOUNTING GASKET)	3286278
128	WATER PUMP – B 3.3 / QSB 4.5	3800883
129	WATER PUMP KIT – ISB (WITH MOUNTING GASKET)	2881805
130	WATER PUMP – 4B / 6B / ISB / QSB (HEAVY DUTY)	3800984
131	WATER PUMP KIT – B / ISB (WITH CAST IRON IMPELLER)	4955394
132	WATER PUMP – QSB	2881804
133	WATER PUMP KIT – ISB / QSB	4089731

134	WATER PUMP KIT – B3.3 / QSB3.3	4955417
135	FRESH WATER PUMP – QSB 4.5	4891252
	Cummins ISB and QSB Raw Water Pumps	
136	RAW WATER PUMP – B SERIES / ISB / QSB	5268375
137	SEA WATER PUMP – QSB 5.9L / QSB 6.9L	5265998
138	SEA WATER PUMP REPAIR KIT – ISB / QSB (MINOR)	3974456
139	RAW WATER PUMP REPAIR KIT	3908220
140	SEA WATER PUMP REPAIR KIT – ISB / QSB (MAJOR)	5268424
141	RAW WATER PUMP REPAIR KIT	3908220
	Cummins ISB and QSB Thermostats	
142	THERMOSTAT – 4B3.9 / 6B5.9 / ISB / ISD	3974823
143	THERMOSTAT (180°F/82°C )	4973373
144	THERMOSTAT	5292744
145	THERMOSTAT – 4B 3.9 / 6B 5.9 / ISB 6.7 / QSB	3928499
146	THERMOSTAT – 4B 3.9 / 6B 5.9 / ISB 6.7 / QSB	3928499
147	THERMOSTAT – ISB / QSB	5292712
148	THERMOSTAT (83°C / 181°F)	3928639
149	THERMOSTAT – B 3.3 / QSB 3.3	3800884
150	THERMOSTAT – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB / QSB	3946849
151	THERMOSTAT (180° OPENING) – 4B3.9 / 6B5.9 / ISB / ISD	4900260
152	THERMOSTAT – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB / QSB	4930315
153	THERMOSTAT KIT – 4B3.9 / 6B5.9 / ISB / ISD	3967195
154	THERMOSTAT – ISB / C SERIES	5292708
	Cummins ISB and QSB Fuel Injectors	
155	FUEL INJECTOR – B SERIES / ISB / QSB	5254261
156	REMANUFACTURED FUEL INJECTOR – B SERIES / ISB / QSB	5263262
157	FUEL INJECTOR – B SERIES / ISB / QSB (BOSCH)	3802677
158	FUEL INJECTOR – ISB / QSB	3897597
159	FUEL INJECTOR – 4B3.9 / B4.5 / B5.9 / B6.7 / ISB6.7 / QSB	3802818
160	FUEL INJECTOR – 4B3.9 / B4.5 / B5.9 / B6.7 / ISB6.7 / QSB	3802547
161	FUEL INJECTOR – B SERIES / ISB / QSB (BOSCH)	4089270
162	FUEL INJECTOR – ISB	4089267
163	FUEL INJECTOR – B SERIES / ISB / QSB	4089468
164	FUEL INJECTOR – B SERIES / ISB / QSB	5263312
165	REMANUFACTURED FUEL INJECTOR – 4B3.9 / B4.5 / B5.9	3948529RX
166	REMANUFACTURED FUEL INJECTOR – 4B3.9 / B4.5 / B5.9	3939826RX
167	REMANUFACTURED FUEL INJECTOR – 4B3.9 / B4.5 / B5.9	4089727NX

168	REMANUFACTURED FUEL INJECTOR – 4B3.9 / B4.5 / B5.9	3802334RX
169	REMANUFACTURED FUEL INJECTOR – 4B3.9 / B4.5 / B5.9	3802333RX
170	REMANUFACTURED FUEL INJECTOR – 4B3.9 / B4.5 / B5.9	3802546RX
	Cummins ISB and QSB Lift Pumps	
171	FUEL TRANSFER PUMP – 4B3.9 / 6B5.9 / B4.5 / ISB6.7	5362273
172	FUEL TRANSFER PUMP – B SERIES / ISB / QSB / 6CTA	4983585
173	FUEL TRANSFER PUMP – B SERIES / ISB / QSB	4988751
174	FUEL TRANSFER PUMP – ISB (MECHANICAL)	4988748
175	FUEL TRANSFER PUMP – 4B 3.9 / B4.5 / 6B 5.9 / ISB 6.7	4983584
176	FUEL TRANSFER PUMP	3936320
177	FUEL TRANSFER PUMP – ISB	4935005
178	FUEL TRANSFER PUMP – ISB / ISC / QSC / 6CTA	4988747
179	FUEL TRANSFER PUMP ASSEMBLY (12V, DODGE TRUCKS)	3990105
180	FUEL TRANSFER PUMP – 6CTA / ISB / ISC / QSB	4988749
181	LIFT PUMP – 4B 3.9 / B 4.5 / 6B 5.9 / ISB 6.7 (12V)	5260632
182	FUEL TRANSFER PUMP – B SERIES / ISB	4944714
183	FUEL TRANSFER PUMP – B SERIES / ISB	3918076
184	FUEL TRANSFER PUMP – B SERIES / ISB / QSB / 6CTA	4983585
185	FUEL TRANSFER PUMP – ISB	4935005
186	FUEL TRANSFER PUMP – 6CTA / ISB / ISC / QSB	4988749
187	FUEL TRANSFER PUMP – 4B 3.9 / 6B 5.9 / ISB 6.7	4937767
188	FUEL TRANSFER PUMP – ISB (12V)	4943048
189	FUEL TRANSFER PUMP	4944711
190	FUEL PUMP GASKET – 4BT3.9 / 6BT5.9 / ISB3.9 / ISB4.5 / QSB3.9	3914389
191	ELECTRIC FUEL PUMP KIT (WITH HOSE, DODGE 2003-2004)	4089602
192	FUEL INJECTION PUMP – B SERIES / ISB / QSB (ZEXEL A)	4063844
193	FUEL INJECTION PUMP – B SERIES / ISB / QSB (STANADYNE)	3918159
194	FUEL INJECTION PUMP – B SERIES / ISB / QSB (BOSCH)	3963959
195	FUEL TRANSFER PUMP – 4B3.9 / B 4.5 / 6B 5.9 / ISB 6.7	4983584
196	FUEL INJECTION PUMP – 4B3.9 / 6B5.9 / B4.5 / ISB6.7	3957710
197	FUEL TRANSFER PUMP – B SERIES / C SERIES / ISB / QSB (24V)	5260634
198	FUEL TRANSFER PUMP – ISB / B SERIES / C SERIES	4943049
199	FUEL TRANSFER PUMP – ISB / ISC / QSC / 6CTA	4988747
200	REMANUFACTURED FUEL INJECTION PUMP – B SERIES / ISB / QSB	3965404RX
201	REMANUFACTURED FUEL PUMP (VP30, 24 V)	3965403RX
202	LIFT PUMP – 4B 3.9 / B 4.5 / 6B 5.9 / ISB 6.7	5260632
	Cummins ISB and QSB Fuel Lines	

203	FUEL SUPPLY TUBE – 4B 3.9 / B 4.5 / 6B 5.9 / ISB 6.7	3914753
204	FUEL SUPPLY TUBE – 4B 3.9 / B 4.5 / 6B 5.9 / ISB 6.7	3918641
205	FUEL SUPPLY TUBE – 4B 3.9 / B 4.5 / 6B 5.9 / ISB 6.7	3918880
206	FUEL MANIFOLD – 4BT3.9 / 6BT5.9 / ISB3.9 / ISB4.5 / QSB3.9	3927633
207	FUEL MANIFOLD – 4BT3.9 / 6BT5.9 / ISB3.9 / ISB6.7 / QSB3.9 / QSB4.5	3966864
208	FUEL SUPPLY TUBE BRACE – ISB / ISC / QSC	3930688
209	FUEL MANIFOLD – ISB / QSB	3909696
	Fleetguard Fuel Filters for Cummins ISB and QSB Engines	
210	FUEL FILTER (USER FRIENDLY VERSION)	FF42000
211	FUEL/WATER SEPARATOR FILTER (SPIN-ON)	FS1251
212	FUEL FILTER	FF5580
213	FUEL/WATER SEPARATOR FILTER (SPIN-ON)	FS1000
214	FUEL/WATER SEPARATOR FILTER (SPIN-ON)	FS1022
215	FUEL FILTER (SPIN-ON)	FF105D
216	FUEL FILTER	FF5421
217	FUEL FILTER (SPIN-ON)	FF202
218	FUEL FILTER – ISB / KTA19 / QSK19 (SPIN-ON)	FF105
219	FUEL FILTER CARTRIDGE	FF5369W
220	FUEL FILTER CARTRIDGE	FF108
221	FUEL/WATER SEPARATOR (SPIN-ON)	FS19519
222	FUEL/WATER SEPARATOR FILTER	FS19616
223	FUEL/WATER SEPARATOR FILTER (SPIN-ON)	FS1282
224	FUEL/WATER SEPARATOR FILTER	FS19598
225	FUEL/WATER SEPARATOR FILTER	FS19608
	Cummins ISB and QSB Camshafts	
226	REMANUFACTURED CAMSHAFT – ISB 6.7 / QSB	3947007
227	CAMSHAFT	3929885
228	CAMSHAFT GEAR – 4B3.9 / 6B5.9 / B4.5 / B5.9 / B6.7	3929028
229	CAMSHAFT BEARING – QSB4 / G5.9-C / QSB4.5 / 4B3.9 / B5.9- M330 / QSR6 7 / ISB240	3940059
230	CAMSHAFT BEARING – NH/NT855 / NT / NTA 855 / 6B5.9	3945329
231	CAMSHAFT – B SERIES / ISX / QSX / ISB / QSB	3683658
232	CAMSHAFT – 6BTA / ISB 6.7L	3930378
233	CAMSHAFT – ISB	4930770
234	CAMSHAFT GEAR	3918777
235	CAMSHAFT – QSB	3942567
236	CAMSHAFT – 4B3.9 / 6B5.9 / 6CTA 8.3L / ISB5.9 / ISB6.7	3979506
	Cummins ISB and QSB Piston Kits	

237	PISTON KIT (STANDARD)	3802747
238	PISTON KIT (WITH RING SET AND PIN RETAINERS)	4089260
239	PISTON KIT – ISB (.50 MM, WITH RING SET)	4955481
240	PISTON KIT WITH RING SET AND PIN RETAINERS – ISB	3800781
241	PISTON KIT (1.00 MM OVERSIZE)	3802765
242	PISTON KIT – B SERIES (WITH PIN RETAINERS)	4089183
243	PISTON KIT (WITH RING SET AND PIN RETAINERS)	3800838
244	PISTON (WITH RETAINER AND RINGS)	4089671
245	PISTON KIT (STANDARD, WITH RING SET AND PIN RETAINERS)	4025072
246	PISTON KIT – ISB / QSB	3800756
247	PISTON KIT – ISB / QSB (.50 MM OVERSIZE)	3802764
248	PISTON KIT – ISB / QSB	4089462
249	PISTON KIT – ISB / QSB	4089620
250	PISTON KIT (WITH RING SET AND PIN RETAINERS)	3800840
251	PISTON KIT (WITH RING SET AND PIN RETAINERS, GRADE B)	3800782
252	PISTON KIT (1.00 MM, WITH RING SET AND PIN RETAINERS)	3800785
253	PISTON KIT (WITH RING SET AND PIN RETAINERS, GRADE C)	3800783
254	PISTON KIT (0.50 MM, WITH RING SET AND PIN RETAINERS)	3800784
255	PISTON KIT (WITH RING SET AND PIN RETAINERS)	3800841
256	PISTON KIT (WITH RING SET AND PIN RETAINERS)	3800839
257	PISTON KIT (WITH RING SET AND PIN RETAINERS)	3800842
258	PISTON KIT (WITH RING SET AND PIN RETAINERS)	4025011
259	PISTON KIT – B SERIES (1.0 MM, WITH RING SET)	4089184
260	PISTON KIT – B SERIES (.50 MM, WITH RING SET)	4089185
261	PISTON KIT – 4B3.9 / B6.7 / QSB4.5 / QSB5.9 / B5.9	4956007
262	PISTON KIT – ISB (1.00 MM, WITH RING SET)	3800327
263	PISTON KIT – ISB (.50 MM, WITH RING SET)	4089618
264	PISTON KIT – ISB (1.00 MM, WITH RING SET)	4089619
265	PISTON KIT – ISB (STANDARD, WITH RING SET)	4089461
266	PISTON KIT W/ RETAINERS IN RINGS – ISB / QSB	3802927
267	PISTON KIT – ISB / QSB	4955160
268	PISTON KIT – QSB (4.51L)	PK9950
	Cummins ISB and QSB Piston Ring Sets	
269	SINGLE CYLINDER PISTON RING SET	4089258
270	PISTON RING SET (STANDARD)	4089460
271	SINGLE CYLINDER PISTON RING SET (0.50 MM)	4089181
272	PISTON RING SET – 4B3.9 / B4.5 / B5.9 (.50 MM O/S)	3806229



273	SINGLE CYLINDER PISTON RING SET (1.00 MM)	3806203
274	SINGLE CYLINDER PISTON RING SET (1.00 MM)	4089182
275	PISTON RING SET – 6B5.9 / ISB6.7 / NT855 / QSB5.9	3801755
276	PISTON RING SET (STANDARD) – 4B3.9 / 6B5.9 / ISB / ISD	3804930
277	PISTON RING SET (1.00MM OVERSIZE) – 4B3.9 / 6B5.9	3806242
278	PISTON RING SET (.050 OVERSIZE) – 4B3.9 / 6B5.9 / ISB	4089974
	Cummins ISB and QSB Connecting Rods	
279	CONNECTING ROD – 4B / 6B / ISB / QSB	4943979
280	CONNECTING ROD – 4B3.9 / 6B5.9 / ISB6.7 / QSB3.9 / QSB5.9	3939407
281	REMANUFACTURED CONNECTING ROD – 4B / 6B / ISB / QSB	3925232
282	CONNECTING ROD – 6C8.3 / QSC8.3 / 4B3.9 / 6B5.9	3971394
	Cummins ISB and QSB Connecting Rod Bearings	
283	CONNECTING ROD BEARING – B SERIES / ISB / QSB	4993831
284	CONNECTING ROD BEARING – ISB (STANDARD, UPPER HALF)	3969562
285	CONNECTING ROD BEARING – ISB-305 / ISB325 / ISB6.7 / ISB-250 / 4B3.9 / QSB6.7	4893693
286	CONNECTING ROD BEARING (STANDARD)	4893693
287	CONNECTING ROD BEARING HALF (LOWER)	4892796
288	CONNECTING ROD BEARING HALF (UPPER)	4932376
289	ROD BEARING HALF – B SERIES / ISB (UPPER)	3939390
290	ROD BEARING HALF – B SERIES / ISB (LOWER)	3939380
291	CONNECTING ROD BEARING PAIR	3967060
292	CONNECTING ROD BEARING PAIR	3967061
293	CONNECTING ROD BEARING PAIR	3967062
294	CONNECTING ROD BEARING PAIR	3967063
295	CONNECTING ROD BEARING PAIR	3967064
296	CONNECTING ROD BUSHING – NH220 / NH250 / NTA855	3939371
297	CONNECTING ROD BEARING – ISB (STANDARD)	4993834
298	CONNECTING ROD BEARING – B3.3 / QSB3.3 (.50 MM O/S)	C6207383300
299	CONNECTING ROD BEARING HALF (UPPER, .25 MM O/S)	3939391
300	CONNECTING ROD BEARING HALF (LOWER, .25 MM O/S)	3939381
	Cummins ISB and QSB Crankshafts	
301	CRANKSHAFT – ISBE	4980462
302	CRANKSHAFT – ISB / QSB	3939367
303	CRANKSHAFT ASSEMBLY – ISB / QSB	4934862
304	CRANKSHAFT – ISB	3944243
305	CRANKSHAFT – ISB / QSB (INDUSTRIAL 6.7 L)	2830476
	Cummins ISB and QSB Crankshaft Bearings and Seals	

306	CRANKSHAFT OIL SEAL – ISB / QSB	5338295
307	THRUST WASHER SET – QSB (STANDARD   FPD)	4982149S
308	MAIN BEARING) – B SERIES / ISB / QSB (1.00 MM, FDP)	4955867
309	MAIN BEARING SET – B SERIES / ISB / QSB (STANDARD, FPD)	3800872
310	MAIN BEARING – B SERIES / ISB / QSB (FLANGED)	4955866
311	MAIN BEARING – B SERIES / ISB / QSB (FLANGED)	4955865
312	MAIN BEARING – B SERIES / ISB / QSB (FLANGED)	4955864
313	FRONT CRANKSHAFT SEAL KIT (WITH INSTALLATION TOOL)	3937111
314	FRONT CRANKSHAFT SEAL & WEAR SLEEVE KIT – B SERIES	3802820
315	REAR CRANKSHAFT SEAL SERVICE KIT – 6CTA / ISB / QSB	4089342
316	MAIN BEARING SET – 4B (STANDARD)	3802010
317	REAR CRANKSHAFT OIL SEAL KIT – B SERIES / C SERIES	3926126
318	MAIN BEARING SET – ISB (STANDARD)	3357480
319	MAIN BEARING SET (STANDARD)	4955352
320	MAIN BEARING SET – 4B (.25 MM OVERSIZE)	3802011
321	MAIN BEARING SET – 4B (.50 MM OVERSIZE)	3802012
322	OIL SEAL KIT	3804899
323	MAIN BEARING SET – B SERIES (.0303 / .75 MM)	3802073
324	MAIN BEARING SET – ISB (.0403 / 1.00 MM)	3802074
325	MAIN BEARING SET – ISB (.0403 / 1.00 MM)	3802014
326	MAIN BEARING SET – ISB (.0303 / .75 MM)	3802013
327	OIL SEAL – B3.3 / QSB3.3 (REAR)	C6140211341
328	OIL SEAL – B3.3 / QSB3.3 (FRONT)	C6204213510
329	REAR CRANKSHAFT SEAL SERVICE KIT – 6CTA / ISB / QSB	3934486
330	OIL RING SEAL – ISB / B SERIES	5259499
331	MAIN BEARING – B3.3 / QSB3.3 (.50 MM O/S)	C6204288100
332	FRONT CRANKSHAFT OIL SEAL – ISB / QSB	4890832
333	FRONT OIL SEAL KIT – 6C8.3 / G8.3 / ISC / ISL	4024883
334	MAIN BEARING SET – ISB / QSB (.010 OVERSIZE)	4955860
	Cummins ISB and QSB Belts	
335	RIBBED V-BELT – ISB	5466980
336	RIBBED V-BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289426
337	RIBBED V-BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3288746
338	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3288464
339	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289268
340	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289336
341	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3288532

342	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3288878
343	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289492
344	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289470
345	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289481
346	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289314
347	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289503
348	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289067
349	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3288678
350	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289303
351	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289347
352	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289358
353	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289246
354	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289369
355	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289224
356	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289124
357	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3288656
358	ENGINE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289626
359	RIBBED V-BELT	3288689
360	V-RIBBED BELT – B SERIES / C SERIES / ISB / QSB (57.53)	3288812
361	RIBBED V-BELT	3288689
362	RIBBED V-BELT – B SERIES / C SERIES / ISB / QSB	3911557
363	RIBBED V-BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3288955
364	RIBBED V-BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289279
365	RIBBED V-BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3288922
366	RIBBED V-BELT – B SERIES / ISB / QSB (56.813)	3288790
367	REPLACED. PLEASE USE PART# DS-3288790	3911568
368	RIBBED V-BELT – B SERIES / ISB / QSB (44.53, 8 RIBS)	3920282
369	RIBBED V-BELT – B SERIES / ISB / QSB (36.63, 8 RIBS)	3283977
370	V-BELT – 4BT / 6BT / ISB 6.7L (RIBBED, 68.193)	3979344
371	V-BELT – 4BT / 6BT / ISB 6.7L (RIBBED)	4946198
372	RIBBED BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3288645
373	RIBBED V-BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3288856
374	WATER PUMP DRIVE BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3288634
375	BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3288889
376	RIBBED V-BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289135
377	RIBBED V-BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3288757
378	RIBBED V-BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289325

379	RIBBED V-BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289213
380	BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289157
381	BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289089
382	RIBBED V-BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289078
383	V-BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289056
384	BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289034
385	RIBBED V-BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3289023
386	RIBBED V-BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3288999
387	BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3288966
388	RIBBED V-BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3288944
389	BELT – 4B3.9 / 6B5.9 / ISB / ISB3.9	3288834
	Cummins ISB and QSB Belt Tensioners	
390	BELT TENSIONER – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB / QSB	5333480
391	BELT TENSIONER – 6BT	5333486
392	BELT TENSIONER – B SERIES / ISB / QSB	3937553
393	BELT TENSIONER – B / ISB / QSB	5333477
394	BELT TENSIONER – 6C / ISB / QSB	3976831
395	BELT TENSIONER – 4BT3.9 / 6BT5.9 / ISB / ISB3.9 / ISB4.5 / QSB3.9	3937556
396	BELT TENSIONER – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB / QSB	3974102
397	BELT TENSIONER – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB / QSB	3976834
398	BELT TENSIONER – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB / QSB	4981116
399	BELT TENSIONER – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB / QSB	5270678
400	BELT TENSIONER – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB / QSB	5259022
401	BELT TENSIONER – B SERIES / ISB / QSB	3947574
402	BELT TENSIONER – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB / QSB	5333480
403	BELT TENSIONER – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB / QSB	5333478
	Cummins ISB and QSB Exhaust Manifolds	
404	EXHAUST MANIFOLD – B SERIES / ISB / QSB	4019951
405	EXHAUST MANIFOLD	3902347
406	EXHAUST MANIFOLD – B SERIES / C SERIES / ISB / QSB	3937477
407	EXHAUST MANIFOLD – B SERIES / C SERIES / ISB / QSB	3901683
408	EXHAUST MANIFOLD	4931223
409	EXHAUST MANIFOLD	3937187
410	EXHAUST MANIFOLD	3901635
411	EXHAUST MANIFOLD	4936968
412	EXHAUST MANIFOLD – ISB	3967751
413	EXHAUST MANIFOLD – 6B / QSB	3943872

414	EXHAUST MANIFOLD – ISB (6 CYLINDERS)	3931744
415	EXHAUST MANIFOLD – 6B / QSB (LONG SECTION/HI SILICON MOLY)	3943875
416	EXHAUST MANIFOLD – ISB	3937478
417	EXHAUST MANIFOLD – 4B3.9 / B4.5 / B5.9 / B6.7	3917700
418	EXHAUST MANIFOLD – 4B3.9 / B4.5 / B5.9 / B6.7	2888030
	Cummins ISB and QSB Exhaust Manifold Gaskets	
419	EXHAUST MANIFOLD GASKET – B SERIES / ISB / QSB	3905443
420	EXHAUST MANIFOLD GASKET – 4B 3.9 / B 4.5 / 6B 5.9	3921926
421	EXHAUST MANIFOLD GASKET	5269779
422	EXHAUST MANIFOLD GASKET	3946275
423	EXHAUST MANIFOLD GASKET	3929881
424	EXHAUST MANIFOLD GASKET – 6C8.3 / G8.3 / ISC / ISL	5266422
	Cummins ISB and QSB Oil Pumps	
425	LUBRICATING OIL PUMP – ISC8.3 / QSC8.3	5291050
426	OIL PUMP – ISB / QSB	3930337
427	OIL PUMP – B SERIES / ISB / QSB	4939585
428	OIL PUMP – B SERIES / ISB / QSB	4939587
429	OIL PUMP – B SERIES / ISB / QSB	4939588
430	OIL PUMP – B SERIES / ISB / QSB	4988801
431	OIL PUMP – 6BTA   ISB SERIES	4939586
432	OIL PUMP – B SERIES / ISB / QSB	3971544
433	OIL PUMP – 4B / 6B / ISB	5273937
	Cummins ISB and QSB Oil Coolers	
434	OIL COOLER – 4BT / 6BT / ISB 6.7L / 6CTA 8.3L (15 PLATE)	3966365
435	OIL COOLER (ONAN)	0102-1530
436	OIL COOLER CORE (7 PLATE)	3957544
437	OIL COOLER CORE – 6B / ISB (5 PLATE)	3957543
438	OIL COOLER CORE – ISBE	3959031
439	OIL COOLER CORE – ISB (6.7L)	3975818
440	OIL COOLER CORE – 4B3.9 / 6B5.9 / B4.5 / B6.7	3921557
441	MARINE GEAR OIL COOLER	3912146
	Cummins ISB and QSB Piston Cooling Nozzles	
442	PISTON COOLING NOZZLE	3013591
443	PISTON COOLING NOZZLE – B SERIES / ISB / QSB	3937214
444	PISTON COOLING NOZZLE – B SERIES / ISB / QSB	4937308
	Fleetguard Oil Filters for Cummins ISB and QSB Engines	
445	OIL FILTER (COMBINATION)	LF9009

446	OIL FILTER (FULL FLOW, SPIN-ON)	LF670
447	OIL FILTER (FULL FLOW, SPIN-ON)	LF3959
448	OIL FILTER (FULL FLOW, SPIN-ON)	LF3349
449	OIL FILTER	LF16011
450	OIL FILTER (FULL FLOW, SPIN-ON)	LF3972
451	OIL FILTER	LF3806
452	OIL FILTER	LF16015
453	OIL FILTER (FULL FLOW, SPIN-ON)	LF734
	Cummins ISB and QSB Electrical Accessories	
454	FUEL PUMP SOLENOID – 4B3.9 / B4.5 / 6B5.9 / B6.7	3991168
455	FUEL PUMP SOLENOID – 4B3.9 / B4.5 / 6B5.9 / B6.7	5267132
456	FUEL SHUTOFF SOLENOID – 4B 3.9 / B 4.5 / 6B 5.9 / ISB 6.7	3932529
457	FUEL PUMP SOLENOID KIT (12V)	3903575
458	FUEL SHUTOFF SOLENOID – ISB / QSB (12 VDC)	3991624
459	SHUTOFF SOLENOID	3935650
460	FUEL SHUTOFF SOLENOID KIT	4024809
461	SOLENOID KIT – B3.3 / QSB3.3	3903575
462	SOLENOID – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB / QSB (12 V)	3904630
463	WIRING HARNESS – ISB	3287699
464	WIRING HARNESS – 4B3.9 / B4.5 / B5.9 / B6.7 / ISB6.7	3966805
465	WIRING HARNESS – 4B3.9 / B4.5 / B5.9 / B6.7 / ISB6.7 / QSB	3965108
466	WIRING HARNESS – 4B3.9 / B4.5 / B5.9 / B6.7 / ISB6.7 / QSB	3965224
467	WIRING HARNESS – 4B3.9 / B4.5 / B5.9 / B6.7 / ISB6.7	3972349
468	ELECTRICAL WIRING HARNESS – ISB / ISX / ISM	3164653
469	VOLTMETER – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB / QSB	5273468
470	WIRING HARNESS – 4B3.9 / B4.5 / B5.9 / B6.7 / ISB6.7	4993480
471	FUEL PUMP SOLENOID – 4B / 6B / ISB / ISC	3991167
	Cummins ISB and QSB Senders and Switches	
472	COOLANT LEVEL SWITCH – 4B3.9 / B4.5 / 6B5.9 / B6.7	4359193
473	GEAR OIL PRESSURE SENSOR	4306990
474	TEMPERATURE SENSOR – 6C8.3 / G8.3 / ISC / ISL	2872858
475	PRESSURE SENSOR – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB / QSB	5297641
476	INTAKE MANIFOLD PRESSURE SENSOR	4928593
477	REMANUFACTURED NITROGEN OXIDE SENSOR – 4B3.9 / B4.5	4326872RX
478	NITROGEN OXIDE SENSOR	4326766
479	DIFFERENTIAL PRESSURE SENSOR – 6C8.3 / G8.3 / ISC / ISL	4384138
480	ACTUATOR (ETR FUEL CONTROL)	4903523

481	OIL PRESSURE SENSOR	4921487
482	TEMPERATURE SENSOR – B SERIES / C SERIES / ISB / QSB	4897224
483	PRESSURE SENSOR – B SERIES / C SERIES / ISB / QSB	4921517
484	TEMPERATURE SENSOR – C SERIES	4088832
485	TEMPERATURE SENSOR – B SERIES / C SERIES / ISB / QSB	3408345
486	PRESSURE SENSOR	4921505
487	PRESSURE SENSOR (AMBIENT AIR)	4902720
488	POSITION SENSOR (CAMSHAFT OR CRANKSHAFT)	4984223
489	PRESSURE SENSOR – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB / QSB	4928594
490	WATER TEMPERATURE SENDER – 4B3.9 / B4.5 / 6B5.9	3914081
491	TEMPERATURE SWITCH – 4B3.9 / B4.5 / 6B5.9 / B6.7	4078749
492	WATER SENSOR – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB / QSB	3970911
493	THROTTLE POSITION SENSOR – 4B3.9 / B4.5 / 6B5.9	3930318
494	TEMPERATURE SENSOR – 4B3.9 / 6B5.9 / B6.7 / ISB / QSB	4984570
495	PRESSURE SENSOR – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB / QSB	4921730
496	PRESSURE SENSOR – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB / QSB	3967251
497	PRESSURE SENSOR – 6C8.3 / ISC8.3 / QSC8.3 / QSL9 / ISL9	3949988
498	OIL PRESSURE SWITCH – 4B3.9 / 6B5.9 / ISB / ISD	4984792
499	OIL PRESSURE SWITCH – 6C8.3 / G8.3 / ISC / ISL	3968300
500	PRESSURE SENSOR – 4B3.9 / B4.5 / 6B5.9 / B6.7 / ISB	4995187
501	PRESSURE SENSOR	2872254
502	CRANKSHAFT POSITION SENSOR – ISB / C SERIES / B SERIES	2872279
503	CAMSHAFT POSITION SENSOR – ISB / QSB / ISX / QSX	2872277
504	POSITION SENSOR – B SERIES / C SERIES / ISB / QSB	4890189
505	POSITION SENSOR – B SERIES / C SERIES / ISB / QSB	4890190
506	POSITION SENSOR – ISB / QSB (CRANKSHAFT)	4921601
507	PRESSURE SENSOR – B SERIES / C SERIES / ISB / QSB	4921497
508	MAGNETIC SWITCH – 4B 3.9 / B 4.5 / 6B 5.9 / ISB 6.7	5265270
	Cummins ISB and QSB Parts Catalogs	
509	PARTS CATALOG – QSB 4.5-30	4056527
510	PARTS CATALOG – QSB 5.9 (INDUSTRIAL)	4056478
511	PARTS CATALOG – ISBE 5.9	4056497
512	PARTS CATALOG – ISB 5.9 (WITH CM850 CONTROL MODULE)	4056509
513	PARTS CATALOG – ISB 3.9 / 4BT	4056494
514	AUTOMOTIVE PARTS CATALOG – ISB	3672122
	Cummins ISB and QSB Service Manuals	
515	SERVICE MANUAL – ISB / QSB	4021456

516	SERVICE MANUAL – ISB	4021578
517	WIRING DIAGRAM – QSB / QSC / QSL / 6CTA	4021524
518	WIRING DIAGRAM – QSB 5.9 (MARINE, WITH CM850 ECM)	4081886
519	TROUBLESHOOTING MANUAL – QSB	4021398
520	OPERATOR MANUAL – ISB (INDUSTRIAL)	4021388
521	OPERATOR MANUAL – ISB 3.9 / ISB 5.9	3666170
522	SERVICE MANUAL – ISB / QSB 5.9	3666193
523	WIRING DIAGRAM – ISB	3666195
524	WIRING DIAGRAM – QSB (INDUSTRIAL)	3666396
525	WIRING DIAGRAM – ISB ENGINES (23 PIN)	3666325
526	WIRING DIAGRAM – ISBE4 (WITH CM850 CONTROL MODULE)	4021532
527	SERVICE MANUAL – ISB / QSB 3.9 / QSB 5.9 (COMMON RAIL)	4021271
528	OPERATOR MANUAL – ISB 5.9 / QSB 5.9 (COMMON RAIL)	3666496
529	SERVICE MANUAL – ISB 6.7L	4022254
530	TROUBLESHOOTING AND REPAIR MANUAL – ISB / QSB / ISC	4021553
	Parts for Cummins ISB and QSB Engines	
531	ALTERNATOR – ISB	5316342
532	SEALING WASHER – 4BT3.9 / 6BT5.9 / ISB3.9 / ISB4.5 / QSB3.9 / QSB4.5	3918188
533	TURBO MOUNTING STUD – ISC350 / C8.3-C215 / B5.9 / 6C8.3 / ISB-RV275 / ISC300 / C8.3-P	3818823
534	SALVAGE SLEEVE – B3.9-V110 / QSB5.9480H0 / B5.9-M330 / 6B5.9 / B5.9-C / 4R3.9	3904166
535	RECTANGULAR RING SEAL – 4BT3.9 / 6BT5.9 / ISB3.9 / ISB4.5 / QSB3.9	3906697
536	RECTANGULAR RING SEAL – 4BT3.9 / 6BT5.9 / ISB3.9 / ISB4.5 / QSB3.9	3906698
537	RECTANGULAR RING SEAL – ISB3.9 / ISB4.5 / ISB5.9G / QSB3.9 / QSB4.5	3903475
538	FLYWHEEL RING GEAR – 4R3.9 / 6B5.9 / ISB6.7 / QSB5.9 / 6C8.3 / QSC8.3 (138 TEETH)	3908546
539	FLYWHEEL RING GEAR – 4B 3.9 / B 4.5 / 6B 5.9 / ISB 6.7	3901774
540	FAN PULLEY – ISB / QSB	3914463
541	FAN PULLEY – ISB / QSB / ISC / QSC	3914462
542	BUSHING – QSB4 / 6B5.9 / B5.9-M330 / QSB6.7 / QSB4.5 / B5.9-C / B3.9-C76	4891178
543	PISTON BODY – 4B3.9 / B4.5 / B5.9 / B6.7 / ISB6.7 / QSB5.9	3908815
544	TURBO MOUNTING STUD NUT – ISB240 / 6B5.9 / ISB / ISC350	3818824
545	HEXAGON NUT – C8.3-C215 / B5.9-M210 / ISB-RV275 / ISC350 / C8.3-P / QSB6.7	3818824
546	NOISE ISOLATOR – 4BT3.9 / 6BT5.9 / ISB3.9 / ISB4.5 / QSB3.9 / QSB4.5	3935449
547	FRONT GEAR HOUSING – ISB / QSC / KTA38 / QSK38	3936256
548	FLYWHEEL RING GEAR – 4B 3.9 / B 4.5 / 6B 5.9 / ISB 6.7	3901774
549	PUSH ROD COVER GASKET – 4B3.9 / B4.5 / QSB4.5 / B3.9-C130	3283767
550	OIL FILTER HEAD GASKET – QSB5.9 / B3.9 / BT5.9GEN.DR6 / 6B5.9 / 4B3.9	3942915
551	GEAR COVER GASKET – QSB-110C / B3.9-C80 / 4B3.9 / B5.9 / 6B5.9 / 4BT3.9	3914385



552	FRONT GEAR COVER GASKET	3917780
553	VIBRATION DAMPER – 4BT / 6BT / ISB 6.7L (8.233 DIAMETER BURRED 4 HOLES)	3914454
554	UNLOADER VALVE CAP – ISB / ISC / QSC	184240
555	FAN SUPPORT BALL BEARING	3910739
556	SEALING WASHER – 4BT3.9 / 6BT5.9 / ISB3.9 / ISB4.5 / QSB3.9 / QSB4.5	3963988
557	EXHAUST OUTLET TUBE – 4BT3.9 / 6BT5.9 / ISB3.9 / QSB3.9 / QSB4.5	3910993
558	FUEL SYSTEM LEAK TESTER – ISB	3164618
559	FUEL PUMP TESTER – ISB	3164621
560	ALTERNATOR SUPPORT – 4B3.10 / 6B5.10 / ISB3.9 / ISB4.5 / QSB3.9 / QSB4.5	3930820
561	MOUNTING SPACER – ISC350 / ISL400 / ISLG320 / QSB6.7 / ISC330 / ISB / B5.9- A200	3945252
562	SPEED INDICATOR RING – 4B3.9 / 6B5.9 / ISB6.7 / QSB5.9	3942441
563	SPEED INDICATOR RING – 4B3.9 / 6B5.9 / 6C8.3 / ISC8.3 / QSC8.3 / QSB5.9	3972345
564	IDLER PULLEY – ISB / QSB	3978324
565	IDLER PULLEY – ISB / QSB / ISC / QSC	4991240
566	FAN PULLEY – B Series / ISB / QSB / 6CTA / ISC / QSC	3914458
567	FAN PULLEY – ISB / QSB	3914460
568	CRANKSHAFT PULLEY – ISB / QSB / ISC / QSC	3914494
569	ZINC ELECTRODE PLUG – ISM / QSM / ISB / QSB / ISB	3957921
570	PISTON PIN – NH220 / NH250 / NT855 / ISB / QSB / ISB	3939374
571	OIL PAN – 4B3.9 / 6B5.9 / B4.5 / B6.7 / ISB6.7 / QSB4.5 (STAMPED STEEL)	3907570
572	STARTER – 4B3.9 / B4.5 / B6.7 / ISB6.7 / QSB4.5 / QSB5.9 (12 V)	3964427
573	STATOR REPAIR KIT – 4B3.9 / B4.5 / B5.9 / B6.7 / ISB6.7 / QSB	4089399
574	VACUUM PUMP REPAIR KIT – 4B3.9 / 6B5.9 / ISB / ISD	4089742
575	VIBRATION ISOLATOR – ISB / QSB / ISC / QSC	3968021
576	VIBRATION ISOLATOR – ISB / QSB	3349230
577	VIBRATION ISOLATOR – ISB / QSB / ISC / QSC	3393944
578	RESTRICTION INDICATOR – ISB / NH220 / NH250 / NT855	178957
579	PLAIN HOSE – ISB	63549
580	PLAIN HOSE – ISB / ISC / QSC	3897789
581	PLAIN HOSE	3866540
582	PLAIN HOSE	3286499
583	MOLDED HOSE – ISB / ISC / QSC	3866019
584	MOLDED HOSE – ISB	4020094
585	FLEXIBLE HOSE – ISB	3897700
586	FLEXIBLE HOSE – ISB	3866592
587	FLEXIBLE HOSE – ISB / ISC / QSC	3866565
588	FLEXIBLE HOSE	3866591

589	FLEXIBLE HOSE	3918562
590	FLEXIBLE HOSE – ISB / QSB	3934396
591	FLEXIBLE HOSE – ISB	4019401
592	FLEXIBLE HOSE – ISB	4078924
593	ELBOW HOSE – ISB	3934720
594	ELBOW HOSE – ISB	3912965
595	ELBOW HOSE – ISB	188580
596	ELBOW HOSE – ISB	176743
597	ENGINE HEATER – 4B3.9 / B4.5 / B5.9 / B6.7 / ISB6.7 / QSB	3911836
598	INTAKE AIR HEATER – 4B3.9 / B4.5 / B5.9 / B6.7 / ISB6.7 / QSB	3929108
599	WIRING HARNESS – ISB	3971324
600	WIRING HARNESS – ISB	3971303
601	WIRING HARNESS – ISB	3971321
602	FLYWHEEL RING GEAR – 4B3.9 / 6B5.9 / B4.5 / B5.9 / B6.7 / ISB6.7	3978313
603	TEMPERATURE GAUGE – B SERIES / ISB	3918217
604	PUSH ROD COVER GASKET – ISB	3284623
605	HEAT EXCHANGER GASKET – 4BT3.9 / 6BT / B4.5 / B5.9 / ISB3.9 / ISB4.5 / QSB3.9	3910343
606	EXHAUST OUTLET CONNECTION GASKET – 4BT3.9 / 6BT5.9 / ISB3.9 / QSB3.9	3921961
607	COVER PLATE GASKET – 4BT3.9 / 6BT / ISB3.9 / ISB4.5 / QSB3.9 / QSB4.5	3939258
608	ENGINE FAN – 4BT / 6BT / ISB 6.7L (SUCKER TYPE, 203 DIAMETER 10 RIBS ADES PLASTIC)	3912751
609	ENGINE FAN – 4BT / 6BT / 6CTA 8.3L / ISB 6.7L	3912752
610	ENGINE FAN – 4BT / 6BT / ISB 6.7L (SUCKER TYPE, 223 DIAMETER 6 RIBS METAL)	3914279
611	ENGINE FAN – 4BT / 6BT / ISB 6.7L / 6CTA 8.3L	3911316
612	AIR CLEANER ELEMENT – ISB	4931611
613	MALE ADAPTER ELBOW – ISB / KTA19 / QSK19	116936
614	DIPSTICK – ISB	3933364
615	HEAT EXCHANGER COVER – ISB	3910344
616	CRANKCASE BREATHER COVER – ISB	4936347
617	WATER INLET CONNECTION – 4BT / 6BT / ISB / QSB	3930888
618	WATER INLET CONNECTION – 4BT / 6BT / ISB / QSB	3941929
619	TURBOCHARGER OIL DRAIN CONNECTION – ISB	3934085
620	OIL SUCTION CONNECTION – 4BT / 6BT / ISB / QSB	3905206
621	V BAND CLAMP – ISB / ISC / QSC	3957456
622	EXHAUST CLAMP – ISB	3595658
623	VACUUM PUMP BRACE – ISB	3919619
624	FAN SUPPORT – ISB3.9 / ISB4.5 / ISB6.7 / QSB3.9	3909890
625	BELT TENSIONER BRACKET – ISB	3930838

626	ALTERNATOR BRACE	3920862
627	UNLOADING VALVE BODY – ISB / ISM / QSM / ISC / QSC / L10	3558828
628	ANGLE DRIVE ADAPTER – B SERIES / ISB	3905217
629	FLYWHEEL RING GEAR – 4B3.9 / 6B5.9 / B4.5 / B5.9 / B6.7 / ISB6.7 (127 TEETH)	3905427
630	SEALING WASHER – 4BT3.9 / 6BT5.9 / ISB3.9 / ISB4.5 / QSB3.9 / QSB4.5	3918188
631	ALTERNATOR – ISB	5316342
632	SEALING WASHER – 4BT3.9 / 6BT5.9 / ISB3.9 / ISB4.5 / QSB3.9 / QSB4.5	3918188
633	TURBO MOUNTING STUD – ISC350 / C8.3-C215 / B5.9 / 6C8.3 / ISB-RV275 / ISC300 / C8.3-P	3818823
634	SALVAGE SLEEVE – B3.9-V110 / QSB5.9480H0 / B5.9-M330 / 6B5.9 / B5.9-C / 4R3.9	3904166
635	RECTANGULAR RING SEAL – 4BT3.9 / 6BT5.9 / ISB3.9 / ISB4.5 / QSB3.9	3906697
636	RECTANGULAR RING SEAL – 4BT3.9 / 6BT5.9 / ISB3.9 / ISB4.5 / QSB3.9	3906698
637	RECTANGULAR RING SEAL – ISB3.9 / ISB4.5 / ISB5.9G / QSB3.9 / QSB4.5	3903475
638	FLYWHEEL RING GEAR – 4B3.9 / 6B5.9 / ISB6.7 / QSB5.9 / 6C8.3 / QSC8.3 (138 TEETH)	3908546
639	FLYWHEEL RING GEAR – 4B 3.9 / B 4.5 / 6B 5.9 / ISB 6.7	3901774
640	FAN PULLEY – ISB / QSB	3914463
641	FAN PULLEY – ISB / QSB / ISC / QSC	3914462
642	BUSHING – QSB4 / 6B5.9 / B5.9-M330 / QSB6.7 / QSB4.5 / B5.9-C / B3.9-C76	4891178
643	PISTON BODY – 4B3.9 / B4.5 / B5.9 / B6.7 / ISB6.7 / QSB5.9	3908815
644	TURBO MOUNTING STUD NUT – ISB240 / 6B5.9 / ISB / ISC350	3818824
645	HEXAGON NUT – C8.3-C215 / B5.9-M210 / ISB-RV275 / ISC350 / C8.3-P / QSB6.7	3818824
646	NOISE ISOLATOR – 4BT3.9 / 6BT5.9 / ISB3.9 / ISB4.5 / QSB3.9 / QSB4.5	3935449
647	FRONT GEAR HOUSING – ISB / QSC / KTA38 / QSK38	3936256
648	FLYWHEEL RING GEAR – 4B 3.9 / B 4.5 / 6B 5.9 / ISB 6.7	3901774
649	PUSH ROD COVER GASKET – 4B3.9 / B4.5 / QSB4.5 / B3.9-C130	3283767
650	OIL FILTER HEAD GASKET – QSB5.9 / B3.9 / BT5.9GEN.DR6 / 6B5.9 / 4B3.9	3942915
651	GEAR COVER GASKET – QSB-110C / B3.9-C80 / 4B3.9 / B5.9 / 6B5.9 / 4BT3.9	3914385
652	FRONT GEAR COVER GASKET	3917780
653	VIBRATION DAMPER – 4BT / 6BT / ISB 6.7L (8.233 DIAMETER RUBBER HOLES)	3914454
654	UNLOADER VALVE CAP – ISB / ISC / QSC	184240
655	FAN SUPPORT BALL BEARING	3910739
656	SEALING WASHER – 4BT3.9 / 6BT5.9 / ISB3.9 / ISB4.5 / QSB3.9 / QSB4.5	3963988
657	EXHAUST OUTLET TUBE – 4BT3.9 / 6BT5.9 / ISB3.9 / QSB3.9 / QSB4.5	3910993
658	FUEL SYSTEM LEAK TESTER – ISB	3164618
659	FUEL PUMP TESTER – ISB	3164621
660	ALTERNATOR SUPPORT – 4B3.10 / 6B5.10 / ISB3.9 / ISB4.5 / QSB3.9 / QSB4.5	3930820
661	MOUNTING SPACER – ISC350 / ISL400 / ISLG320 / QSB6.7 / ISC330 / ISB / B5.9-A200	3945252
662	SPEED INDICATOR RING – 4B3.9 / 6B5.9 / ISB6.7 / QSB5.9	3942441

663	SPEED INDICATOR RING – 4B3.9 / 6B5.9 / 6C8.3 / ISC8.3 / QSC8.3 / QSB5.9	3972345
664	IDLER PULLEY – ISB / QSB	3978324
665	IDLER PULLEY – ISB / QSB / ISC / QSC	4991240
666	FAN PULLEY – B Series / ISB / QSB / 6CTA / ISC / QSC	3914458
667	FAN PULLEY – ISB / QSB	3914460
668	CRANKSHAFT PULLEY – ISB / QSB / ISC / QSC	3914494
669	ZINC ELECTRODE PLUG – ISM / QSM / ISB / QSB / ISB	3957921
670	PISTON PIN – NH220 / NH250 / NT855 / ISB / QSB / ISB	3939374
671	OIL PAN – 4B3.9 / 6B5.9 / B4.5 / B6.7 / ISB6.7 / QSB4.5 (STAMPED STEEL)	3907570
672	STARTER – 4B3.9 / B4.5 / B6.7 / ISB6.7 / QSB4.5 / QSB5.9 (12 V)	3964427
673	STATOR REPAIR KIT – 4B3.9 / B4.5 / B5.9 / B6.7 / ISB6.7 / QSB	4089399
674	VACUUM PUMP REPAIR KIT – 4B3.9 / 6B5.9 / ISB / ISD	4089742
675	VIBRATION ISOLATOR – ISB / QSB / ISC / QSC	3968021
676	VIBRATION ISOLATOR – ISB / QSB	3349230
677	VIBRATION ISOLATOR – ISB / QSB / ISC / QSC	3393944
678	RESTRICTION INDICATOR – ISB / NH220 / NH250 / NT855	178957
679	PLAIN HOSE – ISB	63549
680	PLAIN HOSE – ISB / ISC / QSC	3897789
681	PLAIN HOSE	3866540
682	PLAIN HOSE	3286499
683	MOLDED HOSE – ISB / ISC / QSC	3866019
684	MOLDED HOSE – ISB	4020094
685	FLEXIBLE HOSE – ISB	3897700
686	FLEXIBLE HOSE – ISB	3866592
687	FLEXIBLE HOSE – ISB / ISC / QSC	3866565
688	FLEXIBLE HOSE	3866591
689	FLEXIBLE HOSE	3918562
690	FLEXIBLE HOSE – ISB / QSB	3934396
691	FLEXIBLE HOSE – ISB	4019401
692	FLEXIBLE HOSE – ISB	4078924
693	ELBOW HOSE – ISB	3934720
694	ELBOW HOSE – ISB	3912965
695	ELBOW HOSE – ISB	188580
696	ELBOW HOSE – ISB	176743
697	ENGINE HEATER – 4B3.9 / B4.5 / B5.9 / B6.7 / ISB6.7 / QSB	3911836
698	INTAKE AIR HEATER – 4B3.9 / B4.5 / B5.9 / B6.7 / ISB6.7 / QSB	3929108
699	WIRING HARNESS – ISB	3971324

700	WIRING HARNESS – ISB	3971303
701	WIRING HARNESS – ISB	3971321
702	FLYWHEEL RING GEAR – 4B3.9 / 6B5.9 / B4.5 / B5.9 / B6.7 / ISB6.7	3978313
703	TEMPERATURE GAUGE – B SERIES / ISB	3918217
704	PUSH ROD COVER GASKET – ISB	3284623
705	HEAT EXCHANGER GASKET – 4BT3.9 / 6BT / B4.5 / B5.9 / ISB3.9 / ISB4.5 / QSB3.9	3910343
706	EXHAUST OUTLET CONNECTION GASKET – 4BT3.9 / 6BT5.9 / ISB3.9 / QSB3.9	3921961
707	COVER PLATE GASKET – 4BT3.9 / 6BT / ISB3.9 / ISB4.5 / QSB3.9 / QSB4.5	3939258
708	ENGINE FAN – 4BT / 6BT / ISB 6.7L (SUCKER TYPE, 203 DIAMETER, 10 BLADES, PLASTIC)	3912751
709	ENGINE FAN – 4BT / 6BT / 6CTA 8.3L / ISB 6.7L	3912752
710	ENGINE FAN – 4BT / 6BT / ISB 6.7L (SUCKER TYPE, 223 DIAMETER, 6 BLADES, METAL)	3914279
711	ENGINE FAN – 4BT / 6BT / ISB 6.7L / 6CTA 8.3L	3911316
712	AIR CLEANER ELEMENT – ISB	4931611
713	MALE ADAPTER ELBOW – ISB / KTA19 / QSK19	116936
714	DIPSTICK – ISB	3933364
715	HEAT EXCHANGER COVER – ISB	3910344
716	CRANKCASE BREATHER COVER – ISB	4936347
717	WATER INLET CONNECTION – 4BT / 6BT / ISB / QSB	3930888
718	WATER INLET CONNECTION – 4BT / 6BT / ISB / QSB	3941929
719	TURBOCHARGER OIL DRAIN CONNECTION – ISB	3934085
720	OIL SUCTION CONNECTION – 4BT / 6BT / ISB / QSB	3905206
721	V BAND CLAMP – ISB / ISC / QSC	3957456
722	EXHAUST CLAMP – ISB	3595658
723	VACUUM PUMP BRACE – ISB	3919619
724	FAN SUPPORT – ISB3.9 / ISB4.5 / ISB6.7 / QSB3.9	3909890
725	BELT TENSIONER BRACKET – ISB	3930838
726	ALTERNATOR BRACE	3920862
727	UNLOADING VALVE BODY – ISB / ISM / QSM / ISC / QSC / L10	3558828
728	ANGLE DRIVE ADAPTER – B SERIES / ISB	3905217
729	FLYWHEEL RING GEAR – 4B3.9 / 6B5.9 / B4.5 / B5.9 / B6.7 / ISB6.7 (127 TEETH)	3905427
730	SEALING WASHER – 4BT3.9 / 6BT5.9 / ISB3.9 / ISB4.5 / QSB3.9 / QSB4.5	3918188