



Ben Liu

Mobile/ WeChat: +86-13705041170

FUZHOU SUNSHINE MACHINERY CO.,LTD

NO.6 Gulouyuan, Juyuanzhou Industrial Zone,

Jinshan Development Area, Fuzhou, Fujian, China.

Email: sales@primepowergenset.com

<http://www.gensetengine.com>

Cummins 6B5.9 engine Spare parts catalog

Part number	Description
3978822	BEARINGCRANKSHAFT THRUST
3978818	Bearing, Main (Upper: Standard)
3934486	KITSEAL
S600	WASHER,LOCK
154916	GASKET,HYDRAULIC PUMP
3935449	ISOLATORNOISE
3902332	KEYPLAIN WOODRUFF
3902425	WASHERSEALING
3910739	BEARINGBALL
3927692	NUTHEAVY HEXAGON
204048	PLATECOVER
3918188	WASHERSEALING
3920867	VALVEINTAKE
3923044	RETAINERFAN HUB
3938157	GASKETFLANGE
3007635	PLUGEXPANSION
3008400	GASKETHYDRAULIC PUMP
3008465	PLUGPIPE
3008468	PLUGPIPE
3008469	PLUGPIPE
3013786	PLUGPIPE
3026396	CLAMPHOSE

3033033	CLAMPHOSE
3035960	RINGRETAINING
3279228	DIPSTICK
3280956	DATAPLATE
3282074	NUTHEXAGON FLANGE
3282266	PLUGTHREADED
3282824	PUMP, FUEL INJECTION
3282901	HOSEPLAIN
3282942	BRACETUBE
3284623	GASKETPUSH ROD COVER
3501102	LOCKPLATE
3501188	PLATECLAMPING
3502449	SEAL,RECTANGULAR RING
3503100	BEARINGTURBOCHARGER
3503347	SCREWFLAT HEAD CAP
3503662	SLINGEROIL
3503668	BAFFLEOIL
3518980	COLLARTHRUST
3519163	SCREWDRIVE
3519302	SHIELDTURBOCHARGER HEAT
3519336	WHEELTURBOCHARGER H2
3519409	HOUSINGTURBINE H1C
3521832	CLAMPTUR V BAND
3522390	HOUSINGCOMPRESSOR H2
3522801	DIFFUSERTURBOCHARGER
3523318	ROTORTURBOCHARGER
3523958	SEALO RING
3525739	BEARINGTUR THRUST
3527184	SCREWHEXAGON HEAD SET
3527619	DATAPLATE
3528741	TURBOCHARGER
3709861	GASKETTURBOCHARGER
3756754	SEALSPLIT RING
3758848	SEALSPLIT RING
3759917	SCREWHEXAGON HEAD SET
3762259	RINGRETAINING
3802132	KITENGINE PISTON
3802134	KITENGINE PISTON
3802160	KITENGINE PISTON
3802289	TURBOCHARGERH1
3802355	VALVEINTAKE
3802356	VALVEEXHAUST
3802641	KITCYL BLOCK HARDWARE
3804899	KITFRONT SEAL SERVICE
3818823	STUD

3818824	NUTREGULAR HEXAGON
3883284	SEAL,O RING
3900068	DOWELRING
3900227	SCREWHEXAGON HEAD CAP
3900240	NUTREGULAR HEXAGON
3900242	RINGRETAINING
3900245	WASHERPLAIN
3900250	COLLETVALVE
3900257	DOWELPIN
3900267	SEALGROMMET
3900269	WASHERPLAIN
3900276	SPRINGVALVE
3900299	RETAINERVALVE SPRING
3900589	NUTHEXAGON FLANGE
3900629	SCREWHEX FLANGE HEAD CAP
3900630	SCREWHEX FLANGE HEAD CAP
3900631	SCREWHEX FLANGE HEAD CAP
3900632	SCREW,HEX FLANGE HEAD CAP
3900633	SCREWHEX FLANGE HEAD CAP
3900637	SCREWHEX FLANGE HEAD CAP
3900677	SCREWHEXAGON HEAD CAP
3900687	PLUGEXPANSION
3900808	SEALINJECTOR
3900919	SCREWCONNECTING ROD CAP
3900955	PLUGEXPANSION
3900956	PLUGEXPANSION
3900958	PLUGEXPANSION
3901020	NOZZLEPISTON COOLING
3901170	CON ROD BEARINGS
3901221	SCREWHEXAGON HEAD CAP
3901249	SCREWHEX FLANGE HEAD CAP
3901306	BUSHINGCAMSHAFT
3901356	GASKETTURBOCHARGER
3901395	SCREWHEXAGON HEAD CAP
3901446	SCREWHEX FLANGE HEAD CAP
3901706	
3901757	SCREWHEX FLANGE HEAD CAP
3901774	GEARFLYWHEEL RING
3901895	CAPFILLER
3902115	SCREWHEX FLANGE HEAD CAP
3902343	DOWELRING
3902501	STUD
3902601	BEARINGROLLER
3903035	SCREW,BANJO CONNECTOR
3903089	BRACEALTERNATOR

3903293	NUTREGULAR HEXAGON
3903463	COVERACCESS HOLE
3903475	SEALRECTANGULAR RING
3903486	TUBEFUEL SUPPLY
3903487	TUBEFUEL SUPPLY
3903488	TUBEFUEL SUPPLY
3903489	TUBEFUEL SUPPLY
3903490	TUBEFUEL SUPPLY
3903652	CLAMPV BAND
3903723	WASHERPLAIN
3903757	BRACKETLIFTING
3903834	SCREWTWELVE POINT CAP
3903857	SCREWHEX FLANGE HEAD CAP
3903924	PINTIMING
3903990	SCREWHEX FLANGE HEAD CAP
3904181	PLUGTHREADED
3904217	SCREWHEXAGON HEAD CAP
3904230	CLAMPSRING HOSE
3904446	SCREWHEX FLANGE HEAD CAP
3904483	PINROLL
3904519	BRACETUBE
3904849	RINGRETAINING
3904981	FANALTERNATOR
3905307	SCREWBANJO CONNECTOR
3905313	BRACEFUEL PUMP
3905351	SEALGROMMET
3905388	TEEMALE UNION
3905391	SEALGROMMET
3905595	GASKETTIMITING HOUSING
3905692	TUBEFUEL DRAIN
3905802	ENDOIL GAUGE TUBE
3905804	BRACETUBE
3906216	NUTHEXAGON FLANGE
3906619	PLUGPIPE
3906659	SEALINJECTOR
3906694	SEALRECTANGULAR RING
3906695	SEALRECTANGULAR RING
3906696	SEALRECTANGULAR RING
3906697	SEALRECTANGULAR RING
3906698	SEALRECTANGULAR RING
3906773	WASHERSEALING
3906972	PIPEAIR INLET
3907049	SCREWHEX FLANGE HEAD CAP
3907582	TUBEFUEL SUPPLY
3907769	SCREWHEXAGON HEAD CAP

3907860	SCREWHEX FLANGE HEAD CAP
3907998	SCREWROUND HEAD CAP
3908032	CRANKSHAFTENGINE W/GEAR
3908086	COVERINTAKE MANIFOLD
3908096	GASKETCOVER PLATE
3908118	BRACKETLIFTING
3908226	SCREWHEX FLANGE HEAD CAP
3908308	TUBEOIL GAUGE
3908560	PULLEY,ALTERNATOR
3908563	RETAINERALT PULLEY
3908985	UNIONMALE
3908988	TUBEFUEL SUPPLY
3909355	ADAPTERFILTER HEAD
3909356	SEALRECTANGULAR RING
3909373	TUBELUB OIL SUCTION
3909395	CLAMPSRING HOSE
3909438	TUBEFUEL SUPPLY
3909696	MANIFOLDFUEL
3910130	SPACERFAN PILOT
3910248	PLUGO RING
3910260	SEALO RING
3910265	ELBOWMALE ADAPTER
3910495	SCREWHEX FLANGE HEAD CAP
3910715	SPACERMOUNTING
3910810	LEVERROCKER
3910811	LEVERROCKER
3910824	SEALO RING
3910959	NUTLOCK
3910960	WASHERPLAIN
3911423	SUPPORTROCKER LEVER
3911446	SCREWBANJO CONNECTOR
3911924	HUB,FAN
3912072	SCREWHEXAGON HEAD CAP
3912220	GASKETEXH OUT CONNECTION
3912473	SEALO RING
3912753	FANENGINE
3912772	RETAINERBELT
3913433	SUPPORT,FAN
3913638	SCREWHEX FLANGE HEAD CAP
3913994	SEALO RING
3914385	GASKETGEAR COVER
3914396	TUBEOIL GAUGE
3914462	PULLEY,FAN
3915772	SEALRECTANGULAR RING
3915787	PLUGTHREADED

3915800	SEALRECTANGULAR RING
3916042	GASKETHYDRAULIC PUMP
3916302	SWITCH,MAGNETIC
3917747	ISOLATORVIBRATION
3917778	BRACETUBE
3918109	SCREWHEX FLANGE HEAD CAP
3918377	MOTORSTARTING
3918428	PLUNGERPRS REGULATOR
3918641	TUBEFUEL SUPPLY
3918673	GASKETGEAR COVER
3918954	HEADLUB OIL FILTER
3919358	SLEEVEINJECTOR
3919683	HOUSINGTIMING
3920447	SCREWHEX FLANGE HEAD CAP
3920706	PLUGEXPANSION
3920758	HOUSINGGEAR
3920773	WASHERSEALING
3920779	SCREWHEX FLANGE HEAD CAP
3920780	SCREWHEX FLANGE HEAD CAP
3920781	SCREWHEX FLANGE HEAD CAP
3920831	HARNESSWIRING
3920868	VALVEEXHAUST
3283335	GASKET, CYLINDER HEAD
3921640	SEALVALVE STEM
3922488	SUPPORTROCKER LEVER
3923015	CLIP
3923261	SEALINJECTOR
3923262	
3923331	GASKETTHM HOUSING COVER
3924147	PLUGTHREADED
3924606	PANELNOISE
3924724	SCREWBANJO CONNECTOR
3924962	SCREWHEX FLANGE HEAD CAP
3925009	SPRINGCOMPRESSION
3925186	SCREWFLAT HEAD CAP
3925207	BRACKETBELT TENSIONER
3925234	PLATECOVER
3925529	OIL SEAL, REAR
3925860	TUBEFUEL DRAIN
3925883	SCREWHEX FLANGE HEAD CAP
3925955	ADAPTERFILTER HEAD
3926047	SEALO RING
3926700	SPRINGVALVE
3926846	SCREWHEX FLANGE HEAD CAP
3926972	SCREWHEX FLANGE HEAD CAP

3927154	GASKETEXHAUST MANIFOLD
3928404	COVERVALVE
3928405	COVERVALVE
3928759	SEALGROMMET
3928797	CYLINDER BLOCK
3928873	SCREWHEX FLANGE HEAD CAP
3928989	CLIP
3929021	Bearing, Main (Standard)
3929027	GEARCRANKSHAFT
3929037	CRANKSHAFT,6B
3929457	SEALO RING
3929792	GASKETFILTER HEAD
3930324	SEALINJECTOR
3930460	PANOIL
3930906	GASKETVALVE COVER
3931338	GEARACCESSORY DRIVE
3936876	SEALRECTANGULAR RING
3937111	SEALOIL
3937214	NOZZLEPISTON COOLING
5333477	TENSIONER,BELT
3937706	GASKET,OIL DRAIN
3938152	GASKETINT MANIFOLD COVER
3938156	GASKETGEAR HOUSING
3939258	GASKETCOVER PLATE
3942914	GASKET, OIL COOLER CORE B
3942915	GASKETFILTER HEAD
3991084	NAMEPLATE
FF42000	Filter, Fuel
3930942	FUEL FILTER (3930942)
3922487	SHAFT, ROCKER LEVER
3910809	LEVER, ROCKER
3900705	INSERT, ROCKER LEVER
3910808	LEVER, ROCKER
3903380	SEAL, BANJO CONNECTOR
3917712	SCREW, HEXAGON HEAD CAP
3924338	HEAD, LUB OIL FILTER
3802376-01	SET, LOWER ENGINE GASKET
3938159	GASKET, REAR COVER
3937072	GASKET, OIL PAN
3931607	GASKET, FUEL PUMP
3804897-01	SET, UPPER ENGINE GASKET
3938158	GASKET, CONNECTION
3937155	WASHER, SEALING
3281693	SCREW, DRIVE
3278459	TAG, INSTRUCTION

3900706	SCREW, SLOTTED SET
3901787	TAPPET, VALVE
3923896	COVER, GEAR
3913995	HOUSING, TIMING PIN
3931351	GASKET, GEAR HOUSING
3802270	BLOCK, CYLINDER
3900967	CAP, MAIN BEARING
3812090	PLUG, EXPANSION
3930139	NOZZLE, PISTON COOLING
3927916	COVER, PUSH ROD
3928832	GASKET, PUSH ROD COVER
3914454	DAMPER, VIBRATION
3923321	DRIVE, HYD PUMP
3923239	ADAPTER, HYDRAULIC PUMP
3923244	SHAFT, ACCESSORY DRIVE
3802273	KIT, THERMOSTAT
3917324	THERMOSTAT
3920678	ALTERNATOR
3062484	BRACKET, MAGNETIC SWITCH
3923387	SUPPORT, ALTERNATOR
3911557	BELT, V RIBBED
3913434	SUPPORT, FAN
3910004	TUBE, AIR FUEL CONTROL
3905860	SCREW, BANJO CONNECTOR
3905403	SCREW, CAPTIVE WASHER CAP
3897331	HEAD, FUEL FILTER
3897327	HEAD, FUEL FILTER
3918191	WASHER, SEALING
3931627	HOUSING, FLYWHEEL
3928493	GASKET, REAR COVER
3921043	COVER, REAR
3931383	GEAR, FUEL PUMP
3928143	PUMP, FUEL TRANSFER
3931059	GASKET, COVER PLATE
3276948	FLYWHEEL
3282475	FLYWHEEL
3928406	ISOLATOR, NOISE
3902363	SEAL, RECTANGULAR RING
3903102	CONNECTION, WATER INLET
3933615	VALVE, PRESSURE RELIEF
3921558	CORE, COOLER
3932217	CARTRIDGE, LUB OIL FILTER
3928396	PUMP, WATER
3930337	PUMP, LUBRICATING OIL
3902347	MANIFOLD, EXHAUST

3905369	PLUG, EXPANSION
3931349	GASKET, FLANGE
3914639	CAMSHAFT
3910624	CAMSHAFT
3907431	GEAR, CAMSHAFT
3914641	SUPPORT, CAMSHAFT THRUST
3901569	ROD, ENGINE CONNECTING
3901567	ROD, ENGINE CONNECTING
3901085	BUSHING
3907163	PISTON, ENGINE
3802050	SET, PISTON RING
3901793	PIN, PISTON
3908815	PISTON, ENGINE
3802052	SET, PISTON RING
3908816	PISTON, ENGINE
3802054	SET, PISTON RING
3802340	HEAD, CYLINDER
3920612	HEAD, CYLINDER
3902606	PLUG, EXPANSION
3901097	SEAL, VALVE STEM
3920085	INJECTOR
3919343	INJECTOR
3812092	PLUG, EXPANSION
3765575	GASKET, OIL DRAIN
3503562	NUT, LOCK
3537148	IMPELLER, TUR COMPRESSOR
3528206	HOUSING, TUR BEARING
3503335	NUT, REGULAR HEXAGON
3802147	KIT, TURBO REPAIR
3545652	KIT, TURBO REPAIR
3523176	SEAL, RECTANGULAR RING
3518004	WASHER, LOCK
3914388	GASKET, OIL DRAIN
3915704	SENSOR, FLUID LEVER
5258791	COVER, ENGINE SHIPPING
3281694	TAG, INSTRUCTION
3931347	GASKET, INT MANIFOLD COVER
3916166	HOSE, PLAIN
3916165	HOSE, PLAIN
3901448	SCREW, HEX FLANGE HEAD CAP
3914409	HOUSING, THERMOSTAT