



Ben Liu

Mobile/ WeChat: +86-13705041170

FUZHOU SUNSHINE MACHINERY CO.,LTD

NO.6 Gulouyuan, Juyuanzhou Industrial Zone,
Jinshan Development Area, Fuzhou, Fujian, China.

Email: sales@primepowergenset.com

<http://www.gensetengine.com>

Cummins KTTA38 engine Spare parts catalog

Part number	Description
2897691	SWITCH,PRESSURE
3417958	COMPRESSOR, AIR
3010247	COV,VLV
3177713	HOUSING,ROCKER LEVER
2867067	HOSEFLEXIBLE
3643960	SEAL,OIL
3633046	SEALFERRULE
3643961	SHAFTWATER PUMP
4089500	SET PISTONE RING
3037536	PLUG,THREADED
3330584	GEAR,IDLER 3330584
100478	SEALO RING
4026171	GASKET,FUEL PUMP
3016792	SEAL,OIL 3016792
3053478	LEVER,ROCKER
3053476	LEVER,ROCKER
3053477	LEVERROCKER
3643967	PUMP, WATER
3630839	GASKET,RKR LEVER HOUSING
3062676	SEAL,OIL
193736	SEAL,INJECTOR O RING
3521225	SCREWHEXAGON HEAD SET
3008706	SCREENINJECTOR FILTER
3803528	VALVEEXHAUST
3803518	VALVEINTAKE
3922794	SEAL,O RING
3076125	BARREL & PLUNGER,STEPPED

3076489	THERMOSTAT
212161	ORING
4024809	KIT,FUEL SOLENOID 4024809
175830	PLUGEXPANSION
3046200	SPIDER,JAW COUPLING
3640775	SEALTAMPER PROOF
FS1006	FUIL WATER (original) FS1006
3090450	RING,OIL PISTON
3090460	RING,COMPRESSION PISTON
4081176	RING,COMPRESSION PISTON
3081489	SEALOIL
3635074	CORE, COOLER
3642503	LEVER,CAM FOLLOWER 3081413
3078218	SHAFT,CAM FOLLOWER
S169	SCREW,HEXAGON HEAD CAP
S172B	SCREW,HEXAGON HEAD CAP
S174	
S181	
S181C	SCREW, HEXAGON HEAD CAP
S189C	SCREW,SOCKET HEAD CAP
S197	
S199	
S199A	Hexagon Head Cap Screw
S212	NUT,REGULAR HEXAGON
S213A	NUT,REGULAR HEXAGON JAM
S217	NUT,HEAVY HEXAGON
S224	NUT,HEAVY HEXAGON
S2268	FITTING,GREASE
S2286	DRIVE SCREW
S249	NUT,REGULAR HEXAGON JAM
S270	NUT,REGULAR HEXAGON
S306	
S316	KEY,PLAIN WOODRUFF
S600	WASHER,LOCK
S602	Washer, Plain
S603	WASHER,LOCK
S607	WASHER,LOCK
S608	WASHER,LOCK
S610	WASHER,LOCK
S611	WASHER,LOCK
S613	
S622	WASHER,PLAIN
S626	WASHER
S631	WASHER,PLAIN
S640	WASHER

S915A	PLUG,PIPE
S955	BUSHING,REDUCING PIPE
S962E	DRAINCOCK
100133	SHAFTFUEL PUMP
100193	BUSHING
100216	SHAFTFUEL PUMP DRIVE
100835	CLAMPHOSE
102020	SCREW,HEXAGON HEAD CAP
102978	DOWELPIN
103009	SCREW,HEXAGON HEAD CAP
103023	SCREW,HEXAGON HEAD CAP
103089	WASHER,PLAIN
105375	NAMEPLATE
106069	SCREW,HEXAGON HEAD CAP
107460	CLIP
107695	PINROLL
107948	DOWELDIAMOND
108172	SEAL,O RING
108330	WASHER,PLAIN
108384	SLEEVESPRING PACK
108602	SCREW,HEXAGON HEAD CAP
108604	SCREWHEXAGON HEAD CAP
108707	SCREWHEXAGON HEAD CAP
108767	SCREW,HEXAGON HEAD CAP
109319	LOCKPLATE
109917	SCREWSOCKET SET
110058	NUTFUEL PUMP ADJUSTING
110266	SCREW,HEXAGON HEAD CAP
110855	GASKETFUEL PUMP
111445	WASHER,LOCK
112105	ELBOWMALE ADAPTER
112408	WASHER,PLAIN
114307	BRACE,TUBE
116391	BUSHING
118227	DOWELFUEL PUMP
124507	GEAR,FLYWHEEL RING
125741	CLAMP, T BOLT
125742	CLAMPT BOLT
127018	WASHER,LOCK
127362	WASHER,PLAIN
127454	WASHERPLAIN
127571	WASHER,PLAIN
127950	GASKETCONNECTION
128807	RINGRETAINING
129768	SPRINGVALVE

129838	KNOB
129839	COVER,SHUTOFF VALVE
129888	SEALRECTANGULAR RING
130083	BEARING, THRUST
131026	SEALO RING
131584	PIN,ROLL
135144	CLAMPT BOLT
135169	RING,RETAINING
135783	WASHER,LOCK
136574	SCREWHEXAGON HEAD CAP
137890	SCREWHEXAGON HEAD CAP
138912	DOWEL,PIN
139473	PLUG,THREADED
139990	WASHERPLAIN
140315	CLAMP, T BOLT
141630	PLUNGER,IDLE SPRING
143855	SPRINGGOVERNOR ASSIST
144178	PLUNGER,GOVERNOR
144179	SHIM,FUEL PUMP GOVERNOR
145504	SEALO RING
145507	SEAL,O RING
145529	SEALO RING
145530	SEALO RING
145536	SEAL, O RING
145550	SEALO RING
145581	SEALO RING
145586	SEALO RING
145600	SEAL,O RING 4998542
145613	SEALO RING
146437	WEIGHT,GOVERNOR
146483	SCREENROTOR
148582	DOWELPIN
149134	LOCKPLATE
149274	HOSEPLAIN
149437	CLAMPT BOLT
151355	LOCKPLATE
152364	SCREWPAN HEAD CAP
153581	SCREWTWELVE POINT CAP
154087	SEAL,RECTANGULAR RING
158250	SCREW,TWELVE POINT CAP
163086	PLUG,PIPE
163826	WEIGHT,GOVERNOR
163944	BUSHING
163945	RINGRETAINING
167157	BALLCHECK

168306	SCREW,SLOTTED SET
169834	CLIP
170942	GEARFUEL PUMPING
173086	GASKET,INJECTOR
174299	RETAINERINJECTOR FIL SCN
178079	VALVE, CHECK
3053772	PLUNGER, TAPPET
180371	CLIP
3034245	PUMPFUEL GEAR
181461	GOVERNORAIR COMPRESSOR
3042713	CUPINJECTOR
181466	WASHER,LOCK
3069102	GASKETAIR COMPRESSOR
3175255	GEAR,CRANKSHAFT
3521442	SEAL,SPLIT RING
185804	SCREWHEXAGON HEAD CAP
190397	SLEEVEWEAR
191772	SCREW,TWELVE POINT CAP
194037	SOCKETROCKER LEVER
195265	PLUGPIPE
199919	SCREWTWELVE POINT CAP
69911A	CLIP
S1047A	ELBOW, HOSE
200845	INSERTTHREADED
205230	BUSHING
3007525	KIT LINER 3007525
201010	BUSHING
201048	GASKETCONNECTION
201049	GASKET,CONNECTION
201745	RING,THRUST
3047390	BEARING,CON ROD (STD)
203346	SPACERMOUNTING
203426	PIN,INJECTOR ROLL
203933	PLUGEXPANSION
204994	CONNECTORMALE
205059	WASHER,PLAIN
205091	COLLETVALVE
205093	INSERT,VALVE
205094	RETAINERVERVALVE SPRING
205126	WASHERPLAIN
205128	WASHER,PLAIN
205129	DOWEL,RINg
205168	WASHERPLAIN
205227	PLUG, EXPANSION
205269	RINGRETAINING

3177556	SEALRECTANGULAR RING
3201793	DIPSTICK
3626715	COREAFTERCOOLER
205375	SCREWTWELVE POINT CAP
205393	SCREW,TWELVE POINT CAP
3804301	SETLOWER ENGINE GASKET
205394	SCREW,TWELVE POINT CAP
205401	PLUGEXPANSION
3818267	HOSEPLAIN
205438	LOCKWIRE
205439	RING,RETAINING
205544	SHAFTLUB OIL PUMP
205565	SCREWTWELVE POINT CAP
205571	GASKETOIL SLINGER
205584	SCREWTWELVE POINT CAP
205683	BUSHING
205684	BRACKETLIFTING
205976	RING,RETAINING
206013	GASKETFLANGE
206028	SCREW,SOCKET HEAD CAP
206041	SCREWTWELVE POINT CAP
206090	RINGRETAINING
206091	GEARENGINE BARRING
206093	HOUSINGENGINE BARRING
206158	COVER,HYD PUMP FLANGE
206177	GASKETPRS RLF VALVE BODY
206193	GASKETWATER PUMP
206195	SLEEVE,SPLINE COUPLING
206196	RINGRETAINING
206224	PLUG,EXPANSION
206277	GASKET,INTAKE MANIFOLD
206279	GASKETCONNECTION
206326	SCREW,TWELVE POINT CAP
206402	SCREW, TWELVE POINT CAP
206406	COVER,HYD PUMP FLANGE
206407	GASKET,HAND HOLE
206416	GASKETSUPPORT
206436	TUBEAIR
206443	GASKETTHERMOSTAT HOUSING
206460	GASKETCONNECTION
206526	POINTER,TIMING
206527	SCREW,TWELVE POINT CAP
206576	GASKETTURBOCHARGER
206580	BEARINGMAIN STD
206587	CAPMAIN BEARING

206588	CAPMAIN BEARING
206590	BEARINGMAIN STD
206600	BEARINGMAIN STD
206610	BEARINGMAIN STD
206668	ELBOWPLAIN STREET PIPE
206709	TUBEWATER TRANSFER
206742	PLUG,EXPANSION
206747	GEAR,CAMSHAFT
8265	WASHER,PLAIN
206756	GEARLUBRICATING OIL PUMP
8306	PINROLL
206904	KEY,PLAIN WOODRUFF
207214	PIPE, AIR INLET
207226	BUSHING
207244	SEAL INJECTOR
207344	BUSHING
207373	COVER,CAMSHAFT
207515	GASKETCONNECTION
207535	GASKETWTR TRF CONNECTION
207603	PLATECOVER
211633	SHAFT,GOVERNOR
211636	GEAR,GOVERNOR
212350	PLUNGERGOVERNOR
212601	SHAFT,FUEL PUMP DRIVE
212602	GEAR, TACHOMETER DRIVE
212603	SEAL,OIL
212604	RINGRETAINING
212605	GEAR,FUEL PUMPING
212607	SHAFT,TACHOMETER DRIVE
212609	BUSHING,TACHOMETER DRIVE
212610	GEAR,TACHOMETER DRIVE
43764	CONNECTORMALE
44680	LEVERTHROTTLE
60985	HOSE,PLAIN
63223	HOSE,PLAIN
63842	WASHERPLAIN
67622	PLUGPIPE
67684	WASHER,PLAIN
67946	WASHER,PLAIN
68139	ELBOW,PLAIN ADAPTER
68171	PINROLL
68189	CLIP
68193	PLUGPIPE
68445	PIN, GROOVE
68908	LOCKPLATE

69465	CLIP
69519	DOWELPIN
69558	DOWELPIN
69580	DOWELPIN
69771	SCREW, SOCKET HEAD CAP
70415	SEAL, O RING
70662	DOWELPIN
70690	PLUNGER FUEL CONTROL
70700	SPRING FUEL PUMP TORQUE
70704	WASHER PLAIN
70705	GASKET, FUEL PUMP
70715	WASHER PLAIN
70716	SCREW KNURLED
70791	SCREW SOCKET HEAD CAP
70798	GUIDE, SPRING
70823	RING, RETAINING
70834	STOP, THROTTLE LEVER
70836	PLUNGER, THROTTLE LEVER
212613	HUB, JAW COUPLING
212639	ADAPTER, SPLINE
212668	KEY SQUARE
213559	SOCKET, CAM FOLLOWER
213768	SEAL O RING
215921	COUPLING PLAIN HOSE
218792	SPACER FAN PILOT
219153	BOLT CONNECTING ROD
650826	PLUNGER FUEL CONTROL
3000082	WASHER, PLAIN
3000138	SUPPORT BEARING
3000139	BEARING THRUST
3000174	HUB SPLINE COUPLING
3000204	WASHER SEALING
3000446	COVER FUEL CONTROL
3000632	GASKET, CONNECTION
3001340	SEAL O RING
3001707	SHIM
3001811	SCREW, HEXAGON HEAD CAP
3002110	CONNECTOR, MALE
3002158	PLUG PIPE
3002350	BRACKET OIL TUBE
3002351	BRACKET OIL TUBE
3002956	TUBE WATER TRANSFER
3002993	DOWEL, RING
3003156	SEAL, WIRE
3003341	BELT V RIBBED

3003354	BEARINGROLLER
3004057	NUTLOCK
3004318	BRACKETOIL TUBE
3004683	GEAR,IDLER
3004686	BUSHING
3004724	SPACER,SEAL
3006343	STOPTHROTTLE LEVER
3007971	BEARING,CAMSHAFT THRUST
3008465	PLUGPIPE
3009475	SHAFTPIVOT
3009477	SLEEVE
3009481	SHAFTIDLER
3009482	BRACKETIDLER PULLEY
3009483	PULLEYIDLER
3010410	COVERACCESS HOLE
3010595	SCREWCAPTIVE WASHER CAP
3010941	BUSHING
3010943	SHAFTTHROTTLE
3010945	SEALDUST
3011076	SEALO RING
3011580	GASKETAFTERCOOLER COVER
3011716	SCREWCAPTIVE WASHER CAP
3011884	INSERTLINER
3012281	BRACKETFAN
3012474	SCREWCAPTIVE WASHER CAP
3013036	SHAFTSHUTOFF VALVE
3013266	SCREWCONNECTING ROD CAP
3013811	DIAPHRAGM
3014103	WASHER PLAIN
3014449	GASKETFLANGE
3014575	CAPFUEL PUMP FILTER
3014668	SEALO RING
3014766	SCREW,CAPTIVE WASHER CAP
3015232	GAUGEPRESSURE
3015233	GAUGETEMPERATURE
3015234	GAUGETEMPERATURE
3015237	TRANSDUCER
3015238	TRANSDUCER
3016021	HOUSINGGOVERNOR
3016182	NUT,LOCK
3016344	PULLEYIDLER
3016825	ROLLERCAM FOLLOWER
3016826	ROLLERCAM FOLLOWER
3017051	SCREW,CAPTIVE WASHER CAP
3017052	SCREWCAPTIVE WASHER CAP

3017555	SCREW,HEX FLANGE HEAD CAP
3017961	RODPUSH
3018534	Compressor, Air
3018767	SPRINGCOMPRESSION
3018920	CLAMP,WIRE TIE
3020524	COVERSPRING PACK
3021123	SEALO RING
3021394	FLYWHEEL
3021470	SCREWCAPTIVE WASHER CAP
3021618	PLUNGERPRS REGULATOR
3021977	COVERSPRING PACK
3023066	SEAL,O RING
3023095	WASHER SEALING
3023217	PLUG,THREADED
3023499	CAPIDLER LEVER
3023536	SCREWHEXAGON HEAD CAP
3025485	WASHERPLAIN
3026312	SHIM
3026313	SHIM
3026423	GASKETAFTERCOOLER COVER
3026426	GASKETFLANGE
3026556	BEARING, THRUST
3026557	BEARINGTHRUST
3026705	TUBELUB OIL TRANSFER
3027633	BEARINGTHRUST
3027728	SPACERMOUNTING
3028291	SEAL,O RING
3028552	BODYBYPASS VALVE
3030207	RETAINER,DIPSTICK
3030970	DISCVALVE
3031404	CONNECTOR, TUBE
3031518	SHAFTFAN HUB
3032627	UNION,MALE
3032628	ELBOW,MALE UNION
3032633	SCREW,TWELVE POINT CAP
3033405	HEAD,LUB OIL FILTER
3033626	WASHERPLAIN
3033629	PIN,ROLL
3033719	DOWELRING
3033740	VALVECHECK
3033742	PLUGTHREADED
3033800	WASHER,PLAIN
3033853	SHAFTIDLER
3033915	SEAL,O RING
3034408	SEALO RING

3034412	SEAL,O RING
3034574	SCREWHEX FLANGE HEAD CAP
3035083	ISOLATOR,VIBRATION
3035084	ISOLATOR,VIBRATION
3035228	SEALO RING
3035697	SCREWHEXAGON HEAD CAP
3035844	TUBE-FUEL IN
3036115	COVER,PROTECTIVE SHIPPING
3036230	SCREWHEXAGON HEAD CAP
3036460	WASHER,SPRING
3036666	SEALO RING
3036846	SCREWTWELVE POINT CAP
3037236	SEAL,O RING
3037489	MOTOR,AIR STARTING
3037537	SEAL,O RING
3037662	ELBOW,MALE UNION
3037821	GASKET,EXHAUST MANIFOLD
3038743	VALVE, CHECK
3038938	COVER,ROCKER LEVER
3039164	LEVER,CAM FOLLOWER
3040721	GASKETCAM FOL HOUSING
3040722	GASKETCAMSHAFT COVER
3040750	PLUNGERGOVERNOR
3040814	PLUGTHREADED
3040817	SEALO RING
3040818	PLUGTHREADED
4307427	ADAPTER,INJECTOR
3042427	SPRING,COMPRESSION
3042428	SPRING,COMPRESSION
3042430	RETAINERINJECTOR CUP
3042542	SEAL,O RING
3043211	GASKET,OIL PAN
3043212	GASKET,OIL PAN
3043909	Bushing, Connecting Rod
3043912	LOCKPLATE
3045136	WASHERPLAIN
3045137	SCREWHEXAGON HEAD CAP
3045229	SHAFTACCESSORY DRIVE
3045568	CONNECTIONWATER INLET
3045986	SEAL,O RING
3046201	SEALO RING
3046202	PLUG,THREADED
3046407	SCREW SOCKET SET
3046680	SHAFTTHROTTLE
3046852	GASKET,ACC DRIVE SUPPORT

3047276	PISTONAIR FUEL CONTROL
3047278	PISTONAIR FUEL CONTROL
3048557	SPACER,BEARING
3049041	RETAINERSPRING
3050453	IMPELLERWATER PUMP
3050624	VALVEPRESSURE RELIEF
3050692	SWITCH,MAGNETIC
3050944	GASKET,FLANGE
3051461	NUTLOCK
3051463	WASHERPLAIN
3052218	RETAINER,INJECTOR SPRING
3052231	RETAINERINJECTOR LINK
3052233	LINK,INJECTOR PLUNGER
3053479	LEVER,ROCKER
164524	FANENGINE
165006	SCR,CAP
185747	SEALOIL
187556	SCREWCAPTIVE WASHER CAP
199358	SLEEVESPLINE COUPLING
201008	
204995	ELBOWMALE ADAPTER
4095009	PIN, PISTON K
205532	GASKETLUB OIL PUMP
205545	SHAFTLUB OIL PUMP
205546	COVERLUB OIL PUMP
205547	
205548	BUSHING
205549	COVERLUB OIL PUMP
205607	SPRINGCOMPRESSION
205659	SPRINGCOMPRESSION
205661	GASKETBEARING SUPPORT
205662	GASKETPRS RLF VALVE BODY
206092	SPRINGCOMPRESSION
206179	GASKETCONNECTION
206421	GASKETGEAR HOUSING
206446	GASKET WTR TRANSFER TUBE
206505	BEARINGROLLER
206506	NUTLOCK
206520	RINGRETAINING
207038	SEALO RING
207251	GER,PMP
207253	
207551	SEALO RING
216187	SEAL,O RING
3000594	SCREWSOCKET HEAD CAP

3001718	BODYPRS RELIEF VALVE
3001719	PINSTRAIGHT
3003016	SEALO RING
3004594	GEAR
3005939	GASKETCOVER PLATE
3005940	GASKETGEAR HOUSING
3006430	*
3007441	SEALO RING
3007512	SEALO RING
3008710	SEALRECTANGULAR RING
3009323	GSK,COV
3009324	GASKET,WATER HEADER COVER 3637727
3009480	PULLEYFAN
3010269	DRIVE ACCESSORY
3011575	UNITSENDING
3628973	GSK,PLT
3016306	CLAMPV BAND
3016316	VALVECOUPLING
3016766	PULLEYIDLER
3019416	SPRINGTORSION
3019795	TACHOMETER
3022695	MUFFLER
3022696	LUBRICATORAIR STG MOTOR
3022697	I/R Relay Valve
3023077	NIPPLECOUPLING
3023129	SEAL,DUST
3023130	SEALDUST
3026236	TUBEEXHAUST OUTLET
3026391	SEALRECTANGULAR RING
3026393	SEALO RING
3026420	SEALDUST
3026421	SEALO RING
3026796	ELBOWPLAIN STREET PIPE
3026802	BRACESTARTING MOTOR
3027988	RINGRETAINING
3279805	LINKINJECTOR PLUNGER
3028587	PULLEYACCESSORY DRIVE
3028696	COVER,OIL PAN :3178743
3029301	NUTLOCK
3029857	PINROLL
3030487	SPACERBEARING
3030768	HOSEHUMP
3030990	RODCONTROL
3030991	ENDCONTROL ROD
3030992	ENDCONTROL ROD

3030993	NUTREGULAR HEXAGON JAM
3031470	RODCONTROL
3031544	SEAL,RECTANGULAR RING
3032014	SPRING,COMPRESSION
3032629	PLUG,THREADED
3035215	CONNECTIONAIR CROSSOVER
3035216	CONNECTIONAIR CROSSOVER
3035217	BRACERETAINING
3035218	COVERAFTERCOOLER
3035222	CONNECTIONAIR CROSSOVER
3035223	GASKETCONNECTION
3040710	TUBE,WATER TRANSFER
3040810	
3040819	PLG,THD
3040911	PLG,THD
3043214	GASKET,OIL PAN
3043642	WASHERSPRING
3044613	VALVEAIR STARTER
3044993	PLUGINJECTOR ORIFICE
3045047	PLUG, INJECTOR ORIFICE
3046943	SEAL O RING
3051069	SPRINGCOMPRESSION
3052819	INSERTVALVE
3053502	BARREL, INJECTOR
3054411	SPRINGLEAF
3054852	SPRINGCOMPRESSION
3055069	PLUG,THREADED
3056356	HARNESSWIRING
3057139	RODPUSH
3058423	PLUNGERPRESSURE LIMITER
3058424	SPRINGCOMPRESSION
3060605	BARREL,PLUNGER,OIL VALVE
3060606	BODYOIL CONTROL VALVE
3062119	BALL,CHECK
4327021	SWITCH,TEMPERATURE
3063019	
3063022	VALVEOIL CONTROL
3063674	ELBOW,MALE UNION
3064321	SCREW,CAPTIVE WASHER CAP
3065376	COVER,SPRING PACK
3065723	SCREW,CAPTIVE WASHER CAP
3065830	SEALOIL
3066498	SCREW,HEX FLANGE HEAD CAP
3066889	CAMSHAFT
3066914	SEAL,O RING

3067347	PLG,THD
3067424	PLUG,THREADED
3067884	SCREWSOCKET HEAD CAP
3068859	CAP,TAPPET TOP STOP
3068860	NUTLOCK
3069015	NUTLOCK
3069026	CAP
3069027	COVER,GEAR
3069776	ADAPTER,CRANKSHAFT
3069778	PULLEYCRANKSHAFT
3069781	SPACER,CRANKSHAFT
3070108	GASKETBYPASS VALVE BODY
3070186	WASHERPLAIN
3070962	SCREW HEXAGON HEAD CAP
3073890	BODYFUEL SHUTOFF VALVE
3073998	DISCVALVE
3075381	TAPPET,HYD VAR TIMING
3076040	SCREWFUEL PUMP ADJUSTING
3076124	
3076132	INJECTOR
3076226	GASKETAIR COMPRESSOR
3076346	SLEEVEWEAR
3077526	BARRELAIR FUEL CONTROL
3081064	HEAD, CYLINDER
3640315	ROTATOR, VALVE
3081950	UNION,MALE
3084539	SEAL,O RING
3084621	MANIFOLD,OIL
3084622	MANIFOLD,OIL
3085345	SOCKET, TAPPET
3086362	CROSSHEAD,VALVE
3088317	LOCKPLATE
3088371	SEAL,DUST
3088853	PANOIL
3089765	CLAMP,V BAND
3090769	SCREEN, FILTER
3095291	CONNECTOR,MALE
3095292	ELBOWMALE ADAPTER
3095293	UNIONMALE
3095454	PUMP FUEL
3095814	BODYFUEL PUMP
3096077	GASKETFUEL PUMP
3631242	PISTONENGINE
3098593	HOUSINGFILTER
3098594	FILTERFUEL

3160924	SEALDUST
4334080	GASKET,CYLINDER HEAD
3171368	GASKET,TURBOCHARGER
3175027	WASHER,PLAIN
3175032	GASKETBREATHER
3175058	CLIP
3175074	SCREWHEXAGON HEAD CAP
3175239	NUT,LOCK
3175281	SUPPORTBEARING
3175318	TUBE,LUB OIL DRAIN
3175452	HEADCORROSION RESISTOR
3175453	HEADCORROSION RESISTOR
3175517	GASKETFLANGE
3175573	RINGRETAINING
3175658	TUBELUB OIL SUCTION
3175705	SEALFERRULE
3175716	ELBOW,MALE ADAPTER
3175773	ELBOWMALE ADAPTER
3175797	CONNECTIONFUEL BLOCK
3175856	GASKET,HAND HOLE
3175857	SUPPORTWATER PUMP
3176216	WEIGHTCRANKSHAFT COUNTER
3176218	DOWEL,RING
3176355	ELBOWMALE ADAPTER
3176465	SCREWHEXAGON HEAD CAP
3176552	SEAL,TAMPER PROOF
3176570	SCREW,HEX FLANGE HEAD CAP
3176607	BREATHERCRANKCASE
3176618	DOWEL,DIAMOND
3176637	HOUSINGFLYWHEEL
3176710	TUBEFUEL SUPPLY
3176713	CONNECTIONOIL TRANSFER
3176772	SHAFT,ROCKER LEVER
3176857	DOWELRING
3176918	HOUSING GEAR
3177040	SHAFTSHUTOFF VALVE
3177045	WASHER,PLAIN
3177082	HOSEMOLDED
3177093	WASHERPLAIN
3177108	GASKETFILTER HEAD
3177125	SUPPORTPIVOT SHAFT
3177128	SLEEVEWEAR
3177129	BEARINGTHRUST
3177151	PLATECOVER
3177152	PLATECOVER

3177160	GASKET,GEAR COVER
3177198	ELBOW,MALE UNION
3177300	CONNECTIONADAPTER
3177302	CONNECTIONWATER INLET
3177303	TUBEWATER TRANSFER
3177304	TUBEWATER TRANSFER
3177305	TUBEWATER TRANSFER
3177306	TUBEWATER TRANSFER
3177307	TUBEWATER TRANSFER
3177308	TUBEWATER TRANSFER
3177433	COVER,LUB OIL FILTER
3177443	SCREWHEX FLANGE HEAD CAP
3177509	BUSHING
3177510	BUSHING
4955577	BLOCK,CYLINDER
3177760	SCREWHEXAGON HEAD CAP
3630452	GASKET,TURBOCHARGER
3177945	SCREWHEX FLANGE HEAD CAP
3178043	TUBEWATER TRANSFER
3178076	GASKET,GEAR HOUSING
3178290	CONNECTIONWATER TRANSFER
3178319	TUBEWATER BYPASS
3178320	TUBEWATER BYPASS
3178450	SHAFTIDLER
3178457	Washer, Plain
3178466	CONNECTIONWATER TRANSFER
3178563	PULLEY FAN
3178747	CONNECTORMALE
3178763	COVERHAND HOLE
3178808	COVERHAND HOLE
3178947	SCREWHEXAGON HEAD CAP
3179000	DOWELPIN
3179021	SCREW, BANJO CONNECTOR
3179026	GASKETCONNECTION
3179027	GASKETCONNECTION
3179035	GASKET,WTR TRF CONNECTION
3179664	VALVE, PISTON COOLING
3179944	PULLEYACCESSORY DRIVE
3200287	SEALKEYWAY
3201125	SEALO RING
3201128	NUT,REGULAR HEXAGON
3201568	PLUGCOUPLING
3201583	PLUG,THREADED
3201585	SEALO RING
3201739	SHAFT,BARRING

3201740	ASSEMBLY,ENGINE BARRING
3202199	HOUSING,ROCKER LEVER
3202210	GUIDEVALVE STEM
3252438	CONNECTORTUBE
3252444	ELBOWTUBE CONNECTOR
3277045	SPRINGCOMPRESSION
3279503	COVERFUEL PUMP
3279794	SEALINJECTOR O RING
3279821	SCREWINJECTOR STOP
3279850	NUTTAPPET TOP STOP LOCK
LF777	LF PKGA
3648162	SEAL, DUST
3348331	VALVESHUTOFF
3348860	SEALFERRULE
3408250	ISOLATOR,VIBRATION
3411695	CLAMPINJECTOR
3417076	PLUG,THREADED
3417077	SCREW,SOCKET HEAD CAP
3417096	SCREW,SOCKET SET
3417098	SCREW,SOCKET HEAD CAP
3502449	SEAL,RECTANGULAR RING
3504967	WASHERPLAIN
3519535	NUTLOCK
3519627	Bearing, Turbocharger
3519641	RINGRETAINING
3521265	HOUSINGTURBINE
3522631	CLAMPV BAND
3522904	LOCKPLATE
3522921	HOUSINGTURBINE
3523024	IMPELLER, TURBO HC5A
3523412	SEALSPLIT RING
3523546	IMPELLER, TURBO HC5A
3523556	HOUSINGCOMPRESSOR HC5A
3523980	SLINGEROIL
3524031	SHAFT & WHEEL
3524418	SHIM
3524419	BAFFLEOIL
3524421	DIFFUSER, TURBOCHARGER
3524863	DIFFUSERTURBOCHARGER
3525073	SCREWHEXAGON HEAD SET
3525076	HOUSINGCOMPRESSOR HC3
3528109	CLAMPV BAND
3529372	NUTREGULAR HEXAGON
3536588	SHIELDTURBOCHARGER HEAT
3536914	BEARINGTUR THRUST

3591522	COLLARTHURST
3594555	Housing, Tur Bearing
3625504	BULBLIGHT
3626493	HOSEPLAIN
4380750	NUT,LOCK 4380750
3626948	TUBEAIR
3627145	HOSEHUMP
3627309	ADAPTER,FILTER HEAD
3627324	BRACKET,MAGNETIC SWITCH
3627412	CLIP
3627417	TUBEWATER TRANSFER
3627449	SEALRECTANGULAR RING
3627546	TUBE, CPR WATER OUTLET
3627548	TUBECPR WATER INLET
3627682	SPACERBEARING
3627684	SPACERBEARING
3627694	UNIONMALE
3627695	SEAL,O RING
3627697	
3627698	
3627756	BRACKET,AIR CONTROL VALVE
3627763	CLAMPRETAINING
3627793	ELBOWPLAIN STREET PIPE
3627799	CONNECTORMALE
3627802	CONNECTORMALE
3627808	SUPPORTTHM HOUSING
3627856	CONNECTORMALE
3627927	PLUNGERPRS REGULATOR
3627938	GASKET,COVER PLATE
3627961	SEAL,THERMOSTAT
3628002	BUSHINGREDUCING PIPE
3628003	BUSHINGREDUCING PIPE
3628078	CONNECTIONWATER INLET
3628104	SCREWHEXAGON HEAD CAP
3628124	CONNECTORMALE
3628160	HOSEFLEXIBLE
3628194	SCREW,HEXAGON HEAD CAP
3628196	SCREW,HEXAGON HEAD CAP
3628229	COVER,HAND HOLE
3628411	COVERSTARTER FLANGE
3628452	SCREWHEXAGON HEAD CAP
3628476	BRACKETPUMP
3628517	CONNECTIONFUEL BLOCK
3628518	CONNECTIONFUEL BLOCK
3628521	ELBOWMALE ADAPTER

3628553	BRACETUBE
3628554	BRACE, TUBE
3628604	PLUG, PIPE
3628605	PLUG, PIPE
3628606	PLUG, PIPE
3628607	PLUG, PIPE
3628608	PLUG, PIPE
3628609	PLUG, PIPE
3628610	PLUGPIPE
3628639	SHAFTWATER PUMP
3628652	DAMPER VISCOUS VIBRATION
3628750	SWITCH, PRESSURE
3628755	COVER, CAMSHAFT
3628756	COVER, CAMSHAFT
3628758	HARNESSWIRING
3628798	GEAR, CRANKSHAFT
3628822	GEAR IDLER
3628823	GEAR, IDLER
3628888	HOSE, FLEXIBLE
3628894	SEALDUST
3628895	SEALOIL
3628902	WASHER, PLAIN
3628931	TUBEFUEL SUPPLY
3628961	UNION, MALE
3628962	UNION MALE
3628963	ELBOW, MALE UNION
3628965	PRIMERENG LUB OIL SP
3628971	SWITCHRELAY
3629065	COVERWATER HEADER
3629066	COVER, WATER HEADER 3648236
3629067	SPACER, MOUNTING
3629071	DECAL
3629114	PLUGTHREADED
4920076	GASKET, ROCKER LEVER COVER
3629141	GASKET, LUB OIL FIL COVER
3629146	CONNECTION, OIL TRANSFER
3629168	PLUG, EXPANSION
3629341	CONNECTIONOIL TRANSFER
3629387	GASKETFILTER HEAD
3629408	CONNECTION, FUEL BLOCK
3629409	CONNECTIONFUEL BLOCK
3629410	RETAINERSPRING
3629411	SEATPRS REGULATOR VALVE
3629451	CLIP
3629452	CLIP

3629454	CLIP
3629496	ELBOW,MALE ADAPTER
3629497	DRAINCOCK
3629538	HOUSING,ROCKER LEVER
3629540	TUBE,WATER TRANSFER
3629698	TEE,STREET PIPE
3629855	BUSHING
3629861	CVR,WTR
3629962	WASHER,PLAIN
3630164	PLUG,THREADED
3630364	CONNECTIONFUEL BLOCK
3630408	BRACEAIR COMPRESSOR
3630432	HEADLUB OIL FILTER
3630628	SPRING, VALVE
3630734	TEE,MALE UNION
3630736	ELBOW,MALE UNION
3630740	SEAL,O RING
3630741	HEADFUEL FILTER
3630742	GASKET,CONNECTION
3630764	TEEMALE UNION
3630806	ELBOW,MALE UNION
3630864	HOSE, FLEXIBLE
3630865	HOSE,FLEXIBLE
3630867	HOSE, FLEXIBLE
3630874	GASKETFLYWHEEL HOUSING
3630877	CONNECTOR INTAKE
3630969	GASKET,LUB OIL CLR HSG
3631295	HOSE, FLEXIBLE
3631313	SHIELD,HEAT
3631471	ADAPTERO RING
3631617	MANIFOLD,EXHAUST
3631618	MANIFOLD,EXHAUST
3631624	MANIFOLD,EXHAUST
3631690	ELBOWMALE UNION
3631800	CONNECTIONADAPTER
3631821	SHIELDHEAT
3632015	HOSEFLEXIBLE
3632225	ROD,ENGINE CONNECTING
3632333	HOSEFLEXIBLE
3632335	HOSE,FLEXIBLE
3632840	SEALO RING
3632900	BRACKETSOLENOID
3633076	HOSE,PLAIN
3633214	MANIFOLDFUEL
3633215	MANIFOLDFUEL

3633245	TEE,PLAIN ADAPTER
3633246	VALVECHECK
3633479	NUT,LOCK
3633716	FUSE
3633789	HOSEFLEXIBLE
3633805	CLAMP,V BAND
3633972	CLAMP,T BOLT
3634007	SEAL,WATER PUMP
3634019	PLUGEXPANSION
3634065	SUPPORT,WATER PUMP
3634172	BRACKETVALVE
3634269	DOWELDIAMOND
3634304	HOSE,FLEXIBLE
3634392	HOSEFLEXIBLE
3634393	HOSEFLEXIBLE
3634394	HOSEFLEXIBLE
3634395	HOSE, FLEXIBLE
3634430	HOSE,FLEXIBLE
3634431	HOSEFLEXIBLE
3634503	HOSEFLEXIBLE
3634505	HOSEFLEXIBLE
3634522	HOSE,FLEXIBLE
3634639	BODYLUBRICATING OIL PUMP
3634640	PUMPLUBRICATING OIL
3634699	UNIONMALE
3635713	BODYWATER PUMP
3637651	HUB, FAN
3640685	ADAPTERO RING
3642036	TUBEWATER TRANSFER
3800730	SETUPPER ENGINE GASKET
3801724	TURBOHC5A
3801726	TURBOCHARGERHC5A
3803852	KIT,ASSESSORY DRIVE SEAL
3804700	KIT,STC TAPPET REPAIR
3818885	SEAL,O RING
3888312	CHEM. PKG. DCA65-L
LF670	LF PKG A
3913994	SEALO RING
3966349	GASKETEXHAUST MANIFOLD
4016364	DOWELPIN
4017621	PLUG,EXPANSION
4058964	RESISTOR,CORROSION
4077027	
4080141	BELLOWS
4099004	CRANKSHAFT,ENGINE 3648630

4101094	LEVERIDLER
43696A	SEAL,O RING
43828A	CLAMP,HOSE
43828C	CLAMP,HOSE
4916693	ADAPTER,FILTER HEAD
4922219	GASKET,ROCKER LEVER COVER
650827	SEATPRS REGULATOR VALVE
650829	SPRINGVALVE
651045	WASHERPLAIN
68138	CONNECTOR,MALE
68152A	CLIP
69204D	RINGRETAINING
70183	RINGRETAINING
70740	PINROLL
AK4010SS	HOSE,FLEXIBLE
AR11475	VALVE,PRESSURE RELIEF
AR12111	*
AR12250	SET,MAIN BEARING (STD)
2865878	HOSE,FLEXIBLE
AS4011SL	HOSE, FLEXIBLE
AS401440SS	HOSE, FLEXIBLE
AS4023SL	HOSE,FLEXIBLE
AS4026SL	HOSE,FLEXIBLE
S1003A	SEAL, GROMMET
S102	
S103A	SCREW,HEXAGON HEAD CAP
S103D	SCREW,HEXAGON HEAD CAP
S104	SCREW,HEXAGON HEAD CAP
S1042A	TEE,MALE ADAPTER
S105	SCREW,HEXAGON HEAD CAP
S109	SCREW,HEXAGON HEAD CAP
S112	SCREW,HEXAGON HEAD CAP
S113	
S116	SCREW,HEXAGON HEAD CAP
S117	SCREW,HEXAGON HEAD CAP
S119	SCREW,HEXAGON HEAD CAP
S120	
S123	
S125	SCREW,HEXAGON HEAD CAP
S126	Screw, Hexagon Head Cap
S127	SCREW,HEXAGON HEAD CAP
S137	SCREW,HEXAGON HEAD CAP
S139	
S140	SCREW,HEXAGON HEAD CAP
S141	

S145	SCREW,HEXAGON HEAD CAP
S153	SCREW,HEXAGON HEAD CAP
S159B	
S16052	BEARING,BALL
S16054	BEARING, BALL
S16069	BEARING, BALL
S16240	
S163	SCREW, HEX HEAD CAP
S164	SCREW,HEXAGON HEAD CAP
3629113	PLUG, THREADED
3800729	SETSINGLE HEAD GASKET
S169A	SCREW,HEXAGON HEAD CAP
S162A	SCREW,HEXAGON HEAD CAP
3628799	GEAR, IDLER
3630068	BODY, PISTON COOLING VALVE
S907A	PLUG, PIPE
3631805	PLUG, PIPE
3627723	RETAINER, SHAFT
3634066	SUPPORT,WATER PUMP 3634065
3630034	PLUG,THREADED 3023217
3630358	CONNECTION,FUEL BLOCK 3630364
3628633	ELBOW, MALE ADAPTER
3630765	TEE, PLAIN ADAPTER
3177812	SUPPORT, FRONT ENGINE
S121B	SCREW,HEXAGON HEAD CAP
3627026	COVER, GEAR
4916694	HEAD, FUEL FILTER
3100524	UNION, MALE
S150A	SCREW,HEXAGON HEAD CAP
S167A	SCREW, HEXAGON HEAD CAP
3630681	SEAL, OIL
3175550	COVER, PROTECTIVE
3073891	BODY, SHUTOFF VALVE
206099	COVER, OIL PAN
3036665	PLUG, THREADED
3053667	PLUNGER, OIL CONTROL VALVE
3060604	BARREL, OIL CONTROL VALVE
3069989	COVER, OIL CONTROL VALVE
4009927	COVER, DIAPHRAGM
3417103	PLUG, THREADED
3628939	PULLEY, ACCESSORY DRIVE
3027151	NAMEPLATE
3027935	DECAL
3315228	DECAL
3315230	DECAL

3318651	DECAL
3329609	DECAL
3329610	DECAL
3630483	COVER, PROTECTIVE
3630484	COVER, PROTECTIVE
3889382	DECAL
205068	PIN, CAM FOLLOWER ROLLER
205071	PIN, CAM FOLLOWER ROLLER
3033726	COVER, FUEL PUMP GEAR
3033728	HOUSING, FUEL PUMP GEAR
3016793	SEAL, OIL
3177006	PULLEY, ACCESSORY DRIVE
3175805	BUSHING
102827	SEAL, O RING
AR11461	SHAFT, LUB OIL PUMP DRIVE
AR12386	SHAFT, LUB OIL PUMP DRIVE
S174B	SCREW, HEXAGON HEAD CAP
3175861	BRACKET, SHIPPING
S130A	SCREW, HEXAGON HEAD CAP
AR11496	SUPPORT, AND BUSHING
3177278	SUPPORT, ACCESSORY DRIVE
3177279	SUPPORT, ACCESSORY DRIVE
206517	FLYWHEEL
AK6018SS	HOSE, FLEXIBLE
3630106	DECAL KIT
3889381	DECAL
3178070	DATAPLATE
S152A	SCREW, HEXAGON HEAD CAP
3629424	BRACKET, CONNECTION 3634008, ADAPTER, PLAIN PIPE 3
3635035	LEVER, IDLER
3077528	ASSEMBLY, AFC
3077525	BARREL, AIR FUEL CONTROL
3074224	PLUNGER, AIR FUEL CONTROL
3631691	ELBOW, MALE UNION
3633179	NUT, TUBE
3630735	TEE, MALE UNION
3630737	ELBOW, MALE UNION
3630732	UNION MALE 3634699
3630733	UNION, MALE
3630730	UNION MALE 3634699
3630731	UNION, MALE
3630878	UNION, MALE
3632028	HOSE, FLEXIBLE
3634696	UNION, MALE
S111B	SCREW, HEXAGON HEAD CAP

3100550	UNION, MALE
3100549	UNION, MALE
3017243	MANIFOLD, FUEL
3017244	MANIFOLD, FUEL
3634638	BODY, LUBRICATING OIL PUMP
S610A	WASHER, PLAIN
3628534	UNION,MALE 3634685 CLIP 3629452
3628538	UNION, TURBO OIL
3628543	HOSE,FLEXIBLE 3627704, UNION,MALE3095293
4099003	CRANKSHAFT, ENGINE
3079939	COVER, FUEL PUMP
3279615	BODY, FUEL PUMP
AS12043SS	HOSE, FLEXIBLE
AK4038SS	HOSE, FLEXIBLE
3627930	ELBOW, MALE ADAPTER
3348330	VALVE, FUEL SHUTOFF
3630547	MANIFOLD, AIR INTAKE
3630548	MANIFOLD, AIR INTAKE
3630555	HEAD, LUB OIL FILTER
3630256	PAN, OIL
3630545	ADAPTER,OIL PAN 3640031, PLUG,PIPE 3628609
3630262	ADAPTER, OIL PAN
3630024	ROD, ENGINE CONNECTING
3630023	ROD, ENGINE CONNECTING
650828	BODY, CHECK VALVE
650831	GASKET, VALVE CHECK
AS4034SL	HOSE, FLEXIBLE
AK4029SS	HOSE, FLEXIBLE
AS4029SS	HOSE
3630828	ELBOW, MALE ADAPTER
AS4032SS	HOSE, FLEXIBLE
3594031	TURBOCHARGER
3594062	TURBOCHARGER
3005118	TUBE, WTR TRANSFER LB
3028918	TUBE, WATER BYPASS
3040881	TUBE, WATER TRANSFER
3630035	SEAL,O RING 3028291, PLUG,THREADED 3037536, TUBE,
3630016	TUBE, WATER TRANSFER
3175400	COVER, PROTECTIVE
3176534	COVER, PROTECTIVE
4023SL	HOSE
3628750RX	SWITCH PRESSURE
3408607RX	SWITCH PRESSURE
3408631RX	SWITCH, TEMPERATURE
3044613RX	VALVEAIR STARTER

3053476RX	LEVER ROCKER
3086362RX	CROSSHEAD, VALVE
3017961RX	RODPUSH
3037489RX	MOTOR AIR STARTING
3177040RX	SHAFTSHUTOFF VALVE

IN PIPE 3634057

36, TUBE, WATER TRANSFER 3629540

