



Ben Liu

Mobile/ WeChat: +86-13705041170

FUZHOU SUNSHINE MACHINERY CO.,LTD

NO.6 Gulouyuan, Juyuanzhou Industrial Zone,
Jinshan Development Area, Fuzhou, Fujian, China.

Email: sales@primepowergenset.com

<http://www.gensetengine.com>

Cummins QSC8.3 engine Spare parts catalog

Part number	Description
4089647	PUMP,WATER
3942749	LEVERROCKER
5404408	KITLINER
4987958	HEAD,CYLINDER
5266243	ROD,ENGINE CONNECTING
4995630	Rocker lever
3973511	CAPFILLER
3934486	KITSEAL
4076930	SWITCH, PRESSURE
3963983	WASHERSEALING
5253590	VALVE GUIDE SEAL
3922794	SEAL,O RING
S923E	DRAINCOCK
WF2074	WATER FILTER (3100307)
118227	DOWELFUEL PUMP
129866	UNIONMALE
145508	SEALO RING
3004258	PLUG,EXPANSION
3926854	PULLEYFAN
3900634	SCREWHEX FLANGE HEAD CAP
3902332	KEYPLAIN WOODRUFF
3902425	WASHERSEALING
3906733	SCREWHEX FLANGE HEAD CAP
3907308	GEARFLYWHEEL RING
3910739	BEARINGBALL
3918986	CRANKSHAFTENGINE W/GEAR

3919918	RING,COMPRESSION PISTON
3928870	BOLTCONNECTING ROD
3944153	BEARING,MAIN
3944452	RETAINERVEALVE SPRING
3945918	SETMAIN BEARING 010
3945920	SETMAIN BEARING 030
3945967	PLUNGERPRS REGULATOR
3948072	PUMPLUBRICATING OIL
203848	ELBOWMALE UNION
204048	PLATECOVER
3901969	PLUG,EXPANSION
3920692	RINGRETAINING
3925567	DAMPERRUBBER VIBRATION
3934864	NUTREGULAR HEXAGON
3970951	BUSHING
3923044	RETAINERFAN HUB
3939352	GASKETOIL SUC CONNECTION
3938160	GASKETOIL PAN
3934046	PINPISTON
3945917	SETMAIN BEARING STD
4025270	KITSEAL
68189	CLIP
3008465	PLUGPIPE
3008468	PLUGPIPE
3008469	PLUGPIPE
3037236	SEAL,O RING
3040815	PLUGTHREADED
3040817	SEALO RING
3046201	SEALO RING
3046202	PLUG,THREADED
3052061	SCREWHEXAGON HEAD CAP
156075	PLUGEXPANSION
200293	ELBOWMALE UNION
203131	NUTHEAVY HEXAGON
206963	INSERTFILTER HEAD
3004242	GSK,PMP
3029820	SEALO RING
3032693	PLUGEXPANSION
3035960	RINGRETAINING
3040810	
3040816	PLG,THD
3046943	SEAL O RING
3050897	PLG,THD
3059283	ELBOWMALE UNION
3062138	ELBOWMALE UNION

3062139	ELBOWMALE UNION
3069053	CLAMPV BAND
3071049	HOSE,FLEXIBLE
3089238	PLUGTHREADED
3089240	SEAL,O RING
3089384	SCREWHEX FLANGE HEAD CAP
3093730	SCREW,HEX FLANGE HEAD CAP
3093931	SCREWHEX FLANGE HEAD CAP
3201562	SEALO RING
3202101	PLUGTHREADED
3280893	TUBEOIL GAUGE
3282158	HOSEFLEXIBLE
3282372	STUD
3282433	SCREWHEX FLANGE HEAD CAP
3284360	HOUSINGFLYWHEEL
3286499	HOSE,PLAIN
3289648	BELTV RIBBED
3329899	DOWELPIN
3330202	SEALO RING
3330252	WASHERSPRING
3330478	SEALO RING
3330644	DRIVEFUEL PUMP
3331002	SCREWHEXAGON HEAD CAP
3347925	CONNECTIONFUEL DRAIN
3347941	SCREW SOCKET HEAD CAP
3348448	CONNECTORQCK DISCONNECT
3355406	HOSEPLAIN
3401544	ELM,FIL
3408345	SENSOR,TEMPERATURE
3408438	SEALO RING
3412320	CLAMPHOSE
3415691	ALTERNATOR
3417068	SCREWHEX FLANGE HEAD CAP
3417161	HARNESSWIRING
3503100	BEARINGTURBOCHARGER
3504967	WASHERPLAIN
3519163	SCREWDRIVE
3519302	SHIELDTURBOCHARGER HEAT
3522597	PINROLL
3522879	WHEELTURBOCHARGER H2
3527566	RINGRETAINING
3527619	DATAPLATE
3528104	BAFFLEOIL
3528121	COUPLINGELBOW HOSE
3528177	END, ADJUSTING LINK

3528204	NUTLOCK
3528221	RINGRETAINING
3528933	SEALO RING
3530556	SCREWHEXAGON HEAD SET
3530923	PLATEOIL SEAL
3530924	SLINGEROIL
3531238	RINGRETAINING
3532195	SPACERMOUNTING
3532196	SPACERMOUNTING
3532217	COLLARTHRUST
3532427	BAFFLE, TURBOCHARGER NOISE
3533163	RINGRETAINING
3534291	SCREWHEXAGON HEAD SET
3534309	PLATECLAMPING
3535215	CLAMPHOSE
3537960	GASKETTURBOCHARGER
3537979	CONNECTIONADAPTER
3538468	HOSEPLAIN
3539209	SCREWHEXAGON HEAD SET
3595651	BEARINGTUR THRUST
3596402	NUTLOCK
3606653	UNIONMALE
3617959	WASHERLOCK
3654215	COVERPROTECTIVE
3658544	COVERPROTECTIVE
3678603	SEAL,O RING
3678912	SEAL,O RING
3678923	PLUGTHREADED
3678925	SEAL,O RING
3756754	SEALSPLIT RING
3758848	SEALSPLIT RING
3759917	SCREWHEXAGON HEAD SET
3762259	RINGRETAINING
3800320	KITENGINE PISTON
3800343	SETLOWER ENGINE GASKET
3802538	SETPISTON RING
3818823	STUD
3818824	NUTREGULAR HEXAGON
3818885	SEAL,O RING
3820672	CLAMPHOSE
3863988	WASHERSEALING
3867043	SEALO RING
3867480	SEALO RING
3867640	SEALO RING
3867641	SEALO RING

3867642	SEALO RING
3867645	SEALO RING
3883284	SEAL,O RING
3883977	PIPEAIR TRANSFER
3899283	SEALO RING
3900227	SCREWHEXAGON HEAD CAP
3900250	COLLETVALVE
3900257	DOWELPIN
3900269	WASHERPLAIN
3900589	NUTHEXAGON FLANGE
3900628	SCREW,HEX FLANGE HEAD CAP
3900630	SCREWHEX FLANGE HEAD CAP
3900631	SCREWHEX FLANGE HEAD CAP
3900637	SCREWHEX FLANGE HEAD CAP
3900677	SCREWHEXAGON HEAD CAP
3900678	SCREWHEX FLANGE HEAD CAP
3901249	SCREWHEX FLANGE HEAD CAP
3901356	GASKETTURBOCHARGER
3901846	DOWELPIN
3901865	SCREWHEX FLANGE HEAD CAP
3902023	SCREWHEX FLANGE HEAD CAP
3902114	SCREWHEX FLANGE HEAD CAP
3902460	SCREW,HEX FLANGE HEAD CAP
3902662	NUTHEXAGON FLANGE
3903035	SCREW,BANJO CONNECTOR
3903105	SCREWHEX FLANGE HEAD CAP
3903112	SCREWHEX FLANGE HEAD CAP
3903200	SCREWHEXAGON HEAD CAP
3903210	NUTHEXAGON FLANGE
3903475	SEALRECTANGULAR RING
3903990	SCREWHEX FLANGE HEAD CAP
3904181	PLUGTHREADED
3904483	PINROLL
3904519	BRACETUBE
3904711	BRACETUBE
3905216	CLAMPV BAND
3905401	PLUGEXPANSION
3906216	NUTHEXAGON FLANGE
3906619	PLUGPIPE
3906659	SEALINJECTOR
3907177	SEALRECTANGULAR RING
3907740	CLAMPSPRING HOSE
3907769	SCREWHEXAGON HEAD CAP
3907860	SCREWHEX FLANGE HEAD CAP
3908181	SCREWHEXAGON HEAD CAP

3908612	SCREWDRIVE
3909310	SCREWHEXAGON HEAD CAP
3910248	PLUGO RING
3910260	SEALO RING
3910787	CONNECTIONOIL SUCTION
3910960	WASHERPLAIN
3911924	HUB,FAN
3912072	SCREWHEXAGON HEAD CAP
3912473	SEALO RING
3913032	GASKETCONNECTION
3913638	SCREWHEX FLANGE HEAD CAP
3913695	SEALO RING
3914136	CAP,FILLER
3914738	TUBEOIL FILLER
3915490	PLATECLAMPING
3917320	CRANKSHAFT,6C
3917746	ISOLATORVIBRATION
3917747	ISOLATORVIBRATION
3917892	GASKETCONNECTION
3917990	HOSEFLEXIBLE
3918002	SCREWBANJO CONNECTOR
3918174	GASKETOIL COOLER CORE
3918190	WASHERSEALING
3918334	HEADLUB OIL FILTER
3918776	GEARCRANKSHAFT
3919016	PLUGTHREADED
3919359	ISOLATORVIBRATION
3919624	PULLEYACCESSORY DRIVE
3920447	SCREWHEX FLANGE HEAD CAP
3920706	PLUGEXPANSION
3920773	WASHERSEALING
3920854	SCREWCAPTIVE WASHER CAP
3921644	CONNECTIONOIL FILLER
3921816	SCREWHEX FLANGE HEAD CAP
3921919	RING,COMPRESSION PISTON
4940183	CONNECTOR, MALE
3923016	CLIP
3923041	NUTLOCK
3924147	PLUGTHREADED
3924725	SCREWBANJO CONNECTOR
3924986	
3925234	PLATECOVER
3925532	
3925626	KITSEAL
3925883	SCREWHEX FLANGE HEAD CAP

3906081	KITSEAL
3926704	CLAMPSRING HOSE
3926722	SEAL,RECTANGULAR RING
3926846	SCREWHEX FLANGE HEAD CAP
3926863	SCREWHEX FLANGE HEAD CAP
3926865	SPACERMOUNTING
3927611	BRACETUBE
3927862	PIPEEXHAUST OUTLET
3928031	NOZZLEPISTON COOLING
3928519	CONNECTIONAIR INTAKE
3928989	CLIP
3929011	GASKETLUB OIL CLR COVER
3929106	SEALOIL
3930688	BRACETUBE
3930911	SEALO RING
3931824	SEALO RING
3933262	SEAL,OIL
3933384	COVERREAR
3934410	VALVEBYPASS
3935644	BEARINGROLLER
3935646	SHAFTACCESSORY DRIVE
3935945	
3936138	GEARACCESSORY DRIVE
5259022	TENSIONER,BELT
3936236	SPACERCIRCUIT BOARD
3936365	VALVEPRESSURE RELIEF
3936876	SEALRECTANGULAR RING
3936953	CONNECTORMALE
3937142	SEALINJECTOR
3937421	DIPSTICK
3937477	MANIFOLDEXHAUST
5269779	GASKET,EXHAUST MANIFOLD
3937706	GASKET,OIL DRAIN
3938163	CAMSHAFT
3938655	GASKETACC DRIVE COVER
3939258	GASKETCOVER PLATE
3939284	GASKETVALVE COVER
3939353	GASKETREAR COVER
3939694	ELBOWPLAIN UNION
3939962	DRIVEHYDRAULIC PUMP
3940152	INSERTVALVE
3940153	INSERTVALVE
3940245	GASKETHYDRAULIC PUMP
3940386	SEAL, O RING
3940639	CLAMPINJECTOR

3940817	SCREWHEX FLANGE HEAD CAP
3941140	SUPPORTROCKER LEVER
3941786	CARRIERSEAL
3941934	LEVEL, ROCKER
3942535	SEALOIL
3942748	LEVERROCKER
3942764	GEAR,FUEL PUMP
5263529	SUPPORTFAN
3942902	GASKETFLANGE
3943366	GASKET,CYLINDER HEAD
3943408	SPACERMOUNTING
3943440	SUPPORTFUEL PUMP
3943445	CROSSHEADVALVE
3943503	BRACETUBE
3943599	TUBEFUEL DRAIN
3943613	CONNECTIONAIR INTAKE
3943740	SHAFTSHUTOFF VALVE
3943808	PLUGEXPANSION
3943824	CONNECTIONTUR OIL DRAIN
3943844	MANIFOLDEXHAUST
3943857	SEAL,O RING
3943885	SCREWHEX FLANGE HEAD CAP
3943888	SEAL,VALVE STEM
3943933	SCREWHEX FLANGE HEAD CAP
3944001	SUPPORTCAMSHAFT THRUST
3944099	SCREWSTUDED FLANGE CAP
3944110	SUPPRESSORSURGE
3944141	CONNECTIONWATER INLET
3944152	SCREWSTUDED FLANGE CAP
3944158	BEARING,MAIN
3944163	BEARINGCRANKSHAFT THRUST
3944165	BEARINGCRANKSHAFT THRUST
3944166	BEARINGCRANKSHAFT THRUST
3944167	BEARINGCRANKSHAFT THRUST
3944213	TUBEFUEL SUPPLY
3944222	HEATERENGINE
3944239	BRACKETLIFTING
3944290	BRACKETLIFTING
3944293	GASKETGEAR HOUSING
3944298	GEARCAMSHAFT
3944312	BRACEALTERNATOR
3944429	CONNECTIONWATER OUTLET
3944593	SCREWHEX FLANGE HEAD CAP
3944646	GASKETINT MANIFOLD COVER
3944686	TUBEINJECTOR FUEL SUPPLY

3944688	TUBEINJECTOR FUEL SUPPLY
3944690	TUBEINJECTOR FUEL SUPPLY
3944692	TUBEINJECTOR FUEL SUPPLY
3944694	TUBEINJECTOR FUEL SUPPLY
3944698	BRACETUBE
3944699	ISOLATORVIBRATION
3944717	SCREWCAPTIVE WASHER CAP
3944833	CONNECTOR,MALE
3944845	BRACKETFILTER
3944874	SCREWSTUDED FLANGE CAP
3944988	HOSEFLEXIBLE
3945093	PLUGEXPANSION
3945094	PLUGEXPANSION
3945097	PLUGEXPANSION
3945098	PLUGEXPANSION
3945212	ELBOWPLAIN UNION
3945252	SPACERMOUNTING
3945253	BRACKETWIRING RETAINER
5283368	BUSHING
3945603	GASKETCONNECTION
3945833	COVERVALVE
3945853	HOUSING,GEAR
3945866	TAPPETVALVE
3945919	SETMAIN BEARING 020
3945921	SETMAIN BEARING 040
3948045	COVERGEAR
3948083	PLATECOVER
3948229	TUBEFUEL DRAIN
3948529	INJECTOR
3950661	BEARINGCON ROD STD
3957597	MOTORSTARTING
3960043	SCREW,HEX FLANGE HEAD CAP
3963384	FLYWHEEL
3963982	WASHER,SEALING
3963984	WASHERSEALING
3963988	WASHERSEALING
3964713	LEVER,ROCKER
3964720	SCREWRKR LEVER ADJUSTING
3964721	
3964722	ASSY,ROCKER LEVER
3965703	HARNESSETR CNT MDL WRG
5284362	CORE,COOLER
3966658	SHAFTROCKER LEVER
3966716	SEALO RING
3966719	RODPUSH

3966976	SCREWHEX FLANGE HEAD CAP
3967353	TAG, INSTRUCTION
3968112	SUPPORTALTERNATOR
3968382	BREATHERCRAKCASE
3968466	SCREWTWELVE POINT CAP
3968496	HOSEMOLDED
3968921	TUBETUR OIL DRAIN
3970655	SPRINGCOMPRESSION
3970810	SCREWHEX FLANGE HEAD CAP
3970886	GASKETBREATHER
3970955	CAPMAIN BEARING
3972011	CLAMPSRING HOSE
3972540	ASSY,ROCKER LEVER
4376359	PUMP,WATER
3973509	GASKETOIL PAN
3974296	PANOIL
3974325	HEADLUB OIL FILTER
3977737	SCREWOVAL HEAD CAP
3977851	PLUGTHREADED
3977853	PLUGTHREADED
3990084	SEAL,O RING
3990875	SCREWCAPTIVE WASHER CAP
3990876	SCREWHEX FLANGE HEAD CAP
3991108	SUPPORTFUEL PUMP
3991306	SCREWHEX FLANGE HEAD CAP
3992090	GASKETCONNECTION
3992092	GASKETCONNECTION
4002006	SCREWBANJO CONNECTOR
4009781	TUBEFUEL SUPPLY
4010051	SENSORTEMPERATURE
4010084	ADAPTERPOSITION SENSOR
4010174	TUBEFUEL DRAIN
4010374	SEALFERRULE
4010636	SEALMISC FUEL PUMP
4022547	NUTREGULAR HEXAGON
4061755	HUBACCESSORY DRIVE
4076375	WASHERSEALING
4954905	SENSOR,TEMPERATURE
4089958	SETUPPER ENGINE GASKET
4902720	SENSOR,PRESSURE
4921497	SENSOR,PRESSURE
4921574	SEAL, O RING
4921597	SENSOR,POSITION
4921732	TAPPET,PUMP
4930594	THERMOSTAT

3678924	PLUG, THREADED
3089239	PLUG, THREADED
3533135	ACTUATOR, TURBOCHARGER
3944159	BEARING, MAIN
3944164	BEARINGCRANKSHAFT THRUST
3944154	BEARING, MAIN
3944160	BEARING, MAIN
3944155	BEARING, MAIN
3944161	BEARING, MAIN
3944156	BEARING, MAIN
3944162	BEARING, MAIN
3944157	BEARING, MAIN
3965146	PULLEY, ALTERNATOR
3942895	SUPPORT, FAN
3934278	VALVE, BYPASS
3533328	BRACKETACTUATOR
3938077	NUT, LOCK
3926789	RING, COMPRESSION PISTON
3920405	TOOL, SEAL INSTALLATION
3925530	SEAL, OIL
3927871	SEAL, OIL
3911699	COVER, REAR
3974324	COVER, LUB OIL COOLER
3970852	ROD, ENGINE CONNECTING
3527089	SHIM
3528179	LEVER, CONTROL LINKAGE
3931342	DATAPLATE
4937942	DECAL
3408346	SENSOR, TEMPERATURE
4921598	SENSOR, POSITION
3609867	DATAPLATE
4088750	SENSOR, TEMPERATURE
3882589	SEAL, O RING
3968283	CAP, FILLER
3937367	GASKET, CORROSION RESISTOR
3971383	BLOCK, CYLINDER
3971382	BLOCK, CYLINDER
3939958	ADAPTER, HYDRAULIC PUMP
3972735	ALTERNATOR
3945066	FILTER, FUEL
3944987	HEAD, FUEL FILTER
3944269	FILTER, FUEL
3944270	SENSOR, WATER
3944892	DECAL
3329797	SPRING, COMPRESSION

3330448	RETAINER, SPRING
3348453	SCREW, HEXAGON HEAD CAP
3417168	RESISTOR
4001966	VALVE, SOLENOID
4001995	BARREL & PLUNGER
4009865	VALVE, FUEL CONTROL
4010317	NUT, REGULAR HEXAGON JAM
4062265	GASKET, CONTROL VALVE BODY
4076435	PLATE, CNT VALVE GASKET
4076870	ACCUMULATOR
4076877	GEAR, FUEL PUMP
4088001	DISTRIBUTOR, FUEL
4088604	BODY, FUEL PUMP
4088733	BARREL, RETAINER
4984579	SENSOR, PRESSURE
3165166	PIN, GUIDE
3100516	UNION, MALE
4935006	PUMP, FUEL TRANSFER
S102C	SCREW, HEXAGON HEAD CAP
3943650	VALVE, CHECK
3964385	GASKET, FUEL PUMP
3964382	PUMP, FUEL TRANSFER
3964387	BRACKET, TRANSFER PUMP
3959437	FLYWHEEL
3920327	PLUG, THREADED
3991502	MODULE, ELECTRONIC CONTROL
3949089	CAMSHAFT
3943367	PISTON, ENGINE
3942588	VALVE, INTAKE
3800341	VALVE, EXHAUST
3944711	SPRING, VALVE
3945022	HEAD, CYLINDER
3945021	HEAD, CYLINDER
3942645	GUIDE, VALVE STEM
3944700	TUBE, INJECTOR FUEL SUPPLY
3944701	TUBE, INJECTOR FUEL SUPPLY
3948530	INJECTOR
4040246	TURBOCHARGER
4040244	TURBOCHARGER
4036082	SHAFT, TURBOCHARGER
3528101	PLATE, CLAMPING
3528213	DIAPHRAGM
3529983	PISTON, TUR ACTUATOR
3527438	PISTON, TUR ACTUATOR
3527439	WASHER, PLAIN

3529986	SHAFT, ACTUATOR
3529985	HOUSING, ACTUATOR
3532306	GUIDE, ACTUATOR SHAFT
3532304	GUIDE, ACTUATOR SHAFT
3532305	GUIDE, ACTUATOR SHAFT
3590499	COVER, ACTUATOR
3527437	COUPLING, PLAIN HOSE
3590498	COVER, ACTUATOR
3592686	SPRING, COMPRESSION
3537111	HOUSING, TUR BEARING
3539743	HOUSING, TURBINE
3527092	LEVER, CONTROL LINKAGE
3528178	PIN, PIVOT
3529675	BUSHING
3529676	VALVE, WASTEGATE
3527094	VALVE, WASTEGATE
3527131	WASHER, PLAIN
3529677	LEVER, WASTEGATE VALVE
3527095	LEVER, WASTEGATE VALVE
3529678	SHAFT, PIVOT
3537974	HOUSING, TURBINE
3598995	HOUSING, COMPRESSOR
4035380	IMPELLERTUR COMPRESSOR
3964714	LEVER, ROCKER
3939309	ISOLATOR, NOISE
3945110	HEAD, CORROSION RESISTOR
3943738	HEAD, CORROSION RESISTOR
3943739	SHAFT, SHUTOFF VALVE
3944454	SCREW, SELF TAPPING METAL
3991176	HARNESS, ETR CNT MDL WRG