



Ben Liu  
 Mobile/ WeChat: +86-13705041170  
 FUZHOU SUNSHINE MACHINERY CO.,LTD  
 NO.6 Gulouyuan, Juyuanzhou Industrial Zone,  
 Jinshan Development Area, Fuzhou, Fujian, China.  
 Email: sales@primepowergenset.com  
<http://www.gensetengine.com>

### Cummins LTA10 engine Spare parts catalog

Part number	Description
3103445	RING,OIL PISTON
3037536	PLUG,THREADED
4026171	GASKET,FUEL PUMP
BM76340	DAMPER,FUEL CONTROL
4070529	
118346	UNIONMALE
3032872	UNION, MALE
2863701	SEALO RING
193736	SEAL,INJECTOR O RING
3008706	SCREENINJECTOR FILTER
101322	CAPFILLER
3076489	THERMOSTAT
186780	SEALTHERMOSTAT
3046200	SPIDER,JAW COUPLING
S171A	
S189C	SCREW,SOCKET HEAD CAP
S212	NUT,REGULAR HEXAGON
S217	NUT,HEAVY HEXAGON
S251	
S300	
S600	WASHER,LOCK
S602	Washer, Plain
S610	WASHER,LOCK
S626	WASHER
103426	GASKETAIR COMPRESSOR
107460	CLIP
107695	PINROLL
108330	WASHER,PLAIN
108518	SPACERMOUNTING
109557	WASHERPLAIN
109895	BRACKETOIL TUBE

112302	RINGRETAINING
119810	PINPISTON
127316	WASHERPLAIN
127936	SEALRECTANGULAR RING
127940	VALVECOMPRESSOR EXHAUST
128080	SPRINGCOMPRESSION
128086	SEALO RING
129768	SPRINGVALVE
129826	BODYSHUTOFF VALVE
129838	KNOB
129839	COVER,SHUTOFF VALVE
129866	UNIONMALE
129886	BODYFUEL SHUTOFF VALVE
129888	SEALRECTANGULAR RING
134963	SCREWHEXAGON HEAD CAP
142207	DOWELPIN
142784	HED,FIL
144044	HOSEPLAIN
144948	VALVECOMPRESSOR INTAKE
145028	SEATCPR INTAKE VALVE
145504	SEALO RING
145527	SEALO RING
145563	SEALO RING
147389	SCREWHEXAGON HEAD CAP
147610	BUSHING
148555	DOWELPIN
154087	SEAL,RECTANGULAR RING
154916	GASKET,HYDRAULIC PUMP
167157	BALLCHECK
168306	SCREW,SLOTTED SET
170664	WASHERPLAIN
173086	GASKET,INJECTOR
174299	RETAINERINJECTOR FIL SCN
179063	PLUGRETAINER
179901	VALVESHUTOFF
179904	CLAMPHOSE
179912	HOSEPLAIN
181213	ELBOW, PLAIN ADAPTER
181466	WASHER,LOCK
3069102	GASKETAIR COMPRESSOR
185138	RETAINERINJECTOR CUP
199349	SLEEVE, SPLINE COUPLING
S1040A	ELBOW,MALE ADAPTER
3028325	VALVECHECK
203426	PIN,INJECTOR ROLL

203760	WASHER,PLAIN
203850	UNIONMALE
203862	TEEMALE BRANCH
204048	PLATECOVER
206326	SCREW,TWELVE POINT CAP
3047440	COMPRESSOR1 CYL AIR
208084	RIVET
66292	WASHERPLAIN
67684	WASHER,PLAIN
67946	WASHER,PLAIN
68152	CLIP
69324	WASHERPLAIN
69793	SCREWHEXAGON HEAD CAP
69901	PLUGPIPE
70470	ELBOWPLAIN STREET PIPE
70550	DOWELPIN
70704	WASHER PLAIN
217008	SPACERBEARING
217011	SPACERBEARING
3000173	SCREWHEXAGON HEAD CAP
3000174	HUBSPLINE COUPLING
3000266	SHAFT,SHUTOFF VALVE
3001280	RING
3001281	BEARINGROLLER
3003163	WASHERPLAIN
3007025	CLAMPTUBE
3007632	PLUGEXPANSION
3007635	PLUGEXPANSION
3008446	DOWELPIN
3008465	PLUGPIPE
3008466	PLUGPIPE
3008468	PLUGPIPE
3008469	PLUGPIPE
3008470	PLUGPIPE
3008690	CLAMPHOSE
3009329	WASHERPLAIN
3009330	WASHERPLAIN
3009887	SCREWHEXAGON HEAD CAP
3009953	KEYPLAIN WOODRUFF
3010146	SPRINGCOMPRESSION
3012472	SCREWCAPTIVE WASHER CAP
3013786	PLUGPIPE
3014754	WASHERPLAIN
3014755	DISCVALVE
3014756	SPRINGCOMPRESSION

3016652	RINGRETAINING
3016760	BEARING,CON ROD (STD)
3016770	BEARINGMAIN STD
3016780	BEARINGMAIN STD
3018006	SCREWHEXAGON HEAD CAP
3018671	SCREWHEXAGON HEAD CAP
3019630	PLUGDRIVE
3020523	COVERGOVERNOR DRIVE
3021470	SCREWCAPTIVE WASHER CAP
3021977	COVERSPRING PACK
3022148	SCREWHEXAGON HEAD CAP
3025295	COVERCAMSHAFT
3025296	GASKET,CAMSHAFT COVER
3025322	ADAPTERSPLINE
3025458	PLUGPIPE
3026134	GASKETCOVER PLATE
3026135	COVERACCESS HOLE
3026166	SHAFTIDLER
3026167	SHAFTIDLER
3026231	DOWELRING
3026233	RETAINERGEAR
3026758	SEATPRS REGULATOR VALVE
3026806	CLAMPHOSE
3027106	DOWELRING
3027108	SCREWCONNECTING ROD CAP
3027924	GASKETCONNECTION
3028068	CUPINJECTOR CONE SAC
3028309	BEARINGTHRUST
3028384	PLATECOVER
3028684	COVERHAND HOLE
3030274	COVERFUEL PUMP
3030970	DISCVALVE
3031007	GASKETSTARTER
3031511	PLUGPIPE
3033024	ELBOWMALE UNION
3034243	PUMPGEAR FUEL
3034319	NUTREGULAR HEXAGON
3034320	WASHERPLAIN
3034836	SCREWHEXAGON HEAD CAP
3035177	WASHERPLAIN
3035228	SEALO RING
3035342	SOLENOIDFUEL PUMP
3036230	SCREWHEXAGON HEAD CAP
3037537	SEAL,O RING
3038996	GEARIDLER

3040245	SCREWHEXAGON HEAD CAP
3040815	PLUGTHREADED
3040817	SEALO RING
3041042	GEARACCESSORY DRIVE
3042401	SEALGROMMET
3042542	SEAL,O RING
3042619	NIPPLECOUPLING
3044360	NUTREGULAR HEXAGON
3046201	SEALO RING
3046202	PLUG,THREADED
3046206	PULLEYFAN
3047188	SEAL,RECTANGULAR RING
3049996	BARREL&PLUNGERPTD
153964	COVER1 CYL COMPRESSOR
154018	GASKETAIR COMPRESSOR
160586	RINGRETAINING
163654	SEALO RING
187350	RINGCOMPRESSION PISTON
187556	SCREWCAPTIVE WASHER CAP
190334	SPRINGVALVE
191037	CAPUNLOADER VALVE
203131	NUTHEAVY HEXAGON
204163	HEADCORROSION RESISTOR
206741	PLUGEXPANSION
210025	BUSHING
211662	BEARINGTHRUST
3004242	GSK,PMP
3007759	SEALO RING
3009219	NUTREGULAR HEXAGON JAM
3009317	SCREWTWELVE POINT CAP
3009362	NUTLOCK
3009376	BUSHING
3010518	CLAMPHOSE
3012529	PLUNGERPRS REGULATOR
3014341	CONNECTORMALE
3016761	BEARINGCON ROD 010
3016762	BEARINGCON ROD 020
3016763	BEARINGCON ROD 030
3016764	BEARINGCON ROD 040
3016771	BEARINGMAIN 010
3016772	BEARINGMAIN 020
3016773	BEARINGMAIN 030
3016774	BEARINGMAIN 040
3016781	BEARINGMAIN 010
3016782	BEARINGMAIN 020

3016783	BEARINGMAIN 030
3016784	BEARINGMAIN 040
3018037	PLATECOVER
3018151	ROD1 CYL CPR CON
3018153	BUSHING
3018772	SCREWJECTOR STOP
3019600	SEALOIL
3019733	BUSHING
3020092	SCREWHEXAGON HEAD CAP
3023101	SPRINGCOMPRESSION
3024471	GASKETFILTER HEAD
3025123	GEAR & SHAFTLUB OIL PUMP
3025124	GEAR + SHAFTLUB OIL PUMP
3025130	GASKETLUB OIL PUMP COVER
3025354	BEARINGNEEDLE
3025801	SCREWHEXAGON HEAD CAP
3026156	WASHERPLAIN
3026188	BUSHING
3026189	BUSHING
3026961	CAP,MAIN BEARING
3027278	GASKETCOVER PLATE
3027445	GASKETHEATER HOUSING
3027675	SEALOIL
3027676	SHAFTFAN HUB
3027677	FLANGE
3027680	SEALOIL
3027681	BEARINGROLLER
3027686	WASHERPLAIN
3027718	GASKETFAN CLUTCH COVER
3028065	LINKINJECTOR PLUNGER
3028066	ADAPTERINJECTOR
3028196	GASKETCONNECTION
3028252	PINROLL
3028295	SEALRECTANGULAR RING
3028346	CLAMPINJECTOR
3028367	SCREWHEXAGON HEAD CAP
3028422	GEARHYDRAULIC PUMP
3031921	STUD
3032787	SEALO RING
3032850	SEALO RING
3033073	RINGRETAINING
3033230	GUIDEVALVE SPRING
3033231	RETAINERVERVALVE SPRING
3033232	SPRINGVALVE
3033233	SPRINGVALVE

3033247	SEALO RING
3033248	SEALO RING
3033292	SOCKETTAPPET
3034172	BUSHING
3034855	GASKETROCKER LEVER COVER
3035679	IMPELLERWATER PUMP
3037597	HUBFAN
3038081	PLUGPIPE
3038984	GEARCRANKSHAFT
3038986	GEARIDLER
3038988	GEARIDLER
3038991	GEARWATER PUMP
3038992	GEARLUB OIL PUMPING
3039398	SCREWHEXAGON HEAD CAP
3040810	
3040816	PLG,THD
3040995	PLUGTHREADED
3041043	SHAFTACCESSORY DRIVE
3041048	SHAFTACCESSORY DRIVE
3042787	FLYWHEEL
3043995	SEALO RING
3044475	GASKETTHM HOUSING COVER
3045047	PLUG, INJECTOR ORIFICE
3045666	SPA,FAN
3046298	BODYUNLOADING VALVE
3046943	SEAL O RING
3047134	TUBEBREATHER
3047159	GASKET,AIR COMPRESSOR
3049145	ADAPTERPROBE
3049995	RETAINERINJECTOR SPRING
3052198	SCREWSLW TAPPING METAL
3052826	COVERWATER PUMP
3055069	PLUG,THREADED
3058148	GASKETGEAR COVER
3059603	ASSEMBLY, AFC
3060538	GASKETSUPPORT
3060883	PULLEYIDLER
3060884	PLATECOVER
3062104	SPRINGCOMPRESSION
3062601	SEALO RING
3062602	PULLEYIDLER
3062607	HOUSINGROCKER LEVER
3063779	PLUGTHREADED
3063844	COVERFAN HUB
3065151	GEARFLYWHEEL RING

3065358	HUBFAN
3070393	SCREWHEX FLANGE HEAD CAP
3070486	SLEEVEINJECTOR
3071085	SEALWATER PUMP
3072818	COVERACCESSORY DRIVE
3072919	GASKETTURBOCHARGER
3077273	DATAPLATE
3803703	KIT,LINER
3084899	BEARING,THRUST
3161653	BRG,THR
3201386	GASKETAIR COMPRESSOR
3201659	SEALRECTANGULAR RING
3250869	ENDADJUSTING LINK
3251296	NUTREGULAR HEXAGON
3251297	NUTREGULAR HEXAGON JAM
3251321	ADAPTERFILTER HEAD
3251480	TUBEFUEL DRAIN
3251482	TUBEFUEL SUPPLY
3251520	BRACKETCHECK VALVE
3251659	NUTREGULAR HEXAGON
3251767	SCREWHEXAGON HEAD CAP
3251776	BRACKETLIFTING
3252062	BRACKETLIFTING
3252107	PULLEYACCESSORY DRIVE
3252188	LINKADJUSTING
3253236	TUBECORROSION RESISTOR
3253237	TUBECORROSION RESISTOR
3253305	TUBEAFTERCOOLER
3253312	HOSEFLEXIBLE
3253408	CONNECTORFEMALE
3253765	TUBEFUEL DRAIN
3254104	BRACKETALTERNATOR
3254197	SPACERMOUNTING
3254781	LEVERTHROTTLE
3275354	COLLETVALVE
3276261	PULLEYALTERNATOR
3279505	INJECTORTOP-STOP
3279546	
3279794	SEALINJECTOR O RING
FS1212	FIL,FUL
3318853	OIL FILTER
3328328	WASHERPLAIN
3328760	GASKETCARRIER
3328948	GASKETEXHAUST MANIFOLD
3335042	SCR,CAP



3335044	SCREWHEXAGON HEAD CAP
2840780	PLATECLAMPING
3502231	SLINGEROIL
3503347	SCREWFLAT HEAD CAP
3503668	BAFFLEOIL
3504413	BEARINGTURBOCHARGER
3519163	SCREWDRIVE
3519762	GASKETTURBOCHARGER
3522773	WHEELTURBOCHARGER H2
3522952	HOUSINGTURBINE H2
3523227	PLATECLAMPING
3523542	COLLARTHRUST
3523613	BEARINGTUR THRUST
3524262	SCREWSOCKET HEAD CAP
3524808	IMPELLERTURBO H2
3525003	HOUSINGCOMPRESSOR H2
3525199	HOUSINGTUR BEARING
3545576	KITTUR REPAIR
3545653	KITTUR REPAIR
3558735	SCREWDRIVE
3558754	RINGRETAINING
3558761	SCREWHEXAGON HEAD CAP
3558954	CRANKCASE1 CYL CPR
3600467	GASKETCARRIER
3600468	GASKETCARRIER
3600880	COOLEROIL
3600925	GASKETGEAR COVER PLATE
3610503	SCREWSOCKET HEAD CAP
3709753	RINGRETAINING
3755843	GASKETTURBOCHARGER
3756754	SEALSPLIT RING
3758848	SEALSPLIT RING
3759917	SCREWHEXAGON HEAD SET
3760250	NUTLOCK
3762449	RINGRETAINING
3762564	PLATEOIL SEAL
3762915	SEALO RING
3800477	KITCYLINDER
3800478	KITOVERHAUL
3801356	VALVEINTAKE
3801801	AFTERCOOLER
3801888	STUD
3803495	KITPST COOLING NOZZLE
3803580	TURBOH2D
3803582RX	TURBO, H2E

3803930	KITCOMPRESSOR PISTON
3803961	SETPISTON RING
3803965	KITENGINE PISTON
3804304	KITSEAL
3818060	SCREWCAPTIVE WASHER CAP
3818121	SCREW,HEX FLANGE HEAD CAP
3818122	SCREWHEX FLANGE HEAD CAP
3818124	SPACERMOUNTING
3818125	SPACERMOUNTING
3818127	PLATECLAMPING
3818150	ADAPTERPLAIN
3818151	NUTHEAVY HEXAGON JAM
3818229	SCREWHEXAGON HEAD CAP
3818418	HOUSINGTHERMOSTAT
3818463	WASHERPLAIN
3818599	SCREWCAPTIVE WASHER CAP
3818686	COVERLUB OIL PUMP
3818823	STUD
3818824	NUTREGULAR HEXAGON
3818841	GASKETTHERMOSTAT HOUSING
3818843	GASKETINT MANIFOLD COVER
3818844	GASKETCONNECTION
3818846	GASKETCONNECTION
3818847	GASKETHYDRAULIC PUMP
3818885	SEAL,O RING
3818925	COVERROCKER LEVER
3819294	SUPPORTTTHM HOUSING
3819407	PULLEYCRANKSHAFT
3819448	SCREWCAPTIVE WASHER CAP
3819470	TUBECOMPRESSOR AIR INLET
3819521	SCREWHEX FLANGE HEAD CAP
3819624	CRANKSHAFTENGINE
3819632	SHAFTWATER PUMP
3819638	ADAPTERHYDRAULIC PUMP
3819720	UNIONMALE
3819721	ELBOWMALE ADAPTER
3819724	SEALRECTANGULAR RING
3819725	CLAMPHOSE
3819774	SLEEVEWEAR
3819822	SLEEVE
3819871	SEALO RING
3819900	GASKETTURBOCHARGER
3819920	SHAFTIDLER
3819976	DAMPER,VISCOUS VIBRATION
3820047	BRACETUBE

3820091	CONNECTORFEMALE
3820186	SCREWCAPTIVE WASHER CAP
3820205	SCREWHEX FLANGE HEAD CAP
3820316	SCREWHEXAGON HEAD CAP
3820317	SCREWHEXAGON HEAD CAP
3820320	PLUNGERBYPASS VALVE
3820336	SCREWTWELVE POINT CAP
3820510	TUBEWATER OUTLET
2878168	BUSHING
3820586	TUBEFUEL DRAIN
3820629	GASKETFILTER HEAD
3820631	RINGRETAINING
3820665	HOSEPLAIN
3820666	HOSEPLAIN
3820667	HOSE,PLAIN
3820749	INSERTTHREADED
3820754	SUPPORTHYDRAULIC PUMP
3820782	RINGRETAINING
3820791	SEALO RING
3820831	SCREWSQUARE HEAD SET
3820872	GASKETCOVER PLATE
3820918	SLEEVEWEAR
3820922	GSK,CPR
3820945	SEALRECTANGULAR RING
3820946	SEALRECTANGULAR RING
3820959	CONNECTIONAIR CPR INLET
3820988	SCREWHEXAGON HEAD CAP
3820989	SCREWHEXAGON HEAD CAP
3821534	TUBEAIR FUEL CONTROL
3821556	CLIP
3821643	CONNECTIONAIR INTAKE
3821657	WASHERPLAIN
3821676	SCR,CAP
3821695	AFT
3821718	TUBEWATER TRANSFER
3821725	PLUGRETAINER
3821783	SCREWCAPTIVE WASHER CAP
3822067	SCREWCAPTIVE WASHER CAP
3882433	GASKETOIL PAN
3882513	SPACERMOUNTING
3882528	RETAINER,GEAR
3882536	GASKETCONNECTION
3882585	PLUGEXPANSION
3882586	SPRINGCOMPRESSION
3882675	PLATECLAMPING

3882885	WSH,PLA
3882893	TAPE
3882922	SCREWTWELVE POINT CAP
3883036	TUBELUB OIL TRANSFER
3883122	SCREWHEX FLANGE HEAD CAP
3883123	SCREWHEX FLANGE HEAD CAP
3883171	LEVERROCKER
3883217	SCREWTWELVE POINT CAP
3883223	ISOLATORNOISE
3883365	GASKETBEARING SUPPORT
3883407	SEALEXHAUST MANIFOLD
3883472	GSK,HOL
3883510	SEALRECTANGULAR RING
3892095	SEALO RING
3892099	CLIP
3892321	SUPPORTFAN
3892354	SCREWHEXAGON HEAD CAP
3892625	GASKETOIL COOLER SUPPORT
3893690	GASKETHEATER HOUSING
3893752	RINGCOMPRESSION PISTON
3893754	RINGOIL PISTON
3893834	SCREWHEXAGON HEAD CAP
3893850	BRACEFUEL PUMP
3893968	TUBEAFTERCOOLER
3895734	CLAMPHOSE
3895833	SFT,FOL
3896335	SUPPORTCAMSHAFT THRUST
3896837	SEALDUST
3899413	RINGCOMPRESSION PISTON
3900619	SCREWHEXAGON HEAD CAP
3903112	SCREWHEX FLANGE HEAD CAP
3937706	GASKET,OIL DRAIN
4022907	SCREWHEX FLANGE HEAD CAP
4025155	SETUPPER ENGINE GASKET
4070462	SCREWHEXAGON HEAD CAP
4070463	SCREWHEX FLANGE HEAD CAP
4083243	PINPISTON
3059408	THERMOSTAT (3059408)
4970037	HOSE,PLAIN
650330	RINGCOMPRESSION PISTON
68368A	SPACERMOUNTING
70168	NUTLOCK
70275	NUTLOCK
9674D	SPACERMOUNTING
S1097	

S112	SCREW,HEXAGON HEAD CAP
S119	SCREW,HEXAGON HEAD CAP
S126	Screw, Hexagon Head Cap
S159B	
S16002	BEARING, BALL
3518004	WASHER, LOCK
3040809	PLUG, THREADED
3525562	DATAPLATE
3892794	SEAL, OIL
3801279	CAP, MAIN BEARING
3027490	CAP, MAIN BEARING
3027493	SCREW, HEXAGON HEAD CAP
3821160	LEVER, CAM FOLLOWER
3038995	GEAR, IDLER
S1005A	ELBOW, MALE ADAPTER
3883042	SEAL, O RING
S3193	PIN, GROOVE
3883659	GASKET, CARRIER
3893964	SEAL, RECTANGULAR STRIP
4025151	KIT, STRIP SEAL
3045850	SCREW, HEX FLANGE HEAD CAP
3820750	SHAFT, ROCKER LEVER
3899229	GASKET, WATER HEADER COVER
3882615	BODY, WATER PUMP
S167A	SCREW, HEXAGON HEAD CAP
3027151	NAMEPLATE
3027935	DECAL
WF2075	WF PKG
S684	WASHER, PLAIN
3818845	GASKET, HAND HOLE
3027436	GASKET, SUPPORT
3819751	SEAL, O RING
3819452	GASKET, WATER HEADER COVER
3819623	GASKET, OIL COOLER SUPPORT
3801624	KIT, OIL SEAL
3049464	SEAL, OIL
3801625	KIT, OIL SEAL
3049465	SEAL, OIL
3600471	GASKET, CARRIER
3801627	KIT, OIL SEAL
3049467	SEAL, OIL
3803354	KIT, OIL SEAL
3883774	SEAL, OIL
3022176	LEVER, RKR EXH TRANSFER
3041062	LEVER, ROCKER

3022177	LEVER, RKR EXH TRANSFER
3041060	LEVER, ROCKER
3022178	LEVER, RKR INT TRANSFER
3019731	LEVER, ROCKER
3022179	LEVER, RKR INT TRANSFER
3019732	LEVER, ROCKER
3896643	LEVER, ROCKER
3033225	BUSHING
3820151	ROD, PUSH
3820152	ROD, PUSH
3058113	SUPPORT, ROCKER LEVER
3883102	GASKET, RKR LEVER HOUSING
3058111	SUPPORT, ROCKER LEVER
3058112	SUPPORT, ROCKER LEVER
3821846	SCREW, CAPTIVE WASHER CAP
3034791	CROSSHEAD, TLA
3033226	CROSSHEAD, VALVE
3819566	CROSSHEAD, VALVE
3821162	LEVER, CAM FOLLOWER
3028105	PIN, CAM FOLLOWER ROLLER
3038178	ROLLER, CAM FOLLOWER
3821163	LEVER, CAM FOLLOWER
3821161	LEVER, CAM FOLLOWER
3028106	PIN, CAM FOLLOWER ROLLER
3038179	ROLLER, CAM FOLLOWER
3803724	SHAFT AND PLUG
3031920	SUPPORT, CAM FOL SHAFT
3031918	SUPPORT, CAM FOL SHAFT
3031919	SUPPORT, CAM FOL SHAFT
3818859	SUPPORT, CAM FOL SHAFT
3882992	ASSEMBLY, CYLINDER BLOCK
3820391	BLOCK, CYLINDER
3803297	KIT LINER
3064627	LINER, CYLINDER
3038985	GEAR, IDLER
3041038	PLATE, THRUST BEARING WEAR
3038987	GEAR, IDLER
3883273	HOUSING, GEAR
3883267	HOUSING, GEAR
3819634	BEARING, NEEDLE
3801150	SET, MAIN BEARING
3801151	SET, MAIN BEARING
3801152	SET, MAIN BEARING
3801153	SET, MAIN BEARING
3801154	SET, MAIN BEARING .040

3161654	BEARING, THRUST
3071032	NOZZLE, PISTON COOLING
3819496	COVER, GEAR
3882684	SEAL, RECTANGULAR STRIP
3819635	SEAL, OIL
3803274	SEAL, OIL
3819640	SEAL, OIL
3882451	GASKET, CARRIER
3803272	SEAL, OIL
3819631	SEAL, OIL
3820036	GASKET, CARRIER
3820264	PLUG, GEAR COVER
3892083	GASKET, CARRIER
3892085	RING, CLAMPING
3803489	KIT, OIL SEAL
3892795	SEAL, OIL
3892081	GASKET, CARRIER
3892086	RING, CLAMPING
3820193	ELBOW, MALE UNION
3819292	BRACE, TUBE
AX801220SL	HOSE, FLEXIBLE
119859	RING, RETAINING
3000167	CRANKSHAFT, COMPRESSOR
3005152	SUPPORT, AIR COMPRESSOR
3011891	ROD, COMPRESSOR CONNECTING
3043945	SEAT, CPR EXHAUST VALVE
3045670	PISTON, COMPRESSOR
3558853	CRANKCASE, COMPRESSOR
3558703	HEAD, COMPRESSOR
3058407	NAMEPLATE
AR73350	RING, COMPRESSOR, PISTON
3038993	GEAR, HYDRAULIC PUMP
3045776	SUPPORT, ACCESSORY DRIVE
3040314	BELT, V RIBBED
3017506	SCREW, HEXAGON HEAD CAP
3882603	BRACKET, SHIPPING
3882604	BRACKET, SHIPPING
3034942	BELT, V RIBBED
3892768	PULLEY, IDLER
S10041	ELBOW, PLAIN ADAPTER
3321617	ELEMENT, HEATING
3324385	SEAL, RECTANGULAR RING
3320955	SEAL, RECTANGULAR RING
3321569	SEAL, O RING
3321608	ADAPTER, FILTER HEAD

3321610	ADAPTER, FILTER HEAD
3882591	HOUSING, FLYWHEEL
3882590	HOUSING, FLYWHEEL
3801628	KIT, OIL SEAL
3049468	SEAL, OIL
3600469	GASKET, CARRIER
3054344	FUEL PUMP HOUSING
3054611	SOLENOID
3042786	FLYWHEEL
3265742	ASSEMBLY, LUB OIL FILTER
3820332	HEAD, LUB OIL FILTER
3020093	SCREW, HEXAGON HEAD CAP
3893935	ASSEMBLY, LUB OIL PUMP
3820882	PUMP, LUBRICATING OIL
3021050	GEAR, LUB OIL PUMPING
3025114	SHAFT, LUB OIL PUMP
3025113	SHAFT, LUB OIL PUMP
3882738	PAN, OIL TLA
3882725	PAN, OIL
3882733	GASKET, OIL PAN
3895679	CAMSHAFT
3073522	ASSEMBLY, CONNECTING ROD
3079629	ROD, CONNECTING
3892753	HEAD, CYLINDER
3055723	HEAD, CYLINDER
3820700	INSERT, VALVE
3073512	GUIDE, VALVE STEM
3033234	VALVE, INTAKE
3803348	VALVE, EXHAUST
3883287	VALVE, EXHAUST
3073509	SEAL, VALVE STEM
3073510	SEAL, VALVE STEM
3045849	SCREW, HEX FLANGE HEAD CAP
3893927	GASKET, CYLINDER HEAD
3028272	SCREW, TWELVE POINT CAP
3044448	PISTON, ENGINE
3049997	PLUNGER, INJECTOR
3202185	BARREL, INJECTOR
3038989	GEAR, CAMSHAFT
3526400	TURBOCHARGER
3503348	SHIELD, HEAT
3819378	GASKET, TURBOCHARGER
P21056	CHARCOAL GREY, HIGH GLOSS
3821833	MANIFOLD, EXHAUST
3883409	MANIFOLD, EXHAUST



3819760	GASKET, EXHAUST MANIFOLD
200844	CLAMP, T BOLT
3025152	HOSE, PLAIN
3034860	HOUSING, THERMOSTAT
3022502	SCREW, HEXAGON HEAD CAP
3335045	SCREW, HEXAGON HEAD CAP
3882443	TUBE, TURBO OIL DRAIN
3820359	HOSE, FLEXIBLE
UP1198	UPRATE FOR CPL1198
3402819RX	KIT, RECON COMPONENTS
3411462RX	INJECTOR
3896288RX	HEAD, CYLINDER
3804843	SET, UPPER ENGINE GASKET
FXD78RX	PUMP, FUEL
FXD80RX	PUMP, FUEL
FXY20RX	PUMP, FUEL
FXY22RX	PUMP, FUEL
3045095	COVER, ROCKER LEVER HSG
3253159	BRACKET, FILTER
3819782	PLATE, WATER HEADER
3819626	PLATE, WATER HEADER
3803403	ASSEMBLY, WATER PUMP