



Ben Liu

Mobile/ WeChat: +86-13705041170

FUZHOU SUNSHINE MACHINERY CO.,LTD

NO.6 Gulouyuan, Juyuanzhou Industrial Zone,  
Jinshan Development Area, Fuzhou, Fujian, China.

Email: sales@primepowergenset.com

<http://www.gensetengine.com>

## Cummins 6CT8.3 engine Spare parts catalog

Part number	Description
5404408	KITLINER
5266243	ROD,ENGINE CONNECTING
3934486	KITSEAL
4988747	PUMP,FUEL TRANSFER
3963983	WASHERSEALING
101322	CAPFILLER
S923E	DRAINCOCK
118227	DOWELFUEL PUMP
145530	SEALO RING
3004258	PLUG,EXPANSION
3926854	PULLEYFAN
181461	GOVERNORAIR COMPRESSOR
3900625	SCREWHEX FLANGE HEAD CAP
3902332	KEYPLAIN WOODRUFF
3902425	WASHERSEALING
3902468	CAPFILLER
3905194	RODPUSH
3906733	SCREWHEX FLANGE HEAD CAP
3907308	GEARFLYWHEEL RING
3909886	SEALINJECTOR
3910739	BEARINGBALL
3912900	PLUGEXPANSION
3916369	SCREWHEX FLANGE HEAD CAP
3919435	SHAFTROCKER LEVER
3919677	MANIFOLD OIL
3920443	PLUGEXPANSION
3924386	CLAMPT BOLT
3924582	INSERTVALVE

3926842	CONNECTIONTUR OIL DRAIN
4891178	SUPPORTCAMSHAFT THRUST
3927692	NUTHEAVY HEXAGON
3928174	INSERTVALVE
3928870	BOLTCONNECTING ROD
3931379	GEARFUEL PUMP
3944153	BEARING,MAIN
3945918	SETMAIN BEARING 010
3945920	SETMAIN BEARING 030
3945967	PLUNGERPRS REGULATOR
201351	CLAMP,WIRE TIE
3282141	SCREWBANJO CONNECTOR
3802753	INJECTORBOSCH
3901617	SCREWTWELVE POINT CAP
3901693	CLAMPRETAINING
3901717	LEVERROCKER
3901969	PLUG,EXPANSION
3905870	SUPPORTROCKER LEVER
3911901	VALVECHECK
3911936	HOSEPLAIN
3918188	WASHERSEALING
3918777	GEARCAMSHAFT
3920692	RINGRETAINING
3920762	HOSEELBOW
3924726	VALVECHECK
3934864	NUTREGULAR HEXAGON
3991085	SPRINGVALVE
3289481	BELTV RIBBED
3923044	RETAINERFAN HUB
3928639	THERMOSTAT
3939352	GASKETOIL SUC CONNECTION
3938160	GASKETOIL PAN
3929012	GASKETEXHAUST MANIFOLD
3911941	GASKETTURBOCHARGER
3519807	GASKETTURBOCHARGER
3936993	GASKETINT MANIFOLD COVER
3905449	SEALROCKER LEVER
3927642	SEALVALVE STEM
3938267	GASKETCYLINDER HEAD
3934046	PINPISTON
3945917	SETMAIN BEARING STD
4025270	KITSEAL
3902089	SEALO RING
3918779	GASKETCONNECTION
3914310	GASKETTHERMOSTAT HOUSING

210753	CLAMPHOSE
68139	ELBOW,PLAIN ADAPTER
3007635	PLUGEXPANSION
3008400	GASKETHYDRAULIC PUMP
3008466	PLUGPIPE
3008468	PLUGPIPE
3008469	PLUGPIPE
3008470	PLUGPIPE
3037236	SEAL,O RING
3046201	SEALO RING
3052061	SCREWHEXAGON HEAD CAP
156075	PLUGEXPANSION
204995	ELBOWMALE ADAPTER
206963	INSERTFILTER HEAD
3008464	PLUGPIPE
3035960	RINGRETAINING
3045782	PLUGTHREADED
3101026	UNIONFEMALE ADAPTER
3200782	PLATE,COVER
3201562	SEALO RING
3281692	SCREWDRIVE
3282059	CLIP
3282266	PLUGTHREADED
3282372	STUD
3282942	BRACETUBE
3283233	ADAPTERPLAIN
3286623	BRACKETSOLENOID
3401544	ELM,FIL
3415691	ALTERNATOR
3503100	BEARINGTURBOCHARGER
3504967	WASHERPLAIN
3519163	SCREWDRIVE
3519302	SHIELDTURBOCHARGER HEAT
3522597	PINROLL
3522879	WHEELTURBOCHARGER H2
3527566	RINGRETAINING
3527619	DATAPLATE
3528010	CONNECTIONADAPTER
3528104	BAFFLEOIL
3528177	END, ADJUSTING LINK
3528221	RINGRETAINING
3528933	SEALO RING
3530556	SCREWHEXAGON HEAD SET
3530923	PLATEOIL SEAL
3530924	SLINGEROIL

3532195	SPACERMOUNTING
3532196	SPACERMOUNTING
3532217	COLLAR THRUST
3533163	RING RETAINING
3534291	SCREW HEXAGON HEAD SET
3534309	PLATE CLAMPING
3535243	GASKET CONNECTION
3535635	TURBOCHARGER HX40W
3535811	HOUSING COMPRESSOR
3537068	HOUSING TURBINE
3539209	SCREW HEXAGON HEAD SET
3592050	NUT HEXAGON FLANGE
3595651	BEARING TUR THRUST
3596402	NUT LOCK
3599592	IMPELLER TUR COMPRESSOR
3678606	SEAL, O RING
3756754	SEAL SPLIT RING
3758848	SEAL SPLIT RING
3759917	SCREW HEXAGON HEAD SET
3762259	RING RETAINING
3800558	SET LOWER ENGINE GASKET
3800974	PUMP WATER
3802085	VALVE EXHAUST
3802429	SET PISTON RING
3802651	TURBO HX40 WASTEGATE
3802657	KIT ENGINE PISTON
3818823	STUD
3818824	NUT REGULAR HEXAGON
3818885	SEAL, O RING
3900227	SCREW HEXAGON HEAD CAP
3900257	DOWEL PIN
3900269	WASHER PLAIN
3900589	NUT HEXAGON FLANGE
3900628	SCREW, HEX FLANGE HEAD CAP
3900630	SCREW HEX FLANGE HEAD CAP
3900631	SCREW HEX FLANGE HEAD CAP
3900633	SCREW HEX FLANGE HEAD CAP
3900677	SCREW HEXAGON HEAD CAP
3900955	PLUG EXPANSION
3901177	COLLET VALVE
3901249	SCREW HEX FLANGE HEAD CAP
3901395	SCREW HEXAGON HEAD CAP
3901430	BEARING
3901764	RING RETAINING
3901798	WASHER SEALING

3901846	DOWELPIN
3901865	SCREWHEX FLANGE HEAD CAP
3902112	SCREWHEX FLANGE HEAD CAP
3902116	SCREWHEX FLANGE HEAD CAP
3902451	SCREWHEX FLANGE HEAD CAP
3902460	SCREW,HEX FLANGE HEAD CAP
3902466	SEALRECTANGULAR RING
3902662	NUTHEXAGON FLANGE
3903035	SCREW,BANJO CONNECTOR
3903200	SCREWHEXAGON HEAD CAP
3903210	NUTHEXAGON FLANGE
3903293	NUTREGULAR HEXAGON
3903463	COVERACCESS HOLE
3903475	SEALRECTANGULAR RING
3903546	SEALO RING
3903924	PINTIMING
3903990	SCREWHEX FLANGE HEAD CAP
3904446	SCREWHEX FLANGE HEAD CAP
3904483	PINROLL
3904519	BRACETUBE
3904711	BRACETUBE
3904849	RINGRETAINING
3905155	RETAINERINJECTOR NOZZLE
3905216	CLAMPV BAND
3905401	PLUGEXPANSION
3905408	TUBEOIL FILLER
3905928	NOZZLEPISTON COOLING
3906100	WASHERSPRING
3906216	NUTHEXAGON FLANGE
3906440	BRACKETLIFTING
3906619	PLUGPIPE
3906694	SEALRECTANGULAR RING
3906695	SEALRECTANGULAR RING
3906715	SCREWHEX FLANGE HEAD CAP
3906742	TUBEAIR
3906766	HOUSINGFLYWHEEL
3907177	SEALRECTANGULAR RING
3907206	WASHERPLAIN
3907311	BUSHING
3907740	CLAMPSRING HOSE
3907741	CLIP
3907769	SCREWHEXAGON HEAD CAP
3907860	SCREWHEX FLANGE HEAD CAP
3907861	BRACKETLIFTING
3907998	SCREWROUND HEAD CAP

3908095	PLATECOVER
3908772	DIPSTICK
3909310	SCREWHEXAGON HEAD CAP
3909397	SEALO RING
3909552	CONNECTORMALE
3909582	SCREWHEXAGON HEAD CAP
3909669	TUBEBREATHER
3910129	SPACERFAN PILOT
3910248	PLUGO RING
3910260	SEALO RING
3910279	CLAMPINJECTOR
3910787	CONNECTIONOIL SUCTION
3910824	SEALO RING
3910960	WASHERPLAIN
3910994	CONNECTIONEXHAUST OUTLET
3911322	FANENGINE
3911446	SCREWBANJO CONNECTOR
3911924	HUB,FAN
3911925	COUPLINGPLAIN HOSE
3912072	SCREWHEXAGON HEAD CAP
3912473	SEALO RING
3913287	GASKETAIR COMPRESSOR
3913638	SCREWHEX FLANGE HEAD CAP
3913994	SEALO RING
3914095	SEALRECTANGULAR RING
3914308	GASKETLUB OIL CLR COVER
5271773	CLAMP,HOSE
3914708	LOCKPLATE
3915118	LISTCAV SERVICE PARTS
3915119	SPRINGCOMPRESSION
3915772	SEALRECTANGULAR RING
3915872	BRACEALTERNATOR
3916042	GASKETHYDRAULIC PUMP
3916051	HOSEFLEXIBLE
3916284	SEALO RING
3916361	SCREWBANJO CONNECTOR
3917320	CRANKSHAFT,6C
3917716	BRACETUBE
3917717	BRACETUBE
3917729	SCREWHEX FLANGE HEAD CAP
3917746	ISOLATORVIBRATION
3917747	ISOLATORVIBRATION
3917748	ISOLATORVIBRATION
3917779	GASKETGEAR COVER
3917780	GASKETGEAR COVER

3917892	GASKETCONNECTION
3917923	BRACEEXH OUT CONNECTION
3918002	SCREWBANJO CONNECTOR
3918113	SHIELDDUST
3918174	GASKETOIL COOLER CORE
3918176	HOSEPLAIN
3918190	WASHERSEALING
3918192	WASHER,SEALING
3918334	HEADLUB OIL FILTER
3918340	GASKETHYDRAULIC PUMP
3918521	CLAMPHOSE
3918539	TUBEFUEL SUPPLY
3918562	HOSEFLEXIBLE
3918616	HOSEPLAIN
3918776	GEARCRANKSHAFT
3919434	RIVET
3919624	PULLEYACCESSORY DRIVE
3919683	HOUSINGTIMING
3919687	CONNECTORFEMALE
3920400	SCREWHEX FLANGE HEAD CAP
3920408	
3920447	SCREWHEX FLANGE HEAD CAP
3920595	MANIFOLDFUEL
3920706	PLUGEXPANSION
3920773	WASHERSEALING
3920854	SCREWCAPTIVE WASHER CAP
3920855	SCREWCAPTIVE WASHER CAP
3921440	GASKETINT MANIFOLD COVER
3921556	CAPTUBE
3921594	PLUGTHREADED
3922072	PLUGEXPANSION
3922639	SCREWHEX FLANGE HEAD CAP
3922648	COVERINTAKE MANIFOLD
3923261	SEALINJECTOR
3923527	CLAMPHOSE
3923564	GUIDEVALVE STEM
3924147	PLUGTHREADED
3924148	PLUGTHREADED
3924389	WASHERSEALING
3924589	TUBEVENT
3924591	CONNECTIONWATER OUTLET
3924725	SCREWBANJO CONNECTOR
3925186	SCREWFLAT HEAD CAP
3925344	SCREWHEX FLANGE HEAD CAP
3925883	SCREWHEX FLANGE HEAD CAP

3925955	ADAPTERFILTER HEAD
3926049	HOSEPLAIN
3906081	KITSEAL
3926509	HOUSINGTHERMOSTAT
3926721	HOUSINGGEAR
3926846	SCREWHEX FLANGE HEAD CAP
3926847	COVERGEAR
3926863	SCREWHEX FLANGE HEAD CAP
3926865	SPACERMOUNTING
3926875	BRACKETBELT TENSIONER
3926881	PUMPINJECTION BOSCH
3927317	COUPLINGELBOW HOSE
3927611	BRACETUBE
3928031	NOZZLEPISTON COOLING
3928229	NOZZLEINJECTOR
3928624	SEALO RING
3928629	CONNECTIONTUR OIL DRAIN
3928989	CLIP
3929011	GASKETLUB OIL CLR COVER
3929418	SUPPORTALTERNATOR
3929537	SCREWHEXAGON HEAD CAP
3930234	SOLENOIDFUEL PUMP
3930442	TUBEINJECTOR FUEL SUPPLY
3930443	TUBEINJECTOR FUEL SUPPLY
3930444	TUBEINJECTOR FUEL SUPPLY
3930446	TUBEINJECTOR FUEL SUPPLY
3930447	TUBEINJECTOR FUEL SUPPLY
3930683	NUTLOCK
3930690	HOSEFLEXIBLE
3930789	TEESTREET PIPE
3930827	HOSEPLAIN
3930903	COVERVALVE
3930911	SEALO RING
3931084	PLUGTHREADED
3931356	TUBEINJECTOR FUEL SUPPLY
3931416	DATAPLATE
3932063	GASKET,EXHAUST MANIFOLD
3932180	MANIFOLDEXHAUST
3933359	CONNECTORBANJO
3933384	COVERREAR
3934054	SCREWHEX FLANGE HEAD CAP
3934410	VALVEBYPASS
3934473	TUBEAIR FUEL CONTROL
3935113	CONNECTIONVENT
3936027	GASKETCOVER PLATE



3936180	HEAD,CYLINDER
3936331	SEALRECTANGULAR RING
3936365	VALVEPRESSURE RELIEF
3936709	TUBEFUEL SUPPLY
3936813	BRACEAIR COMPRESSOR
3936841	TUBECOMPRESSOR AIR INLET
3937122	STUD
3937123	STUD
3937142	SEALINJECTOR
3937438	SCREWRKR LEVER ADJUSTING
3937613	CLAMPSRING HOSE
3937706	GASKET,OIL DRAIN
3938036	SCREWHEX FLANGE HEAD CAP
3938056	HOSEPLAIN
3939258	GASKETCOVER PLATE
3939353	GASKETREAR COVER
3939356	GASKETSTARTER
3939570	SCREWCAPTIVE WASHER CAP
5263529	SUPPORTFAN
3943520	CLAMPTUBE
3944158	BEARING,MAIN
3944163	BEARINGCRANKSHAFT THRUST
3944165	BEARINGCRANKSHAFT THRUST
3944166	BEARINGCRANKSHAFT THRUST
3944167	BEARINGCRANKSHAFT THRUST
3944168	BEARINGCRANKSHAFT THRUST
3944169	BEARINGCRANKSHAFT THRUST
3944516	GEARACCESSORY DRIVE
3945212	ELBOWPLAIN UNION
5283368	BUSHING
3945919	SETMAIN BEARING 020
3945921	SETMAIN BEARING 040
3960043	SCREW,HEX FLANGE HEAD CAP
3963988	WASHERSEALING
3966976	SCREWHEX FLANGE HEAD CAP
3967353	TAG, INSTRUCTION
3967952	TUBECPR WATER OUTLET
3968467	SCREWTWELVE POINT CAP
3969697	SEALO RING
3970407	HOSEPLAIN
3970655	SPRINGCOMPRESSION
3974815	CORECOOLER
3990881	SCREWBANJO CONNECTOR
3990903	SPACERMOUNTING
3991038	HOSEPLAIN

3991306	SCREWHEX FLANGE HEAD CAP
3991517	TUBEAIR FUEL CONTROL
3992092	GASKETCONNECTION
4022703	UNIONMALE
4022705	ELBOWMALE ADAPTER
4025271	SETUPPER ENGINE GASKET
4058964	RESISTOR,CORROSION
4089208	HEAD1 CYL COMPRESSOR
4089222	KITSEAL
4089240	KITAC GST/SAL 75MM SINGL
4089677	ADAPTERSPLINE
43828A	CLAMP,HOSE
68138	CONNECTOR,MALE
70622	CLIP
FF42000	Filter, Fuel
3930942	FUEL FILTER (3930942)
S1097	
3903380	SEAL, BANJO CONNECTOR
3278459	TAG, INSTRUCTION
3905860	SCREW, BANJO CONNECTOR
3936315	HEAD, FUEL FILTER
3936313	HEAD, FUEL FILTER
3284244	CONNECTOR, FEMALE
3358252	GASKETGEAR HOUSING
3278460	TAG, INSTRUCTION
3938737	GASKET, GEAR HOUSING
3934921	LEVER, ROCKER
3902588	INSERT, ROCKER LEVER
3926429	LEVER, ROCKER
3919433	SHAFT, ROCKER LEVER
3934906	BLOCK, CYLINDER
3934901	BLOCK, CYLINDER
3936058	CAP, MAIN BEARING
3944159	BEARING, MAIN
3944164	BEARINGCRANKSHAFT THRUST
3944154	BEARING, MAIN
3944160	BEARING, MAIN
3944155	BEARING, MAIN
3944161	BEARING, MAIN
3944156	BEARING, MAIN
3944162	BEARING, MAIN
3944157	BEARING, MAIN
3944170	BEARINGCRANKSHAFT THRUST
4022706	ELBOW, MALE UNION
4022704	UNION, MALE

3936837	TUBE, CPR WATER INLET
3101468	UNION, FEMALE ADAPTER
3969122	COMPRESSOR, AIR
3969123	COMPRESSOR, AIR
4089675	PLUGTHREADED
3922557	DAMPER, VIBRATION
3965146	PULLEY, ALTERNATOR
3937556	TENSIONER, BELT
3929237	SUPPORT, FRONT ENGINE
3942895	SUPPORT, FAN
3934888	TUBE, AIR FUEL CONTROL
3043556	PLUG, THREADED
3909411	SEAL, OIL
4944710	PUMP, FUEL TRANSFER
3907558	FLYWHEEL
3907310	FLYWHEEL
3930910	PLUG, THREADED
3974325	HEAD, LUB OIL FILTER
3931077	COVER, LUB OIL COOLER
3934278	VALVE, BYPASS
3279104	TUBE, OIL GAUGE
3802278	KIT, LUBE PUMP
3948071	PUMP, LUBRICATING OIL
3924471	CAMSHAFT
3914013	PAN, OIL
3928228	INJECTOR
3905154	DISC, INTERMEDIATE
4989873	SHIM
3924350	ROD, ENGINE CONNECTING
3913990	BUSHING
3929161	PISTON, ENGINE
3991152	HEAD, CYLINDER
3924492	VALVE, INTAKE
3921444	VALVE, EXHAUST
3912976	RETAINER, VALVE SPRING
3532631	HOUSING, TUR BEARING
3533328	BRACKETACTUATOR
3593679	ACTUATOR, TURBOCHARGER
3912837	SHAFT, SHUTOFF VALVE
S1000A	ELBOW, MALE ADAPTER
3285323	PUMP, WATER
S910B	PLUG, PIPE