



Ben Liu

Mobile/ WeChat: +86-13705041170

FUZHOU SUNSHINE MACHINERY CO.,LTD

NO.6 Gulouyuan, Juyuanzhou Industrial Zone,

Jinshan Development Area, Fuzhou, Fujian, China.

Email: sales@primepowergenset.com

<http://www.gensetengine.com>

Cummins ISF2.8 engine Spare parts catalog

Part number	Description
LF17356	PAC, LF
5297747	CONNECTION,TUR OIL DRAIN
4934344	GASKET,OIL PAN
3978818	Bearing, Main (Upper: Standard)
4076930	SWITCH, PRESSURE
2872277	SENSORPOSITION
4076493	SENSORPRESSURE
5282085	PUMP,VACUUM
5264230	CRANKSHAFT, ENGINE
178957	INDICATORRESTRICTION
3900625	SCREWHEX FLANGE HEAD CAP
205227	PLUG, EXPANSION
3032105	BEARINGBALL
2834188	TURBOCHARGER
3042543	SEALO RING
3089016	SCREWHEX FLANGE HEAD CAP
3089568	PLUGTHREADED
3090126	SEALO RING
3093775	SCREWHEX FLANGE HEAD CAP
3093826	SCREWHEX FLANGE HEAD CAP
3093923	SCREWHEX FLANGE HEAD CAP
3093926	SCREWHEX FLANGE HEAD CAP
3093940	SCREWHEX FLANGE HEAD CAP
3102651	SCREWHEX FLANGE HEAD CAP
3289897	BELTV RIBBED
3679118	SCREWHEX FLANGE HEAD CAP

3819900	GASKETTURBOCHARGER
3900068	DOWELRING
3900626	SCREWHEX FLANGE HEAD CAP
3900627	SCREWHEX FLANGE HEAD CAP
3900629	SCREWHEX FLANGE HEAD CAP
3900631	SCREWHEX FLANGE HEAD CAP
3900632	SCREW,HEX FLANGE HEAD CAP
3900678	SCREWHEX FLANGE HEAD CAP
3900679	SCREWHEX FLANGE HEAD CAP
3900955	PLUGEXPANSION
3900956	PLUGEXPANSION
3969562	Bearing, Connecting Rod (Standard)
3901865	SCREWHEX FLANGE HEAD CAP
3902023	SCREWHEX FLANGE HEAD CAP
3902114	SCREWHEX FLANGE HEAD CAP
3902116	SCREWHEX FLANGE HEAD CAP
3902663	SCREWHEX FLANGE HEAD CAP
3903464	SCREWHEX FLANGE HEAD CAP
3903834	SCREWTWELVE POINT CAP
3904383	SCREWHEXAGON HEAD CAP
3904483	PINROLL
3906391	SCREWSOCKET HEAD CAP
3910248	PLUGO RING
3910260	SEALO RING
3913638	SCREWHEX FLANGE HEAD CAP
3914407	SCREWHEX FLANGE HEAD CAP
3919359	ISOLATORVIBRATION
3920706	PLUGEXPANSION
3920854	SCREWCAPTIVE WASHER CAP
4940183	CONNECTOR, MALE
3925402	SCREWHEX FLANGE HEAD CAP
3927948	SCREW,HEX FLANGE HEAD CAP
3929755	STUD
3929777	NUTHEXAGON FLANGE
3932475	GASKETTURBOCHARGER
3935945	
3935946	SOCKET, ROCKER LEVER
3936365	VALVEPRESSURE RELIEF
3939719	INSERT,VALVE
3939720	INSERT,VALVE
3939721	INSERT, VALVE
3949326	DOWELRING
3954099	CAMSHAFT
3957849	SCREWSOCKET HEAD CAP
3967353	TAG, INSTRUCTION

3969833	CAPPIPE
3971371	TUBE, BREATHER
3971615	MOTORSTARTING
3974030	BELT, V RIBBED
3974163	SPACERMOUNTING
3975770	TEESTREET PIPE
3976834	TENSIONERBELT
3977913	SET, LUB OIL COOLER GASKET
3979211	MANIFOLDEXHAUST
4010519	SEALO RING
4058941	SEALO RING
4062328	SEALO RING
4954905	SENSOR,TEMPERATURE
4307346	
4892795	BEARING,CON ROD (010)
4892796	Bearing, Connecting Rod (0,50 mm)
4895877	SCREWSOCKET HEAD CAP
4896355	RETAINERCOVER
4898482	SCREW,HEX FLANGE HEAD CAP
4898590	CLAMPV BAND
4903482	SEALO RING
4921322	SENSOR,PRS TEMPERATURE
4921574	SEAL, O RING
4928599	SEAL,O RING
4940117	SCREW,HEX FLANGE HEAD CAP
4941699	TUBE, INJECTOR FUEL SUPPLY
4941701	TUBE, INJECTOR FUEL SUPPLY
4944374	SEAL, O RING
4946030	BEARING,MAIN (STD)
4946031	BEARING, CRANKSHAFT THRUST
4946432	HEATER,ENGINE
4946649	ADAPTER, FUEL CONNECTOR
4946759	GEAR, FLYWHEEL RING
4955158	TURBOCHARGER,HX35 WASTEGA
4976168	
4976170	SEAL,VALVE STEM
4976246	BUSHING
4976251	RING, OIL PISTON
4976252	RING,COMPRESSION PISTON
4976980	SPRING,VALVE
4978357	SEAL, O RING
4980467	
4980644	SEAL,OIL
4982040	CHAIN
4983279	CONNECTION,OIL TRANSFER

4983654	GASKET,INTAKE MANIFOLD
4983736	
4988653	MANIFOLD,EXHAUST
4990816	
4991149	SEAL,O RING
4992560	SEAL,O RING
4993097	
4993383	HEATER, ENGINE
4994692	*
4995185	SEAL,D RING
4995266	PISTON,ENGINE
4995863	BUSHING
4996250	BEARING, MAIN
5253029	PLATE, COVER
5253505	
5254215	SEAL,RECTANGULAR RING
5254518	
5254599	PULLEY,IDLER
5254871	
5255270	SPROCKET
5255310	
5255312	SEAL,ROCKER LEVER
5255313	GASKET,INJECTOR
5255314	Seal, Oil
5255321	
5255518	CAP, ACTUATOR
5255538	Gasket, Exh Out Connection
5255746	SPRING, COMPRESSION
5256325	GEAR,FUEL PUMP
5256949	VALVE,EXHAUST
5313910	Pulley, Hydraulic Pump
5257057	PIN, PISTON
5257072	SEAL,O RING
5257076	THERMOSTAT
5257077	
5257187	GASKET,CYLINDER HEAD
5257526	NOZZLE,PISTON COOLING
5257728	SCREW,HEX FLANGE HEAD CAP
5258619	WASHER SEALING
5258744	INJECTOR
5258844	
5258888	
5258889	MODULE ELECTRONIC CONTROL
5258898	
5258983	TUBE,INJECTOR FUEL SUPPLY

5259557	MANIFOLD,FUEL
5259562	PLUG, THREADED
5259563	SEAL, O RING
5259643	BRACKET,LIFTING
5259744	
5259745	HOUSING, GEAR
5259767	
5259924	SEAL,O RING
5260318	CONNECTION, WATER TRANSFER
5260319	CONNECTION, WATER TRANSFER
5260765	
5261049	
5261256	Cylinder Block
5261320	VALVE,INTAKE
5261337	
5261340	
5261421	GASKET,EXHAUST MANIFOLD
5262030	
5262173	INSERT,VALVE
5262500	TENSIONER BELT
5262518	
5262617	COVER,VALVE
5262618	
5272961	GEAR, IDLER
5262661	SHAFT IDLER
5262662	
5262663	
5262686	GASKET,COVER PLATE
5262692	PAN, OIL
5302120	PAN, OIL
5262804	HEATER,ENGINE
5262813	INSERT,VALVE
5262898	PUMP,LUBRICATING OIL
5262899	PUMP,LUBRICATING OIL
5262903	SEAL, OIL
5262906	VALVE,PRESSURE REGULATOR
5263080	
5263134	CONNECTION,WATER OUTLET
5263530	Seal, Chain Drive Cover
5263944	SCREW,CONNECTING ROD CAP
5263945	
5263946	ROD,ENGINE CONNECTING
5264231	Crankshaft, Engine
5264426	GASKETS
5264443	

5264444	COVER CHAIN DRIVE
5264477	SEALS
5264757	HOUSING, THERMOSTAT
5265266	SEAL, OIL
5265267	SEAL, OIL
5265277	SEAL, O RING
5265278	TUBE, WATER BYPASS
5266796	RING, LINER SEAL
5266955	COOLER, OIL
5266969	MOTOR, STARTING
5267056	SEAL, O RING
5267149	
5267237	
5267619	
5267973	
5267974	CHAIN
5267993	RING SPEED INDICATOR
5267994	CAMSHAFT
5268245	SHIELD, HEAT
4309423	SET PISTON RING
5269357	
5269358	
5269784	PUMP WATER
5269878	
5269879	SEAL, WATER PUMP
5269930	
5270239	
5270241	CONNECTION, WATER INLET
5270265	CONNECTION, WATER TRANSFER
5270266	
5270363	PULLEY, FAN
5270366	
5270367	
5270378	SUPPORT, FAN
5270739	PUMP, HYDRAULIC
5270760	
5270762	
5307154	HEAD, CYLINDER
5271177	
5271178	HEAD, CYLINDER
5301534	
5271539	LEVER, ROCKER
5271540	Lever, Rocker
5272666	ALTERNATOR
5282176	DAMPER, TUNED VIBRATION

5283275	INJECTOR
5284290	Adapter, Hydraulic Pump
5284537	Bearing, Connecting Rod (Lower)
5284978	
5285750	HOSE, FLEXIBLE
5285962	HEATER,INTAKE AIR
5309066	PULLEY,IDLER
3089239	PLUG, THREADED
5255748	SCREW, FLAT HEAD CAP
5261097	CLAMP, INJECTOR
5258845	SCREW, BANJO CONNECTOR
5270903	DATAPLATE
4993098	CAP, MAIN BEARING
3864113	SCREWHX FLANGE HEAD CAP
5255271	SCREW, SHOULDER CAP
5255434	CAP, ACTUATOR
5262658	GEAR, IDLER
4982085	PIN, ROLL
5262660	SHAFT, IDLER
5302884	MODULE, LUB OIL COOLER
5265739	PLUG, THREADED
5271533	COVER, FRONT
5267095	PLUG, THREADED
5259561	PLUG, THREADED
5284130	CLAMP, SPRING HOSE
5259775	TUBE, BREATHER
5261048	CLIP
4990384	PLATE, CLAMPING
4990385	SCREW, HEX FLANGE HEAD CAP
5262506	BRACKET, ALTERNATOR
3900720	DOWELRING
5262504	BRACKET, ALTERNATOR
502077	RINGRETAINING
5270364	RETAINER, FAN HUB
5270362	HUB, FAN
5270368	PLATE, CLAMPING
5297619	FILTER, FUEL
5258848	HOUSING, FLYWHEEL
5256192	CLIP
5256390	TUBE, FUEL SUPPLY
3947729	BRACE, TUBE
4991125	BRACE, TUBE
5254438	TUBE, FUEL SUPPLY
4945853	CLIP
4942710	SCREW, CAPTIVE WASHER CAP

5267622	MANIFOLD, AIR INTAKE
5267327	SCREW, STUDDED FLANGE CAP
4930983	END, OIL GAUGE TUBE
5270761	DIPSTICK
5265024	CLIP
4980154	NUT, REGULAR HEXAGON JAM
4976169	COLLET, VALVE
4976250	RING, RETAINING
5305334	LEVER, ROCKER
5255568	SHAFT, ROCKER LEVER
2871345	NUTREGULAR HEXAGON
5267691	PIN, CAM FOLLOWER ROLLER
5255413	ROLLER, CAM FOLLOWER
5267686	LEVER, ROCKER
5270357	BALL, ROCKER LEVER
5267687	LEVER, ROCKER
5255567	SPACER, MOUNTING
5262622	SCREW, CAPTIVE SLEEVE CAP
5255315	INSERT, COM LIMITER
5255316	SEAL, O RING
5283162	DECAL
3957139	TUBE FUEL SUPPLY