



Ben Liu

Mobile/ WeChat: +86-13705041170

FUZHOU SUNSHINE MACHINERY CO.,LTD

NO.6 Gulouyuan, Juyuanzhou Industrial Zone,

Jinshan Development Area, Fuzhou, Fujian, China.

Email: sales@primepowergenset.com

<http://www.gensetengine.com>

## Cummins K50 engine Spare parts catalog

Part number	Description
3010247	COV,VLV
3177713	HOUSING,ROCKER LEVER
3643960	SEAL,OIL
3633046	SEALFERRULE
3643961	SHAFTWATER PUMP
4089500	SET PISTONE RING
3037536	PLUG,THREADED
100478	SEALO RING
4026171	GASKET,FUEL PUMP
BM76340	DAMPER,FUEL CONTROL
WF2076	WF PKG
3016792	SEAL,OIL 3016792
4098998NX	CRANKSHAFT,ENGINE (rem)
3053478	LEVER,ROCKER
3053476	LEVER,ROCKER
3053477	LEVERROCKER
3630839	GASKET,RKR LEVER HOUSING
3062676	SEAL,OIL
193736	SEAL,INJECTOR O RING
3521225	SCREWHEXAGON HEAD SET
3008706	SCREENINJECTOR FILTER
3803528	VALVEEXHAUST
3803518	VALVEINTAKE
3922794	SEAL,O RING
3631241	PISTON ENGINE

3076489	THERMOSTAT
212161	ORING
4024809	KIT,FUEL SOLENOID 4024809
175830	PLUGEXPANSION
3640775	SEALTAMPER PROOF
FS1006	FUIL WATER (original) FS1006
3090450	RING,OIL PISTON
3090460	RING,COMPRESSION PISTON
4081176	RING,COMPRESSION PISTON
3081489	SEALOIL
3635074	CORE, COOLER
3078218	SHAFT,CAM FOLLOWER
S172B	SCREW,HEXAGON HEAD CAP
S174	
S181	
S181B	SCREW,HEXAGON HEAD CAP
S181C	SCREW, HEXAGON HEAD CAP
S186	
S189C	SCREW,SOCKET HEAD CAP
S197	
S212	NUT,REGULAR HEXAGON
S224	NUT,HEAVY HEXAGON
S2268	FITTING,GREASE
S2286	DRIVE SCREW
S249	NUT,REGULAR HEXAGON JAM
S270	NUT,REGULAR HEXAGON
S306	
S316	KEY,PLAIN WOODRUFF
S600	WASHER,LOCK
S603	WASHER,LOCK
S606	
S608	WASHER,LOCK
S610	WASHER,LOCK
S611	WASHER,LOCK
S622	WASHER,PLAIN
S626	WASHER
S631	WASHER,PLAIN
S640	WASHER
S915A	PLUG,PIPE
S946	NIPPLE,PLAIN PIPE
S955	BUSHING,REDUCING PIPE
S962E	DRAINCOCK
100099	SEAL,RECTANGULAR RING
100129	SCREWSOCKET HEAD CAP
100193	BUSHING

100217	SHAFTFUEL PUMP DRIVE
102020	SCREW,HEXAGON HEAD CAP
103009	SCREW,HEXAGON HEAD CAP
103023	SCREW,HEXAGON HEAD CAP
103089	WASHER,PLAIN
105375	NAMEPLATE
106069	SCREW,HEXAGON HEAD CAP
106549	SCREWHXAGON HEAD CAP
107534	NUTLOCK
107695	PINROLL
107948	DOWELDIAMOND
108172	SEAL,O RING
108330	WASHER,PLAIN
108602	SCREW,HEXAGON HEAD CAP
108707	SCREWHXAGON HEAD CAP
108767	SCREW,HEXAGON HEAD CAP
109319	LOCKPLATE
109660	NIPPLEPLAIN PIPE
109895	BRACKETOIL TUBE
110058	NUTFUEL PUMP ADJUSTING
110266	SCREW,HEXAGON HEAD CAP
110855	GASKETFUEL PUMP
111445	WASHER,LOCK
112105	ELBOWMALE ADAPTER
114307	BRACE,TUBE
116391	BUSHING
118226	SCREW,SOCKET HEAD CAP
118227	DOWELFUEL PUMP
119364	GEARFUEL PUMPING
124507	GEAR,FLYWHEEL RING
127018	WASHER,LOCK
127316	WASHERPLAIN
127362	WASHER,PLAIN
127454	WASHERPLAIN
127571	WASHER,PLAIN
129510	SCREWHXAGON HEAD CAP
129768	SPRINGVALVE
129838	KNOB
129839	COVER,SHUTOFF VALVE
129888	SEALRECTANGULAR RING
130083	BEARING, THRUST
131026	SEALO RING
131584	PIN,ROLL
135783	WASHER,LOCK
138912	DOWEL,PIN

139473	PLUG,THREADED
139988	SEAL,RECTANGULAR RING
139990	WASHERPLAIN
141629	PLUNGERIDLE SPRING
143854	SPRING,COMPRESSION
144178	PLUNGER,GOVERNOR
144179	SHIM,FUEL PUMP GOVERNOR
145507	SEAL,O RING
145529	SEALO RING
145530	SEALO RING
145536	SEAL, O RING
145550	SEALO RING
145581	SEALO RING
145586	SEALO RING
145600	SEAL,O RING 4998542
145613	SEALO RING
146483	SCREENROTOR
148582	DOWELPIN
149134	LOCKPLATE
151355	LOCKPLATE
151900	SEAL RECTANGULAR RING
153336	BODYFUEL PUMP DAMPER
153338	DAMPER FUEL CONTROL
153346	SCREWSOCKET HEAD CAP
153581	SCREWTWELVE POINT CAP
154087	SEAL,RECTANGULAR RING
154088	SEALRECTANGULAR RING
157088	CAPFUEL PUMP FILTER
158250	SCREW,TWELVE POINT CAP
158826	HUB,JAW COUPLING
160514	WASHER,PLAIN
163086	PLUG,PIPE
163944	BUSHING
163945	RINGRETAINING
167157	BALLCHECK
168306	SCREW,SLOTTED SET
169834	CLIP
170664	WASHERPLAIN
173086	GASKET,INJECTOR
174299	RETAINERINJECTOR FIL SCN
175865	SHAFTFUEL PUMP
3053772	PLUNGER, TAPPET
3018210	Set, Main Bearing (Standard)
181466	WASHER,LOCK
3048182	SEAL,O RING

3069102	GASKETAIR COMPRESSOR
3175255	GEAR,CRANKSHAFT
3521442	SEAL,SPLIT RING
3630125	HOSE,PLAIN
185804	SCREWHEXAGON HEAD CAP
190397	SLEEVEWEAR
191772	SCREW,TWELVE POINT CAP
194037	SOCKETROCKER LEVER
195265	PLUGPIPE
196057	DISCVALVE
199919	SCREWTWELVE POINT CAP
S1040A	ELBOW,MALE ADAPTER
69911A	CLIP
S1047A	ELBOW, HOSE
200845	INSERTTHREADED
205230	BUSHING
3007525	KIT LINER 3007525
3047390	BEARING,CON ROD (STD)
202897	DIAPHRAGM
203426	PIN,INJECTOR ROLL
203760	WASHER,PLAIN
203933	PLUGEXPANSION
205059	WASHER,PLAIN
205091	COLLETVALVE
205094	RETAINERVEALVE SPRING
205126	WASHERPLAIN
205128	WASHER,PLAIN
205129	DOWEL,RING
205168	WASHERPLAIN
205227	PLUG, EXPANSION
205269	RINGRETAINING
3201793	DIPSTICK
205375	SCREWTWELVE POINT CAP
205393	SCREW,TWELVE POINT CAP
205394	SCREW,TWELVE POINT CAP
205401	PLUGEXPANSION
205438	LOCKWIRE
205439	RING,RETAINING
205544	SHAFTLUB OIL PUMP
205565	SCREWTWELVE POINT CAP
205571	GASKETOIL SLINGER
205584	SCREWTWELVE POINT CAP
205683	BUSHING
205684	BRACKETLIFTING
205976	RING,RETAINING

206028	SCREW, SOCKET HEAD CAP
206090	RING RETAINING
206091	GEAR ENGINE BARRING
206093	HOUSING ENGINE BARRING
206158	COVER, HYD PUMP FLANGE
206193	GASKET WATER PUMP
206195	SLEEVE, SPLINE COUPLING
206224	PLUG, EXPANSION
206277	GASKET, INTAKE MANIFOLD
206279	GASKET CONNECTION
206326	SCREW, TWELVE POINT CAP
206406	COVER, HYD PUMP FLANGE
206407	GASKET, HAND HOLE
206416	GASKET SUPPORT
206519	SPACER BEARING
206526	POINTER, TIMING
206527	SCREW, TWELVE POINT CAP
206576	GASKET TURBOCHARGER
206580	BEARING MAIN STD
206587	CAP MAIN BEARING
206588	CAP MAIN BEARING
206590	BEARING MAIN STD
206600	BEARING MAIN STD
206610	BEARING MAIN STD
206646	SHAFT, FUEL PUMP DRIVE
206664	SPACER MOUNTING
206709	TUBE WATER TRANSFER
206742	PLUG, EXPANSION
206747	GEAR, CAM SHAFT
8265	WASHER, PLAIN
206756	GEAR LUBRICATING OIL PUMP
207226	BUSHING
207244	SEAL INJECTOR
207344	BUSHING
207373	COVER, CAM SHAFT
207509	SLEEVE
207538	CONNECTION WATER INLET
208084	RIVET
210753	CLAMP HOSE
211635	PIN, GOVERNOR WEIGHT
212601	SHAFT, FUEL PUMP DRIVE
212602	GEAR, TACHOMETER DRIVE
212603	SEAL, OIL
212604	RING RETAINING
212605	GEAR, FUEL PUMPING

212607	SHAFT,TACHOMETER DRIVE
212609	BUSHING,TACHOMETER DRIVE
212610	GEAR,TACHOMETER DRIVE
60985	HOSE,PLAIN
62279	SPACERMOUNTING
63842	WASHERPLAIN
64709	SPACERMOUNTING
67622	PLUGPIPE
67684	WASHER,PLAIN
67946	WASHER,PLAIN
68171	PINROLL
68193	PLUGPIPE
68908	LOCKPLATE
68910	SEAL,O RING
69519	DOWELPIN
69558	DOWELPIN
69621	SCREW,HEXAGON HEAD CAP
69771	SCREW,SOCKET HEAD CAP
70415	SEAL,O RING
70662	DOWELPIN
70690	PLUNGERFUEL CONTROL
70700	SPRINGFUEL PUMP TORQUE
70704	WASHER PLAIN
70705	GASKET,FUEL PUMP
70713	RETAINERGOVERNOR SPRING
70715	WASHERPLAIN
70716	SCREWKNURLED
70717	SHIMFUEL PUMP GOVERNOR
212613	HUB,JAW COUPLING
212639	ADAPTER,SPLINE
212668	KEYSQUARE
213364	SCREWHEXAGON HEAD CAP
213559	SOCKET,CAM FOLLOWER
213768	SEALO RING
213769	PLUGBALL
214139	BALL
215617	HEAD, CORROSION RESISTOR
218792	SPACERFAN PILOT
219153	BOLTCONNECTING ROD
650826	PLUNGERFUEL CONTROL
3000082	WASHER,PLAIN
3000138	SUPPORTBEARING
3000139	BEARINGTHRUST
3000204	WASHERSEALING
3000446	COVERFUEL CONTROL

3000632	GASKET,CONNECTION
3001340	SEALO RING
3001811	SCREW,HEXAGON HEAD CAP
3002110	CONNECTOR,MALE
3002956	TUBEWATER TRANSFER
3002993	DOWEL,RING
3003156	SEAL,WIRE
3003354	BEARINGROLLER
3004057	NUTLOCK
3004683	GEAR,IDLER
3004686	BUSHING
3004724	SPACER,SEAL
3005436	SCREWTWELVE POINT CAP
3006343	STOPTHROTTLE LEVER
3006344	SCREWSQUARE HEAD SET
3007971	BEARING,CAMSHAFT THRUST
3009380	PLUNGERGOVERNOR
3009475	SHAFTPIVOT
3009477	SLEEVE
3009481	SHAFTIDLER
3009482	BRACKETIDLER PULLEY
3009483	PULLEYIDLER
3010410	COVERACCESS HOLE
3010595	SCREWCAPTIVE WASHER CAP
3010810	PLUNGERGOVERNOR
3011076	SEALO RING
3011715	SCREW,CAPTIVE WASHER CAP
3011884	INSERTLINER
3013036	SHAFTSHUTOFF VALVE
3013266	SCREWCONNECTING ROD CAP
3014103	WASHER PLAIN
3014449	GASKETFLANGE
3014575	CAPFUEL PUMP FILTER
3014668	SEALO RING
3014766	SCREW,CAPTIVE WASHER CAP
3015665	DRIVETACHOMETER
3016611	GEAR & SHAFTGEAR PUMP
3016826	ROLLERCAM FOLLOWER
3017051	SCREW,CAPTIVE WASHER CAP
3017052	SCREWCAPTIVE WASHER CAP
3017961	RODPUSH
3018767	SPRINGCOMPRESSION
3018924	WIRE,GROUND
3019617	GEAR & SHAFTGEAR PUMP
3021123	SEALO RING



3021618	PLUNGERPRS REGULATOR
3021977	COVERSPRING PACK
3022725	VE, PUMP, FUEL AFC CENTRY RH, FCBF94RX, F
3023066	SEAL,O RING
3023095	WASHER SEALING
3023217	PLUG,THREADED
3023499	CAPIDLER LEVER
3023536	SCREWHEXAGON HEAD CAP
3024991	CARRIERGOVERNOR WEIGHT
3025459	PLUGPIPE
3025460	PLUG, PIPE
3025485	WASHERPLAIN
3026312	SHIM
3026313	SHIM
3026557	BEARINGTHRUST
3027633	BEARINGTHRUST
3028291	SEAL,O RING
3028372	ASSEMBLYSHAFT & SPROCKET
3028552	BODYBYPASS VALVE
3030207	RETAINER,DIPSTICK
3030267	COVERFUEL PUMP
3031518	SHAFTFAN HUB
3032627	UNION,MALE
3032628	ELBOW,MALE UNION
3032633	SCREW,TWELVE POINT CAP
3033405	HEAD,LUB OIL FILTER
3033629	PIN,ROLL
3033719	DOWELRING
3033740	VALVECHECK
3033742	PLUGTHREADED
3033853	SHAFTIDLER
3034221	PUMPGEAR FUEL
3034408	SEALO RING
3034412	SEAL,O RING
3034451	HOUSINGACTUATOR
3034452	DISC,ACTUATOR
3035228	SEALO RING
3036460	WASHER,SPRING
3036473	GUIDE,IDLE SPRING PLUNGER
3036666	SEALO RING
3037236	SEAL,O RING
3037537	SEAL,O RING
3037821	GASKET,EXHAUST MANIFOLD
3038743	VALVE, CHECK
3038938	COVER,ROCKER LEVER

3039164	LEVER,CAM FOLLOWER
5412990	BELTV RIBBED
3040721	GASKETCAM FOL HOUSING
3040722	GASKETCAMSHAFT COVER
3040814	PLUGTHREADED
3040818	PLUGTHREADED
4307427	ADAPTER,INJECTOR
3042427	SPRING,COMPRESSION
3042428	SPRING,COMPRESSION
3042430	RETAINERINJECTOR CUP
3042542	SEAL,O RING
3043032	PIPEEXHAUST OUTLET
3043211	GASKET,OIL PAN
3043213	GASKETOIL PAN
3043909	Bushing, Connecting Rod
3044286	CONNECTIONOIL TRANSFER
3045986	SEAL,O RING
3046201	SEALO RING
3046202	PLUG,THREADED
3046407	SCREWSOCKET SET
3046690	SHAFTTHROTTLE
3046852	GASKET,ACC DRIVE SUPPORT
3047665	GASKET,CONNECTION
3048557	SPACER,BEARING
3049041	RETAINERSPRING
3049368	GASKET,CONNECTION
3050454	IMPELLERWATER PUMP
3050624	VALVEPRESSURE RELIEF
3050692	SWITCH,MAGNETIC
3050944	GASKET,FLANGE
3052218	RETAINER,INJECTOR SPRING
3052231	RETAINERINJECTOR LINK
3052233	LINK,INJECTOR PLUNGER
3052906	GASKETTHERMOSTAT HOUSING
3054518	CONNECTIONWATER TRANSFER
172558	CLIP
185747	SEALOIL
205199	SCREWTWELVE POINT CAP
4095009	PIN, PISTON K
205546	COVERLUB OIL PUMP
205548	BUSHING
205659	SPRINGCOMPRESSION
206092	SPRINGCOMPRESSION
206421	GASKETGEAR HOUSING
206446	GASKET WTR TRANSFER TUBE

206505	BEARINGROLLER
206506	NUTLOCK
206520	RINGRETAINING
207038	SEALO RING
4953348	GEAR, CAMSHAFT
207251	GER,PMP
207253	
207551	SEALO RING
216187	SEAL,O RING
2882102	TURBOCHARGER
3001719	PINSTRAIGHT
3004594	GEAR
3005939	GASKETCOVER PLATE
3005940	GASKETGEAR HOUSING
3007441	SEALO RING
3007512	SEALO RING
3008921	GASKETPRS RLF VALVE BODY
3009323	GSK,COV
3009324	GASKET,WATER HEADER COVER 3637727
3009480	PULLEYFAN
3010636	HEADFUEL FILTER
3628973	GSK,PLT
3012603	FLYWHEEL
3015460	SUPPORTFAN
3016766	PULLEYIDLER
3018682	SCR,CAP
3019416	SPRINGTORSION
3025292	TUBELUB OIL SUPPLY
3025294	COVERLUB OIL PUMP
3026163	GER&SFT
3026391	SEALRECTANGULAR RING
3026392	SEAL,RECTANGULAR RING
3026421	SEALO RING
3026676	SCREWHEX FLANGE HEAD CAP
3026677	SCREWHEX FLANGE HEAD CAP
3026678	SCREWHEX FLANGE HEAD CAP
3026925	CONNECTIONOIL TRANSFER
3026926	SPRINGCOMPRESSION
3026927	PLUNGERPRS REGULATOR
3027988	RINGRETAINING
3028368	
3028696	COVER,OIL PAN :3178743
3030487	SPACERBEARING
3031385	VALVE,PRESSURE RELIEF
3031544	SEAL,RECTANGULAR RING

3031545	HUBFAN
3032014	SPRING, COMPRESSION
3032629	PLUG, THREADED
3033627	WASHER, PLAIN
3033628	ADAPTER CRANKSHAFT
3033630	SCREW, HEX FLANGE HEAD CAP
3033739	COVER, FUEL PUMP GEAR
3036970	HOUSING SPRING PACK
3037219	INSERT FILTER HEAD
3040710	TUBE, WATER TRANSFER
3040810	
3040819	PLG, THD
3040911	PLG, THD
3044993	PLUG INJECTOR ORIFICE
3045047	PLUG, INJECTOR ORIFICE
3046287	SPACER MOUNTING
3046943	SEAL O RING
3047924	SCREW, HEXAGON HEAD SET
3049364	GASKET CONNECTION
3049565	HOSE PLAIN
3050945	CONNECTION WATER INLET
3050953	TUBE, WATER TRANSFER
3051069	SPRING COMPRESSION
3052908	GASKET WTR TRF CONNECTION
3053504	
3054411	SPRING LEAF
3054519	BRACE, TUBE
3054852	SPRING COMPRESSION
3055069	PLUG, THREADED
3055710	TUBE, WATER BYPASS
3055712	CONNECTION WATER BYPASS
3057139	ROD PUSH
3058423	PLUNGER PRESSURE LIMITER
3058424	SPRING COMPRESSION
3058809	CONNECTION AIR CROSSOVER
3058812	SEAL, DUST
3058814	CONNECTION AIR INTAKE
3060605	BARREL, PLUNGER, OIL VALVE
3060606	BODY OIL CONTROL VALVE
3060889	HOUSING THERMOSTAT
3062119	BALL, CHECK
3062141	ROLLER, CAM FOLLOWER
3063022	VALVE OIL CONTROL
3063052	GASKET FRONT COVER
3063294	SEAL, GROMMET

3065723	SCREW,CAPTIVE WASHER CAP
3065830	SEALOIL
3065944	SCREW,CAPTIVE WASHER CAP
3066467	UNION,MALE
3066914	SEAL,O RING
3067347	PLG,THD
3067424	PLUG,THREADED
3068859	CAP,TAPPET TOP STOP
3069015	NUTLOCK
3069026	CAP
3069027	COVER,GEAR
3069776	ADAPTER,CRANKSHAFT
3069779	SCREW,TWELVE POINT CAP
3069781	SPACER,CRANKSHAFT
3070108	GASKETBYPASS VALVE BODY
3070186	WASHERPLAIN
3070962	SCREW HEXAGON HEAD CAP
3072040	CONNECTION,AIR CROSSOVER
3073890	BODYFUEL SHUTOFF VALVE
3073998	DISCVALVE
3074304	CAMSHAFT
3074305	CAMSHAFT
3075381	TAPPET,HYD VAR TIMING
3075524	KIT,CVN
3075537	
3076124	
3076126	BARREL & PLUNGER,STEPPED
3076346	SLEEVEWEAR
3081064	HEAD, CYLINDER
3640315	ROTATOR, VALVE
3081413	LEVER,CAM FOLLOWER 3642503
3084539	SEAL,O RING
3084623	MANIFOLD OIL
3084624	MANIFOLD OIL
3085345	SOCKET, TAPPET
3086192	INSERT VALVE
3086362	CROSSHEAD, VALVE
3087563	PAN,OIL
3088317	LOCKPLATE
3088579	SPACER MOUNTING
3088854	PAN OIL
3090769	SCREEN, FILTER
3090770	HOUSING FILTER
3095292	ELBOW MALE ADAPTER
3095773	INJECTOR

3096078	FILTERFUEL
3096857	VALVESHUTOFF
3160924	SEALDUST
4334080	GASKET,CYLINDER HEAD
3175027	WASHER,PLAIN
3175032	GASKETBREATHER
3175058	CLIP
3175074	SCREWHEXAGON HEAD CAP
3175239	NUT,LOCK
3175281	SUPPORTBEARING
3175517	GASKETFLANGE
3175573	RINGRETAINING
3175584	BRACKETOIL TUBE
3175585	BRACKETOIL TUBE
3175716	ELBOW,MALE ADAPTER
3175856	GASKET,HAND HOLE
3175857	SUPPORTWATER PUMP
3175985	COVERLUB OIL PUMP
3176080	
3176216	WEIGHTCRANKSHAFT COUNTER
3176218	DOWEL,RING
3176465	SCREWHEXAGON HEAD CAP
3176552	SEAL,TAMPER PROOF
3176556	SPT,DRV
3176618	DOWEL,DIAMOND
3176637	HOUSINGFLYWHEEL
3176710	TUBEFUEL SUPPLY
3176772	SHAFT,ROCKER LEVER
3176857	DOWELRING
3176918	HOUSING GEAR
3177089	TUBELUB OIL SUCTION
3177108	GASKETFILTER HEAD
3177126	SUPPORTPIVOT SHAFT
3177128	SLEEVEWEAR
3177129	BEARINGTHRUST
3177160	GASKET,GEAR COVER
3177198	ELBOW,MALE UNION
3177433	COVER,LUB OIL FILTER
3177443	SCREWHEX FLANGE HEAD CAP
3177509	BUSHING
3177510	BUSHING
3177591	BRACKETCRN RESISTOR
3177945	SCREWHEX FLANGE HEAD CAP
3178076	GASKET,GEAR HOUSING
3178224	GEAR & SHAFTLUB OIL PUMP

3178225	GEAR & SHAFTLUB OIL PUMP
3178257	SCREW, SOCKET HEAD CAP
3178450	SHAFTIDLER
3178457	Washer, Plain
3178564	PULLEY FAN
3178743	COVEROIL PAN
3178785	COVERHAND HOLE
4955242	BLOCKCYLINDER
3178837	VALVE, SHUTOFF
3178838	ELBOW, PLAIN STREET PIPE
3178947	SCREWHEXAGON HEAD CAP
3179000	DOWELPIN
3179021	SCREW, BANJO CONNECTOR
3179027	GASKETCONNECTION
3179035	GASKET, WTR TRF CONNECTION
3179585	CONNECTIONAIR CROSSOVER
3179664	VALVE, PISTON COOLING
3179850	TUBEWATER TRANSFER
3179853	TUBEWATER TRANSFER
3179856	TUBEWATER TRANSFER
3179859	TUBEWATER TRANSFER
3179866	SUPPORTALTERNATOR
3179922	PULLEYALTERNATOR
3179944	PULLEYACCESSORY DRIVE
3200287	SEALKEYWAY
3201125	SEALO RING
3201128	NUT, REGULAR HEXAGON
3201583	PLUG, THREADED
3201585	SEALO RING
3201739	SHAFT, BARRING
3201740	ASSEMBLY, ENGINE BARRING
3202032	SPACERMOUNTING
3202117	GASKETCONNECTION
3202199	HOUSING, ROCKER LEVER
3202210	GUIDEVALVE STEM
3277045	SPRINGCOMPRESSION
3279620	BODYFUEL PUMP
3279720	CUP, INJECTOR
3279794	SEALINJECTOR O RING
3279821	SCREWINJECTOR STOP
3279850	NUTTAPPET TOP STOP LOCK
LF3325	CTG, FIL
LF777	LF PKGA
3648162	SEAL, DUST
3332255	PLUGGEAR COVER

3379231	ELECTRIC FUEL CONTROL GO
3408250	ISOLATOR,VIBRATION
3408326	JATORELC GOVERNOR WITH SEAL,O-RING 304
3411695	CLAMPINJECTOR
3417076	PLUG,THREADED
3417077	SCREW,SOCKET HEAD CAP
3417096	SCREW,SOCKET SET
3417098	SCREW,SOCKET HEAD CAP
3502449	SEAL,RECTANGULAR RING
3504967	WASHERPLAIN
3519163	SCREWDRIVE
3519535	NUTLOCK
3519627	Bearing, Turbocharger
3519641	RINGRETAINING
3521032	WHEELTURBOCHARGER HC3
3522597	PINROLL
3522904	LOCKPLATE
3523412	SEALSPLIT RING
3523980	SLINGEROIL
3524418	SHIM
3524419	BAFFLEOIL
3525073	SCREWHEXAGON HEAD SET
3527104	DIFFUSERTURBOCHARGER
3527619	DATAPLATE
3528109	CLAMPV BAND
3529372	NUTREGULAR HEXAGON
3533704	IMPELLER,TUR COMPRESSOR
3536588	SHIELDTURBOCHARGER HEAT
3536914	BEARINGTUR THRUST
3537301	RINGRETAINING
3539268	HOUSINGCOMPRESSOR
3591522	COLLARTHURST
3594555	Housing, Tur Bearing
3626479	BRACECONNECTION
4380750	NUT,LOCK 4380750
3626867	SPACER,MOUNTING
3626871	LINKADJUSTING
3626944	
4376118	PUMP,WATER
3627095	SCREWHEXAGON HEAD CAP
3627309	ADAPTER,FILTER HEAD
3627324	BRACKET,MAGNETIC SWITCH
3627381	SEALRECTANGULAR STRIP
3627382	SEALO RING
3627392	MANIFOLDAIR INTAKE



3627393	MANIFOLD AIR INTAKE
3627412	CLIP
3627703	TEEMALE UNION
3627894	LINK INJECTOR PLUNGER
3627927	PLUNGER PRS REGULATOR
3627938	GASKET, COVER PLATE
3627945	SCREW, TWELVE POINT CAP
3627961	SEAL, THERMOSTAT
3628104	SCREW HEXAGON HEAD CAP
3628194	SCREW, HEXAGON HEAD CAP
3628196	SCREW, HEXAGON HEAD CAP
3628229	COVER, HAND HOLE
3628411	COVER STARTER FLANGE
3628452	SCREW HEXAGON HEAD CAP
3628517	CONNECTION FUEL BLOCK
3628518	CONNECTION FUEL BLOCK
3628604	PLUG, PIPE
3628605	PLUG, PIPE
3628606	PLUG, PIPE
3628607	PLUG, PIPE
3628608	PLUG, PIPE
3628609	PLUG, PIPE
3628610	PLUG PIPE
3628650	DAMP VISCOUS VIBRATION
3628755	COVER, CAM SHAFT
3628756	COVER, CAM SHAFT
3628798	GEAR, CRANK SHAFT
3628822	GEAR IDLER
3628823	GEAR, IDLER
3628894	SEAL DUST
3628895	SEAL OIL
3628902	WASHER, PLAIN
3628931	TUBE FUEL SUPPLY
3628967	TUBE WATER TRANSFER
3628968	SUPPORT THM HOUSING
3629065	COVER WATER HEADER
3629066	COVER, WATER HEADER 3648236
4920076	GASKET, ROCKER LEVER COVER
3629141	GASKET, LUB OIL FIL COVER
3629146	CONNECTION, OIL TRANSFER
3629196	CONNECTION WATER TRANSFER
3629256	BELT V RIBBED
3629341	CONNECTION OIL TRANSFER
3629387	GASKET FILTER HEAD
3629408	CONNECTION, FUEL BLOCK

3629409	CONNECTIONFUEL BLOCK
3629410	RETAINERSPRING
3629411	SEATPRS REGULATOR VALVE
3629437	CONNECTORTUBE
3629451	CLIP
3629494	ELBOW,MALE ADAPTER
3629496	ELBOW,MALE ADAPTER
3629497	DRAINCOCK
3629516	CLIP
3629518	CONNECTIONEXHAUST OUTLET
3629538	HOUSING,ROCKER LEVER
3629541	HEADLUB OIL FILTER
3629729	BRACETUBE
3629762	SPACER,MOUNTING
3629820	BRACE,TUBE 3644511
3629821	CLAMP,TUBE
3629855	BUSHING
3629962	WASHER,PLAIN
3630164	PLUG,THREADED
3630172	Manifold, Exhaust
3630173	Manifold, Exhaust
3630505	MANIFOLD, EXHAUST
3630506	EXHAUST MANIFOLD
3630248	CONNECTIONWATER OUTLET
3630249	CONNECTIONAIR CROSSOVER
3630364	CONNECTIONFUEL BLOCK
3630619	CONNECTORMALE
3630741	HEADFUEL FILTER
3630742	GASKET,CONNECTION
3630764	TEEMALE UNION
3630792	TUBEFUEL SUPPLY
3630840	CONNECTORTUBE
3630874	GASKETFLYWHEEL HOUSING
3630969	GASKET,LUB OIL CLR HSG
3630986	COUPLINGPLAIN HOSE
3631163	SCREWHX FLANGE HEAD CAP
3631405	CROSSMALE UNION
3631471	ADAPTERO RING
3631539	BREATHERCRAKCASE
3631572	HOSEMOLDED
3631578	HOSEPLAIN
3631579	COVER,HAND HOLE
3631643	HOSEPLAIN
3631921	COVERWATER TRANSFER
3632225	ROD,ENGINE CONNECTING

3632273	MOTORSTARTING
3632336	HOSE, FLEXIBLE
3632337	HOSEFLEXIBLE
3632879	SPACERMOUNTING
3632942	ELB,UNN
3633045	
3633047	NUTTUBE
3633120	CONNECTION,WATER TRANSFER
3633121	CONNECTION,WATER TRANSFER
3633122	CONNECTION,WATER TRANSFER
3633123	CONNECTION,WATER TRANSFER
3633132	CONNECTION,WATER TRANSFER
3633133	CONNECTION,WATER TRANSFER
3633134	CONNECTION,WATER TRANSFER
3633135	CONNECTION,WATER TRANSFER
3633216	MANIFOLDFUEL
3633217	MANIFOLDFUEL
3633479	NUT,LOCK
3633545	WASHERPLAIN
3633805	CLAMP,V BAND
3643725	SPRING,VALVE
3633972	CLAMP,T BOLT
3633974	CLP,BOL
3641131	CLAMP,T BOLT
3634007	SEAL,WATER PUMP
3634019	PLUGEXPANSION
3634065	SUPPORT,WATER PUMP
3634116	HOSEHUMP
3634172	BRACKETVALVE
3634269	DOWELDIAMOND
3634299	HOSEFLEXIBLE
3634302	HOSEFLEXIBLE
3634389	HOSEFLEXIBLE
3634390	HOSE, FLEXIBLE
3634395	HOSE, FLEXIBLE
3634396	HOSEFLEXIBLE
3634423	PLATESTOP
3634472	HOSEFLEXIBLE
3634473	HOSEFLEXIBLE
3634522	HOSE,FLEXIBLE
3634642	BODYLUBRICATING OIL PUMP
3634643	PUMPLUBRICATING OIL
3634685	UNIONMALE
3634690	UNIONMALE
3634697	UNIONMALE

3635032	HOSEFLEXIBLE
3635033	HOSEFLEXIBLE
3647025	BODYWATER PUMP
3635805	ADAPTER,OIL PAN
3638078	HOSE, FLEXIBLE
3638360	CORE AFTERCOOLER
3639721	KEYSQUARE
3640685	ADAPTERO RING
3648607	GASKET,COVER PLATE
3803852	KIT,ASSESSORY DRIVE SEAL
3804300	SETLOWER ENGINE GASKET
3804700	KIT,STC TAPPET REPAIR
3818885	SEAL,O RING
3913994	SEALO RING
3924052	HOSEFLEXIBLE
3957960	HOSEFLEXIBLE
3957961	HOSEFLEXIBLE
4009248	PINCAM FOLLOWER ROLLER
4009479	PINCAM FOLLOWER ROLLER
4016364	DOWELPIN
4017621	PLUG,EXPANSION
4043604	
4066112	SEAL,O RING
4077027	
4098998	CRANKSHAFTENGINE
4101093	LEVERIDLER
4101094	LEVERIDLER
43696A	SEAL,O RING
43828C	CLAMP,HOSE
4916693	ADAPTER,FILTER HEAD
555273	NUTLOCK
64816A	DOWELPIN
650829	SPRINGVALVE
651045	WASHERPLAIN
67184B	INSERTTHREADED
69028	SCREW,HEXAGON HEAD CAP
69204D	RINGRETAINING
69461	CONNECTORMALE
70183	RINGRETAINING
70717A	SHIM,FUEL PUMP GOVERNOR
70717B	SHIM,FUEL PUMP GOVERNOR
AR12112	Fuel Pump And Mounting Damper
AS401440SS	HOSE, FLEXIBLE
AS6018SS	
S1003A	SEAL, GROMMET

S102	
S103D	SCREW,HEXAGON HEAD CAP
S104	SCREW,HEXAGON HEAD CAP
S105	SCREW,HEXAGON HEAD CAP
S106C	SCREW,HEXAGON HEAD CAP
S109	SCREW,HEXAGON HEAD CAP
S112	SCREW,HEXAGON HEAD CAP
S113	
S116	SCREW,HEXAGON HEAD CAP
S117	SCREW,HEXAGON HEAD CAP
S118	
S125	SCREW,HEXAGON HEAD CAP
S126	Screw, Hexagon Head Cap
S127	SCREW,HEXAGON HEAD CAP
S137	SCREW,HEXAGON HEAD CAP
S140	SCREW,HEXAGON HEAD CAP
S145	SCREW,HEXAGON HEAD CAP
S153	SCREW,HEXAGON HEAD CAP
S16052	BEARING,BALL
S16054	BEARING, BALL
S16069	BEARING, BALL
S162	
S16240	
S164	SCREW,HEXAGON HEAD CAP
S167B	SCREW,HEXAGON HEAD CAP
4989873	SHIM
S910B	PLUG, PIPE
3800729	SETSINGLE HEAD GASKET
S169A	SCREW,HEXAGON HEAD CAP
S162A	SCREW,HEXAGON HEAD CAP
4970456	DATAPLATE
3081411	LEVER, CAM FOLLOWER
205069	LEVER, CAM FOLLOWER
3628799	GEAR, IDLER
3631474	SEAL, O RING
3630068	BODY, PISTON COOLING VALVE
3029415	COVER, LUB OIL PUMP
3175984	COVER, LUB OIL PUMP
3177110	COVER, LUB OIL PUMP
3178223	GEAR, LUBRICATING OIL PUMP
3000624	SHAFT, LUB OIL PUMP
3628097	UNION, TURBO OIL SUPPLY
3634687	UNION,MALE 3634685
3628098	UNION,TURBO OIL SUPPLY
3628720	HOSE, TURBO OIL SUPPLY

3634692	UNION, MALE
3628722	HOSE, TURBO OIL SUPPLY
S907A	PLUG, PIPE
3631805	PLUG, PIPE
3627723	RETAINER, SHAFT
3634066	SUPPORT, WATER PUMP 3634065
3628187	SHAFT, WATER PUMP
3630034	PLUG, THREADED 3023217
3630358	CONNECTION, FUEL BLOCK 3630364
3633212	MANIFOLD, FUEL
3633213	MANIFOLD, FUEL
3628633	ELBOW, MALE ADAPTER
3630765	TEE, PLAIN ADAPTER
3633550	SHAFT, FAN DRIVE
3633548	PULLEY, CRANKSHAFT
3634778	ALTERNATOR
3176012	ASSEMBLY, FRONT ENGINE SUP
3177812	SUPPORT, FRONT ENGINE
S121B	SCREW, HEXAGON HEAD CAP
3627026	COVER, GEAR
4916694	HEAD, FUEL FILTER
3100524	UNION, MALE
S150A	SCREW, HEXAGON HEAD CAP
S167A	SCREW, HEXAGON HEAD CAP
3630681	SEAL, OIL
AR45047	SUPPORT, FUEL PUMP
MP5288	DRIVE, ACCESSORY MTG
3175550	COVER, PROTECTIVE
3279691	BODY, FUEL PUMP
3058559	BARREL, GOVERNOR
3006175	SCREW, FUEL PUMP ADJUSTING
3006440	ASSEMBLY, THROTTLE SHAFT
44678	COVER, SPRING PACK
3004957	SPRING, GOVERNOR MAX
68061A	SEAL, O RING
3630841	CONNECTOR, TUBE
3073891	BODY, SHUTOFF VALVE
3006189	FLYWHEEL
3629545	CONNECTION, AIR CROSSOVER
S166B	SCREW, HEXAGON HEAD CAP
S170A	SCREW, HEXAGON HEAD CAP
3628228	CONNECTION, OIL TRANSFER
3642473	CONNECTION, OIL TRANSFER
3645045	CONNECTION, OIL TRANSFER
3635031	PLUG, THREADED

3629988	PAN, OIL
206099	COVER, OIL PAN
3630510	ADAPTER, OIL PAN
3633434	BRACE, CONNECTION
3633629	DRAINCOCK
3036665	PLUG, THREADED
3053667	PLUNGER, OIL CONTROL VALVE
3060604	BARREL, OIL CONTROL VALVE
3069989	COVER, OIL CONTROL VALVE
4009927	COVER, DIAPHRAGM
3417103	PLUG, THREADED
3627708	HOSE, FLEXIBLE
3627712	HOSE, FLEXIBLE
S108B	SCREW, HEXAGON HEAD CAP
3539756	BAFFLE, TURBOCHARGER NOISE
3632169	ROD, ENGINE CONNECTING
3634694	UNION, MALE
3628939	PULLEY, ACCESSORY DRIVE
3027151	NAMEPLATE
3630107	DECAL KIT
3027935	DECAL
3315228	DECAL
3315230	DECAL
3318651	DECAL
3329609	DECAL
3329610	DECAL
3329611	DECAL
3630483	COVER, PROTECTIVE
3630484	COVER, PROTECTIVE
3889382	DECAL
3630338	HEAD, CORROSION RESISTOR
AK6009SS	HOSE, FLEXIBLE
4080529	DECAL
S102D	SCREW, HEXAGON HEAD CAP
3626716	COVER, PROTECTIVE
3176521	COVERPROTECTIVE
3628649	DAMPER, VISCOUS VIBRATION
108722	CLIP
3086193	INSERT, VALVE
3076033	GUIDE, SPRING
3053476RX	LEVER ROCKER
3086362RX	CROSSHEAD, VALVE
3017961RX	RODPUSH



















PUMP,FUEL AFC,RH FP100D















8182















